

Celebrity

Models S3061, S3061-030, S3077

Ref. No.	Part No.	Description
1	37215021	Cord Reel Housing
	37215047	Cord Reel Housing - S3077
2	170334AG	Gasket
3	19765	Screw
4	46831015	Cord Reel Comp.
5	46383303	Cord
6	170368JM	Plug Insert
7	47348007	Brush Block Comp.
8	34165002	Brush Block Insulator (2)
9	47938	Hinge Pin
10	27482227	Strain Relief Bushing (2)
11	48123AV	Lock Ring
12	12619	Screw (4)
13	170332BZ	Secondary Filter
14	161881	Terminal Lock (2)
15	17001FW	Screw (5)
16	170375JM	Motor Cover
17	48969	Wire Nut (2)
18	21652003	Hex Nut (3)
19	21447014	Screw (2)
20	27479307	Wire Tie
21	170359FP	Rear Rest Pad
	170359PH	Rear Rest Pad - S3077
22	34341006	Retaining Clip
23	160108JJ	Wheel (2)
	160108PH	Wheel
24	161448AG	Rubber Tire
25	160017	Lock Ring (2)
26	169242	Wheel Cover (2)
27	43577074	Motor - 3.7 - (P - 60)
28	169294	Motor Mount - Lower
29	170374JM	Blower Adapter
30	170339	Spring
31	41421129	Bottom Pan Comp.
	41421025	Bottom Pan Comp. - S3077
32	23737202	Caster Wheel
33	31721004	Spacer (3)
34	31194005	Muffler
35	169293	Motor Mount - Upper
36	42213126	Intermediate Shell Comp.
37	170352AG	Bag Collar Connector
38	39457006	Handle
39	46326076	Connector
40	36151012	Latch

Ref. No.	Part No.	Description
41	48512FW	Shell Cover Latch Spring
42	16439JX	Shell Cover Latch
43	166735EF	Screw (2)
44	4010009H	Throw Away Bag (3 Pk.)
45	37911002	Vacuum Control Panel
46	21479229	Screw (Control Panel) (5)
47	21447003	Screw
48	170361JM	Furniture Guard
49	42211193	Upper Shell
	37211017	Upper Shell - S3077
50	32172002	Bag Indicator Seal
51	51151002	Full Bag Indicator Comp.
52	170344HE	Cam (2)
53	170345AG	Vacuum Control Button (Min.)
54	38422002	Vacuum Control Button (Med.)
55	38422007	Vacuum Control Button (Max.)
56	47538005	Switch Actuator Assm.
57	162961	Insulating Pod (Pigtail) (2)
58	163055	Terminal (Pigtail) (2)
59	38421017	Switch Button
60	170370JM	Control Panel Cover
	170370PH	Control Panel Cover
61	51481002	Control Panel
	51481004	Control Panel - S3077
62	46312016	Pigtail Cord
63	46831076	Commutator
64	19999	Ratchet
65	38331004	Detent Spring
66	170343AY	Cord Reel Bracket
67	51661008	Medallion


ITEMS NOT ILLUSTRATED

170351AW Hinge Leaf Upper (Upper Shell)

PACKAGING MATERIAL

56513056 Owner Manual
 58132009 Nozzle Carton
 58332001 Nozzle Support
 56513038 Owner Manual - S3077

Powermatic Nozzle



Motor 43177043



Mounting Tab (Secure to boss on Nozzle Body w/ Screw 21447007)



Models S3127, S3147, S3161

(After Jan. 1990)

Models S3057, S3059, S3059-030, S3061, S3061-030, S3077, S3079, S3079-030, S3079-035, S3081, S3083, S3083-030, S3093, S3127, S3131, S3131-030, S3133, S3135, S3137, S3139, S3139-035, S3141, S3147, S3149, S3153, S3161, S3173




Ref. No.	Part No.	Description
	48416004	Agitator Assm. Comp.
1	48495 AY	Thread Guard Assm. - L.H.
2	12987	+* Retainer Clip (2)
3	13010	* Washer - Felt (2)
4	12978	Agitator Bearing Assm. (2) (Use w/Item 2 & 3)
	43267002	Agitator Bearing Assm. (2) (Current)
5	21347003	* Washer (2)
6	160542	Agitator End Assm.
7	160070	Agitator Shaft
8	160646 BZ	Agitator Brush Back Assm. (2)
9	160538	Agitator End Pulley
10	12985 AY	Agitator Thread Guard Assm. - R.H.

Celebrity Motor

Motor - 1 Speed - 43577074 (3.7)

Motor - 2 Speed - 43577093 (3.7)




43577093 Motor Comp. - S3153, S3141
 43577074 Motor Comp. - S3059, S3059-030, S3061, S3061-030, S3077, S3139, S3139-035, S3173, S3217, S3219, S3233

Ref. No.	Part No.	Description
1	12022	Field Bolt
2	21429406	Screw
3	168038	Brush Carrier
4	168506-	Brush Holder
5	167679	Carbon Brush
6	27666551	Terminal
7	38353004	Spring
8	169706	Motor Housing - Upper
9	44765106	Armature
10	45311018	Field - 2 Speed - 3.7
	45311022	Field - 1 Speed - 3.7
11	167721FW	Spring
12	41823001	Motor Housing - Lower
13	169702BZ	Bushing
14	167695EF	Nut
15	21312774	Washer
16	43566006	Fan
17	31732003	Spacer
18	169712	Interstage
19	33426001	Nut
20	37218005	Diffuser
21	34786002	Spring Clip
22	169713FW	Mounting Plate
23	31148002	Spacer
25	168506	Brush Carrier Assm.

Cleaning Tools

Models S3059, S3059-030, S3061, S3061-030, S3079,
S3079-030, S3083, S3083-030, S3127, S3147, S3149, S3161



Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
1	43414057	Furniture Nozzle Comp.	10	13257BZ	Suction Regulator Support
2	38617017	Crevice Tool	11	13142AG	Suction Regulator Control
3	13077JM	Floor Brush Assm.	12	13275	Screw
	43414073	Floor Brush Assm.	13	12783	Rivet
4	13155JM	Brush Back & Nozzle Assm. (Use w/13077JM)	14	12846AG	Tube Latch (2)
5	13276	Floor Brush Swivel Bushing (Use w/13154JM)	15	12845JM	Gasket (2)
	33712007	Split Ring (Use w/38644040)	16	12772	Rivet
6	13154JM	Swivel Connector (Use w/13077JM)	17	12783	Rivet (2)
	38644040	Swivel Connector (Use w/48473025)	18	12763AW	Rivet
7	13263BZ	Brush (Use w/161851JM)	19	36171005	Cord Clip
8	161851JM	Dusting Brush Comp.	20	43453085	Ext. Tube (2) (17")
	43414064	Dusting Brush (One Piece)		43453052	Ext. Tube 20 - AX- S3127, S3161
9	43438022	Current Carrying Hose & Tube	21	36153009	Latch Ring
	43433085	Current Car in Hose	22	43468055	Hose Tube (Early)
				43453023	Ext. Tube - AX- 20 - S3127, S3161 (Current)
				170110	Shag Vac Rake - S3161 S3149