


This Owner's Manual is provided and hosted by [Appliance Factory Parts](#).



HOOVER S3129 Owner's Manual

[Shop genuine replacement parts for HOOVER S3129](#)




[Find Your HOOVER Vacuum Cleaner Parts - Select From 1456 Models](#)

----- Manual continues below part list -----

Available Replacement Parts for HOOVER S3129

H-43414073	Floor brush.
H-43414064	DUSTING BRUSH (ONE PEICE)
HR-5000	EXTENSION TUBE



Ref. No.	Part No.	Description
1	36433034	Tool Rack - LZ
2	37215123	Cord Reel Cover - KP
3	36218014	Cord Guide
4	48383068	Attach. Cord - AG
5	48831106	Cord Reel - AAP
6	31193010	Seal
7	21388004	Speed Nut
8	34141004	Wire Shield
9	48969	Wire Nut
10	47348045	Brush Block
11	34135006	Insulator
12	21447003	Screw
13	47938	Hinge Pin
14	27482120	Strain Relief
15	35214004	Hinge Leaf - Upper
16	48123AV	Lock Ring
17	170361JM	Furniture Guard
18	21447014	Screw
19	21447003	Screw
20	38764006	Filter
21	17001FW	Screw
22	27482227	Strain Relief
23	37196060	Motor Cover - JM
24	46311142	Pigtail Cord - AAP
25	27479307	Wire Tie
26	36921008	Rest Pad - JJ
27	170348AW	Hinge Leaf - Lower
28	42213325	Intermediate Shell - JJ
29	169293	Resilient Mount - Upper
30	43577101	Motor - 2.6 - (P - 90)
31	169294	Resilient Mount - Lower
32	31114008	Muffler
33	31721025	Spacer
34	41421298	Bottom Pan - JJ
35	23737202	Caster Wheel
36	170352AG	Bag Collar Connector
37	36151012	Latch - BZ
38	39457006	Handle - JM
39	48512FW	Spring
40	16439JX	Latch
41	160862	Screw
42	21447014	Screw
43	21652003	Hex Nut
44	4010009H	Paper Bag (3 Pk.)
45	38198	Screw
46	21447009	Screw
47	42211301	Upper Shell - KP
48	52125022	Nameplate
49	38332001	Spring
50	43138024	Brake Assm. w/Pad
51	28212008	Switch
52	37215132	Cover Plate - KP
53	21447017	Screw
54	34861007	Cam
55	34783003	Pedal Spring
56	31514004	Shaft
57	38433051	Switch Pedal
58	38433060	Brake Pedal

ITEMS NOT ILLUSTRATED


48831076	Commutator (Component of Cord Reel Assm.)
56513103	Owner Manual
58177087	Cleaner Carton
58254001	Front Bottom Support
58336001	Rear Bottom Support
58346003	Top Support

Celebrity Motor




Models S3129, S3137, S3171, S3187, S3193,
S3195, S3199, S3201, S3219, S3237, S3239

Motor - 2 Speed 43577093 (3.7)


Motor - 43577101 (2.6)



Ref. No.	Part No.	Description
	43577101	Motor - (2.6) S3129, S3137, S3171, S3187, S3193, S3195, S3219
	43577093	Motor Comp. - (3.7) S3199, S3201, S3237, S3239
1	12022	Field Bolt
2	21429406	Screw
3	168038	Brush Carrier
4	168506--	Brush Holder
5	167679	Carbon Brush
6	27666551	Terminal
7	38353004	Spring
8	169706	Motor Housing - Upper
9	44765078	Armature (2.6)
	44765106	Armature (3.7)
10	45311017	Field Coll (2.6)
	45311018	Field Coll (3.7) 2-Speed
11	167721FW	Spring (3.7)
	38311016	Spring (2.6)
12	41823001	Motor Housing - Lower
13	169702BZ	Bushing
14	167695EF	Nut
15	21312774	Washer
16	43566006	Fan
17	31732003	Spacer
18	169712	Interstage
19	33426001	Nut
20	37218005	Diffuser
21	34786002	Spring Clip
22	169713FW	Mounting Plate
23	31148002	Spacer
25	168506	Brush Carrier Assm.



A	4341401	Rug & Floor Nozzle - AAP - S3125, S3125-035, S3171
1	43463012	Connector Tube
2	13267	Felt Gasket
3	38615156	Nozzle Body - JM
4	13259PH	Litter Picker
5	15963FW	Spring
6	13261AY	Rib Shoe
7	16184	Brush Back
8	161413	Tube Retainer
9	13272	Roller Shaft
10	42246002	Bottom Plate
11	12955	Screw
12	13157AG	Roller



B	N/A	Rug & Floor Nozzle AAP - S3121, S3123, S3165, S3169 - (Use 4341401P)
1	166652JM	Nozzle Tube (See Note)
2	166651	Gasket
3	43414089	Nozzle Body - JM
4	166646	Brush Retainer
5	166650AY	Tube Clamp
6	166648AW	Screw
7	166649FW	Spring
8	166656	Brush Back

C	4341401	Rug & Floor Nozzle - AAP - S3129
1	34113001	Foam Seal
2	169241AW	Washer
3	169239AG	Wheel
4	13730	Lock Ring
5	169242	Wheel Cover
6	38615160	Nozzle Body - JM
7	34112001	Foam Seal
8	34223002	Felt Seal
9	169250AG	Brush Housing
10	169253AY	Rib Shoe
11	169256	Brush Back
12	169247JM	Furniture Guard
13	169251	Gasket
14	169538	Bottom Plate
15	21481464	Screw
16	21481465	Screw
17	169243AG	Roller
18	21312758	Washer
19	169244AW	Roller Shaft
20	24735081	Lock Ring
21	166649FW	Spring
22	34513001	Foam Seal - L.H.
23	34513002	Foam Seal - R.H.
24	169240AY	Wheel Shaft
25	169249JM	Connector Tube
26	34122006	Seal
27	169254JM	Control Knob

Cleaning Tools

Models S3121, S3123, S3125, S3125-035, S3129 S3165, S3169, S3171

Ref. No.	Part No.	Description
1	43434191	Hose - JM
2	161852JM	Furniture Brush
	43414016	Furniture Brush - AG
3	13077JM	Floor Brush
	43414073	Floor Brush
4	161851JM	Dusting Brush
	43414064	Dusting Brush (One Piece)
5	43414057	Furniture Nozzle
6	38617017	Crevice Tool
7	43453027	Extension Tube
8	12845JM	Gasket
9	13263	Brush (Use w/161851JM)
10	13253AG	Brush Back
11	13276	Swivel Bushing (2) (Use w/13154JM)
	33712007	Split Ring (Use w/38644040)
12	13154JM	Swivel Connector (Use w/13077JM)
	38644040	Swivel Connector (Use w/48473025)
13	13254BZ	Brush (Use w/161852JM)
14	13149JM	Connector Tube (Use w/161852JM)
15	32855003	Hose Connector
16	12615BZ	Collar
17	32156010	Sleeve
18	43434213	Hose Complete
	43434203	Hose Complete
19	36116006	Collar
20	43466044	Hose Grip-JM
21	38711006	Suction Control Ring
22	51869006	Label
23	36153009	Latch Ring
24	3863801P	Extension Tube - Poly - AG

170110

Shag Rake- S3165