


This Owner's Manual is provided and hosted by Appliance Factory Parts.



HOOVER S3247 Owner's Manual

[Shop genuine replacement parts for HOOVER S3247](#)




[Find Your HOOVER Vacuum Cleaner Parts - Select From 1456 Models](#)

----- Manual continues below part list -----

Available Replacement Parts for HOOVER S3247


H-4010028K	BAG OEM HOOVER (3 PACK) K
HR-1810	FILTER HOOVER MESH FILTER
H-43414073	Floor brush.
H-43414064	DUSTING BRUSH (ONE PEICE)
HR-5000	EXTENSION TUBE



Ref. No.	Part No.	Description
1	21447041	Screw
2	37195047	Motor Cover - JM - S3241, S3291
	37195041	Motor Cover - MX - S3247
	37195047	Motor Cover - S3479
3	34163003	Diffuser
4	21366004	Speed Nut
5	34133007	Seal
6	34132006	Pad
7	34143002	Seal
8	43577109	Motor - 1.7 - (P-1 1 1)
	43577013	Motor - 2.2 - S3479 - (P-1 63)
9	12227	Insulated Terminal (2 Wire)
	48969	Wire Nut (2 Wire)
10	46363039	Attach. Cord - AAP - 16
11	27482301	Strain Relief
12	38511015	Wheel Bearing - AG
13	38522041	Wheel - LE - S3241
	38522061	Wheel - AG - S3247, S3291
	38522058	Wheel - AAP - S3479
14	38521036	Wheel - AG
15	41432040	Wheel Carrier - (Incl. Wheel)
17	37231027	Main Body - MH - S3241, S3291
	37231043	Main Body - AAG - S3247
	37231070	Main Body - AAP - S3479
18	36151015	Latch
19	31114009	Filter
20	36426012	Filter Support
21	36321011	Motor Retainer
22	21447072	Screw
23	28162007	Switch
24	37214051	Control Panel - LE
	37214031	Control Panel - LY - S3247
	37214066	Control Panel - MY - S3241, S3291
	37214052	Control Panel - M - S3479
25	38781010	Seal
26	4010028K	Paper Bag - 3 Pk.
27	42212007	Lid - MH - S3241, S3291
	42212009	Lid - LB - S3247
	42212090	Lid - AAP - S3479
	56513208	Owner Manual
	56513218	Owner Manual - S3291
	56513271	Owner Manual - S3479
	58173227	Carton - S3241
	58173232	Carton - S3247
	58173374	Carton - S3291, S3479
	58353007	Bottom Support
	58364013	Front Support
	58461021	Rear Support
	58351015	Mid Pad - S3291, S3479
CLEANING TOOLS - (P-93)		
	43414015	Furniture Brush
	43414016	Furniture Brush - AG
	38617017	Crevice Tool - AG
	43434065	Hose - JM
	43434131	Hose - AAP - 7 Ft.
	3863801P	Extension Tube - Poly - AG
	0M114169	Rug & Floor Nozzle - AAP - (P-93/94/188)
	43434013	CL. Tool Hose Assem. - S3247
	43434233	Hose - AAV - 6- Molded - Spirit


Motor

Model S3203, S3205, S3207, S3209, S3211, S3213, S3241, S3243, S3245, S3247, S3257, S3261, S3263, S3265, S3267 S3291, S3293, S3295, S3401, S3403, S3433



MOTOR 43577109 - (1.7)





Ref. No.	Part No.	Description
1	33426001	Nut
2	21312701	Washer
3	21434224	Screw
4	37191016	Outerstage Housing
5	43566017	Fan
6	43551005	Interstage
7	31742010	Spacer
8	21429406	Screw
9	167696AG	Brush Carrier
10	N/A	Brush Holder - Use Brush Carrier Assem. - 47318008 (Inlc. It. 9 - 12)
11	38353004	Spring
12	167681	Carbon Brush
13	42937003	Motor Housing - Upper
14	169702BZ	Bushing
15	33421004	Bolt
16	31195002	Insulator
17	45311035	Field Coil
18	167721FW	Spring
19	44765171	Armature
20	37191085	Motor Housing - Lower
21	31148002	Spacer
22	36322002	Mounting Plate
23	167695EF	Nut



Ref. No.	Part No.	Description
1	43434191	Hose - JM - S/C - 6"Wire - Celebrity
	43434155	Hose - JM - S/C - 6"Wire - Spirit
	43434013	Hose Assem. - Stretch (not pictured)
	43434065	Hose - JM - 6"Wire - Spirit
	43434130	Hose - JM - 7.5" Molded - Spirit
	43434131	Hose - AAP - 7.5' - Molded - Spirit
	43434125	Hose - AAP - S/C - 7' - Molded - Spirit
	43434126	Hose - AAV - S/C - 6' - Molded - Spirit
	43434231	Hose - AAP - 6' - Molded - Spirit
	43434233	Hose - AG/ABX 6" Molded - Sprint
	2	43414072
	43414073	Floor Brush - AG
3	43414064	Dusting Brush - AG
4	43414057	Furniture Nozzle - AAP
	38614020	Furniture Nozzle - JM - 1 Pc.
	38614024	Furniture Nozzle - AG - 1 Pc.
5	43453037	Extension Tube - Poly - 20 - JM
	3863801P	Extension Tube - Poly - AG
6	43453052	Extension Tube - 20 - AX
7	38617017	Crevice Tool - AG
8	12845JM	Gasket
9	48447001	Brush Back
10	43414015	Furniture Brush - JM
	43414016	Furniture Brush - AG
11	33712007	Split Ring
12	38644020	Swivel Connector - AG
	38644040	Swivel Connector - AAP
13	32855003	Hose Connector - Celeb.
	38638017	Hose Connector - AAP - Molded Hose
	38638019	Hose Connection - AAP
	38638039	Hose Connector - AG - Molded Hose
14	12615BZ	Collar (All Wire Hoses)
	38671011	Collar (Molded Hoses)
15	32156010	Sleeve (All Hoses)
16	38671029	Hose - 6' - AAV - Molded
	38671033	Hose - 6' - ABX - Molded
17	36116006	Collar (All Wire Hoses)
	36171025	Collar (Molded Hose)
18	43466044	Hose Grip - AAP - S/C
	43466066	Hose Grip - AG
19	38711006	Suction Control Ring - JM
	38711007	Suction Control Ring - MV
20	36153009	Latch Ring - AG
21	43414139	Rug & Floor Nozzle - AAP - (P - 188)
	0M114169	Rug & Floor Nozzle - ABE - (P - 188)
22	43414101	Rug & Floor Nozzle - DLX - (P - 188)



Rug & Floor Nozzle

Models S3183, S3187, S3187-030, S3203, S3205, S3207, S3215, S3241, S3247, S3257, S3259, S3289, S3291, S3299, S3299-031, S3401



A	48476026	Rug & Floor Nozzle - AAP - S3205, S3299, S3299-031 (Replaced by 43414101 +)
1	43463012	Connector Tube
2	13267	Felt Gasket
3	38615156	Nozzle Body - JM - S3299
4	13259PH	Litter Picker
5	15963FW	Spring
6	13261AY	Rib Shoe
7	16184	Brush Back
8	161413	Tube Retainer
9	31524005	Roller Shaft
10	42246002	Bottom Plate
11	12955	Screw
12	13157AG	Roller
B	43414105	Rug & Floor Nozzle - AAP - S3183, S3203, S3215, S3241, S3247, S3289, S3291, S3401 (Replaced by 43414121)
1	166652JM	Nozzle Tube (See Note)
2	166651	Gasket
3	43414089	Nozzle Body - JM
4	166646	Brush Retainer
5	166650AY	Tube Clamp
6	166648AW	Screw
7	166649FW	Spring
8	166656	Brush Back
C	48476064	Rug & Floor Nozzle - AAP - S3187, S3187-030 (Replaced by 43414101)
	48476066	Rug & Floor Nozzle - JM - S3207, S3257 (Replaced by 43414101)
	43414101	Rug & Floor Nozzle - MX - S3259
1	34113001	Foam Seal
2	169241AW	Washer
3	169239JR	Wheel
	169239AG	Wheel - S3207
4	13730	Lock Ring
5	169242	Wheel Cover
6	38615161	Nozzle Body - JM
7	34112001	Foam Seal
8	34223002	Felt Seal
9	169250AG	Brush Housing
10	169253AY	Rib Shoe
11	169256	Brush Back
12	169247JR	Furniture Guard
	169247JM	Furniture Guard - S3207, S3257
13	169251	Gasket
14	169538	Bottom Plate
15	21481464	Screw
16	21481465	Screw
17	169243AG	Roller
18	21312758	Washer
19	169244AW	Roller Shaft
20	24735081	Lock Ring
21	166649FW	Spring
22	34513001	Foam Seal - L.H.
23	34513002	Foam Seal - R.H.
24	169240AY	Wheel Shaft
25	169249JM	Connector Tube
26	34122006	Seal
27	169254JM	Control Knob

Rug & Floor Nozzle



Ref. No.	Part No.	Description
1	43414121	Standard Rug & Floor Nozzle Assem. - AAP
	43414139	Standard Rug & Floor Nozzle Assem. - AAP
	43414140	Standard Rug & Floor Nozzle Assem. - ABE (S3393-020, S3521)
	0M114169	Standard Rug & Floor Nozzle - ABX - S1221, S1315, S1337, S3393-040
	43414170	Standard Rug & Floor Nozzle AG - S1339, S3547
2	43414172	Standard Rug & Floor Nozzle - AG
	38646039	Nozzle Tube - AG
3	38615153	Rug & Floor Nozzle - AAP
	38615182	Rug & Floor Nozzle - ABE S3393-020, S3521, S1339, S3547, S1221, S1315, S1337
4	38521018	Roller (2) (Nozzle 43414172 req's 4)
5	31511004	Roller Axle - AY (2) (Nozzle 43414172 req's 4)
6	36414018	Brush Housing S1221, S1315, S1337
7	166649FW	Spring (2)
8	48443003	Brush Back Assem. - AG
9	21447203	Screw - Self Tapping (2)
10	38454004	Brush Back Lever - MV
	38454006	Brush Back Lever - ABN S3393-020, S3521, S1221 S1339, S3547
11	21329105	Felt Washer

Ref. No.	Part No.	Description
1	43414101	Deluxe Rug & Floor Nozzle Assem. - AAP
2	38646045	Nozzle Connector - AAP
3	43244043	Wheel & Bearing Assem. (2)
4	38511016	Wheel Bearing - AAT (2)
5	38615180	Rug & Floor Nozzle - AAP
6	38521018	Roller (2)
7	31511004	Roller Axle - AY (2)
8	38451008	Slider - AG
9	36414013	Brush Housing - MV
10	166649FW	Spring (2)
11	48443004	Brush Back Assem. - AG
12	21447203	Screw - Self Tapping (3)
13	34122013	Seal (2)
14	38434015	Pedal - MV