

Ref. No.	Part No.	Description
1	21447041	Screw
2	42219044	Motor Cover/Control Panel - JM
3	34163003	Diffuser
4	21366004	Speed Nut
5	38422073	Switch Pedal - AG
6	38314002	Spring
7	34133007	Seal
8	34132006	Pad
9	34143002	Seal
10	43577109	Motor - (P-111)
11	48969	Wire Nut
12	38458008	Brake Arm
13	38353009	Spring
14	37215167	Cord Reel Support - MP
15	36222008	Brake Pad
16	21447003	Screw - 5/8
	21447072	Screw - 7/8
17	47348076	Brush Block
18	46383311	Attach. Cord - AG - 20
19	46831106	Cord Reel - AAP
20	38511015	Wheel Bearing - AG
21	38522061	Wheel
23	41432040	Wheel Carriage - AG
24	46326079	Receptacle Assem. - AG
25	37231048	Main Body - MR
26	36151015	Latch
27	4010028K	Paper Bag - (3-Pk.)
28	31114009	Filter
29	36426012	Support
30	36321011	Motor Retainer
31	21447072	Screw
32	34287021	Exhaust Muffler
33	38422080	Cord Reel Pedal - MS
34	28212026	Switch
35	42219044	Motor Cover / Control Panel - JM
38	51151010	Bag Indicator
39	38781010	Lid Seal
42	21378154	Clip
44	42212023	Bag Housing Lid - MP
45	36433044	Tool Rack - MP
46	21447003	Screw

ITEMS NOT ILLUSTRATED


46831076	Commutator (Component of Cord Reel Assm.)
56513211	Owner Manual
58184003	Carton
58216009	Bottom Pad
58332014	Bottom Support
58366061	Mid Pad
58461023	Top Support

CLEANING TOOLS - (P-92)

43414073	Floor Brush
43414057	Furniture Nozzle
43414064	Dusting Brush -
38617017	Crevice Tool -
43433111	Hose - 2W - AG
43453052	Extension Tube - 20 - AX
43453023	Extension Tube - 20 - AX
48438044	Power Nozzle ( P. 126 )

# Motor

**Model S3203, S3205, S3207, S3209, S3211, S3213, S3241, S3243, S3245, S3247, S3257, S3261, S3263, S3265, S3267 S3291, S3293, S3295, S3401, S3403, S3433**





## MOTOR 43577109 - (1.7)

Ref. No.	Part No.	Description
1	33426001	Nut
2	21312701	Washer
3	21434224	Screw
4	37191016	Outerstage Housing
5	43566017	Fan
6	43551005	Interstage
7	31742010	Spacer
8	21429406	Screw
9	167696AG	Brush Carrier
10	N/A	Brush Holder - Use Brush Carrier Assem. - 47318008 (Inlc. It. 9 - 12)
11	38353004	Spring
12	167681	Carbon Brush
13	42937003	Motor Housing - Upper
14	169702BZ	Bushing
15	33421004	Bolt
16	31195002	Insulator
17	45311035	Field Coil
18	167721FW	Spring
19	44765171	Armature
20	37191085	Motor Housing - Lower
21	31148002	Spacer
22	36322002	Mounting Plate
23	167695EF	Nut

# Power Nozzle

# Model S3265, S3267, S3295, S3295-031








Ref. No.	Part No.	Description
	48438055	Power Nozzle - TF - (Same as 48438033 except 4.5' Cord)
	48438033	Power Nozzle Comp. - TF - S3295, S3295-031
1	48438044	Power Nozzle
	46321088	Cord - 3.5'
2	46321005	Attachment Cord
3	36231103	Furniture Guard - MD
4	48416030	Agitator - 4B
5	163768	Strain Relief
6	21447041	Screw
7	27479307	Wire Tie
	36131044	Retainer Housing - MP
	36131022	Retainer Housing - TF - S3295, S3295-031
8	43461021	Nozzle Connector - AG
9	34112005	Seal
10	34337003	Seal
11	47171009	Lamp Socket
12	48969	Wire Nut
14	42256098	Duct Cover
15	34123017	Seal
16	35276001	Detent Spring
17	32175025	Wheel - AG
18	31523005	Wheel Shaft
19	32761001	Wheel
20	31522004	Wheel Shaft
21	21447007	Screw
22	42246121	Base Plate (Inc. items 17,18,19,20,23)
23	34337004	Lower Seal
	34378010	Upper Seal
24	51865018	Indicator Lens Nameplate
25	36218005	Grommet
26	27317307	Lamp - 15
27	43177073	Motor
28	39382013	Indicator Lens
29	27666702	Terminal
30	37258082	Shield
31	281770KD	Switch
32	51151053	Indicator - PH
33	34361001	Switch Actuator
34	42262032	Housing
35	36131017	Retainer
36	38353007	Torsion Spring
37	31523006	Pivot Pin
38	38458002	Depressor
39	38433054	Switch Pedal - MR
	38433044	Switch Pedal - MY - S3295, S3295-031
40	38528011	Belt
41	42252189	Nozzle Body - AG
42	52125092	Nameplate
	51377018	Nameplate - S3295, S3295-031
43	39383060	Lens - KC
44	43457037	Swivel Tube - AG

Ref. No.	Part No.	Description
1	48416030	Agitator
2	48495AY	Thread Guard
3	43267002	Bearing
4	21347003	Washer
5	41435023	Agit.End (Inc. items 2,3)
6	48445017	Agitator Brush
7	41435018	Thread Guard
8	38537008	End Pulley
9	48418001	Brush Ring
10	31722019	Spacer
	32724005	Shaft

# Cleaning Tools

# Spirit & Celebrity



Ref. No.	Part No.	Description
1	43433085	Hose - AAP - Celebrity
2	43433032	Hose - JM - Spirit - 5-1/2'
3	43433067	Hose - AAP - Spirit - 5-1/2'
	43433081	Hose - MV -S/C- Spirit - 5-1/2'
	43433084	Hose - AAP - S/C - Spirit - 7'
	43433111	Hose - 2W - AG -S/C - Spirit
4	46321076	Cord Repair Kit
5	34777005	Suction Reg. Control - AG
	34777007	Suction Reg. Control - MV
6	36153009	Latch Ring - AG
7	43468055	Hose Tube - BL - 14
8	43453086	Extension Tube - BL - 22
	43453035	Extension Tube - AX - 22
	43453052	Extension Tube - 20 - AX (Gray Clip)
	43453058	Extension Tube - BL - 20 (Gray Clip)
9	3863801P	Extension Tube -Poly - AG
10	43453027	Extension Tube
11	43414073	Floor Brush - AG
12	38614023	Furniture Nozzle - 1 Pc. - 17
	43414057	Furniture Nozzle - AG
	38614024	Furniture Nozzle - AG
13	43414064	Dusting Brush - AG
14	38617017	Crevice Tool - AG
15	43414015	Furniture Brush - JM
	43414016	Furniture Brush - AG
16	38644040	Swivel Connector - JM
	38644020	Swivel Connector - AG
17	33712007	Split Ring
18	48447001	Brush Back
19	12845JM	Gasket
20	12783	Rivet
21	36171008	Cord Clip - MV
	36171005	Cord Clip - AG
22	13275	Screw
23	13142AG	Suction Control
24	13257BZ	Support