

Ref. No.	Part No.	Description
1	21447041	Screw
2	37195063	Motor Cover - MR - S3299, S3299-031
	37195073	Motor Cover - AAU - S3481
3	34163003	Diffuser
4	21366004	Speed Nut
5	34133007	Seal
6	34132015	Pad
7	34143003	Seal
8	43578051	Motor - 3.1 - (P-1 56)
9	12227	Insulated Terminal (2 wire)
	48969	Wire Nut (2 wire)
10	46363039	Attach. Cord - AAP - 16 Ft.
11	27482301	Strain Relief
12	38511015	Wheel Bearing - AG
13	38522061	Wheel -AG - S3299, S3299-031
	38522058	Wheel - AAP - S3481
15	41432040	Wheel Carrier - AG

Ref. No.	Part No.	Description
16	160472	Insulating Pod
17	37231069	Main Body - AAP - S3299, S3299-031
18	36151015	Latch
19	31114010	Filter
20	36426014	Bulkhead
21	36321012	Motor Retainer
22	21447072	Screw
23	34287021	Muffler
24	28164276	Switch
25	37214052	Control Panel - AAP - S3481, S3299, S3299-031
29	38781010	Seal
30	42212049	Bag Housing Lid - MR - S3299
	42212047	Bag Housing Lid -JM, S3299-031
	42212091	Bag Housing Lid & Rack - AAU - S3481
32	4010028K	Paper Bag - 3 Pk.
34	47534018	Thermal Protector
36	36433053	Tool Rack - MX - S3299-031
	36433066	Tool Rack - AAU - S3481
37	21447003	Screw
	56513220	Owner Manual - S3299, S3299-031
	56513271	Owner Manual - S3481
	58173374	Carton - S3299
	58173375	Carton - S3299-031, S3481
	58351015	Mid Pad
	58353007	Bottom Support
	58364015	Front Support
	58461023	Top Support
	58173272	Carton


CLEANING TOOLS - S3299, S3299-031 - (P-93)

38614024	Furniture Nozzle - AG
38617017	Crevice Tool - AG
43414064	Dusting Brush - AG
43414073	Floor Brush - AG
43434233	Hose - ABX/AG - 6 Ft.
3863801P	Extension Tube - Poly - AG
43414101	Rug & Floor Nozzle - AAP (P-94/188)

CLEANING TOOLS - S3481 - (P-93)

38614024	Furniture Nozzle - AG
38617017	Crevice Tool - AG
43414064	Dusting Brush - AG
43434233	Hose - AAV - 6 - Molded - Spirit
3863801P	Extension Tube - Poly - AG
43414101	Dlx. Rug & Floor Nozzle - AAP P-94/188


**Motor 43578051 (3.1)
43578069 (4.0)**



Ref. No.	Part No.	Description
1	21429406	Screw
2	168038AG	Brush Carrier
3	168506--	Brush Holder
4	38353004	Spring
5	167679	Carbon Brush
6	169702BZ	Bushing
7	36112003	Bolt 3.1
	21563061	Bolt 4.0
8	42192016	Motor Housing
9	21345116	Spring Washer
10	21312778	Thrust Washer
11	24198002	Star Ring
12	45311048	Field Coil 3.1
	45311022	Field Coil 4.0
13	44765185	Armature 3.1
	44765225	Armature 4.0
14	31195003	Motor Mount Insulator 3.1
	31195004	Motor Mount Insulator 4.0
15	43551013	Diffuser
16	31148009	Spacer
17	21312701	Washer
18	43566017	Fan
19	42192033	Interstage
20	31743003	Spacer
21	33426001	Nut
22	37196087	Fan Cover

Motor:





	43578051	43578069
	S3259	S3269-036
	S3269	S3269-070
	S3269-060	S3271-036
	S3271	S3271-070
	S3271-060	S3483
	S3295-031	S3485
	S3299-031	S3485-070
	S3405	S3487
	S3419	S3499
	S3423	S3501
	S3441-031	S3503
	S3441-070	S3505
	S3473	S3621
	S3475	S3629
	S3481	S3631
	S3627	



Ref. No.	Part No.	Description
1	43434191	Hose - JM - S/C - 6"Wire - Celebrity
	43434155	Hose - JM - S/C - 6"Wire - Spirit
	43434013	Hose Assem. - Stretch (not pictured)
	43434065	Hose - JM - 6"Wire - Spirit
	43434130	Hose - JM - 7.5" Molded - Spirit
	43434131	Hose - AAP - 7.5' - Molded - Spirit
	43434125	Hose - AAP - S/C - 7' - Molded - Spirit
	43434126	Hose - AAV - S/C - 6' - Molded - Spirit
	43434231	Hose - AAP - 6' - Molded - Spirit
	43434233	Hose - AG/ABX 6" Molded - Sprint
2	43414072	Floor Brush - JM
	43414073	Floor Brush - AG
3	43414064	Dusting Brush - AG
4	43414057	Furniture Nozzle - AAP
	38614020	Furniture Nozzle - JM - 1 Pc.
	38614024	Furniture Nozzle - AG - 1 Pc.
5	43453037	Extension Tube - Poly - 20 - JM
	3863801P	Extension Tube - Poly - AG
6	43453052	Extension Tube - 20 - AX
7	38617017	Crevice Tool - AG
8	12845JM	Gasket
9	48447001	Brush Back
10	43414015	Furniture Brush - JM
	43414016	Furniture Brush - AG
11	33712007	Split Ring
12	38644020	Swivel Connector - AG
	38644040	Swivel Connector - AAP
13	32855003	Hose Connector - Celeb.
	38638017	Hose Connector - AAP - Molded Hose
	38638019	Hose Connection - AAP
	38638039	Hose Connector - AG - Molded Hose
14	12615BZ	Collar (All Wire Hoses)
	38671011	Collar (Molded Hoses)
15	32156010	Sleeve (All Hoses)
16	38671029	Hose - 6' - AAV - Molded
	38671033	Hose - 6' - ABX - Molded
17	36116006	Collar (All Wire Hoses)
	36171025	Collar (Molded Hose)
18	43466044	Hose Grip - AAP - S/C
	43466066	Hose Grip - AG
19	38711006	Suction Control Ring - JM
	38711007	Suction Control Ring - MV
20	36153009	Latch Ring - AG
21	43414139	Rug & Floor Nozzle - AAP - (P - 188)
	0M114169	Rug & Floor Nozzle - ABE - (P - 188)
22	43414101	Rug & Floor Nozzle - DLX - (P - 188)



Rug & Floor Nozzle

Models S3183, S3187, S3187-030, S3203, S3205, S3207, S3215, S3241, S3247, S3257, S3259, S3289, S3291, S3299, S3299-031, S3401



A	48476026	Rug & Floor Nozzle - AAP - S3205, S3299, S3299-031 (Replaced by 43414101 +)
1	43463012	Connector Tube
2	13267	Felt Gasket
3	38615156	Nozzle Body - JM - S3299
4	13259PH	Litter Picker
5	15963FW	Spring
6	13261AY	Rib Shoe
7	16184	Brush Back
8	161413	Tube Retainer
9	31524005	Roller Shaft
10	42246002	Bottom Plate
11	12955	Screw
12	13157AG	Roller
B	43414105	Rug & Floor Nozzle - AAP - S3183, S3203, S3215, S3241, S3247, S3289, S3291, S3401 (Replaced by 43414121)
1	166652JM	Nozzle Tube (See Note)
2	166651	Gasket
3	43414089	Nozzle Body - JM
4	166646	Brush Retainer
5	166650AY	Tube Clamp
6	166648AW	Screw
7	166649FW	Spring
8	166656	Brush Back
C	48476064	Rug & Floor Nozzle - AAP - S3187, S3187-030 (Replaced by 43414101)
	48476066	Rug & Floor Nozzle - JM - S3207, S3257 (Replaced by 43414101)
	43414101	Rug & Floor Nozzle - MX - S3259
1	34113001	Foam Seal
2	169241AW	Washer
3	169239JR	Wheel
	169239AG	Wheel - S3207
4	13730	Lock Ring
5	169242	Wheel Cover
6	38615161	Nozzle Body - JM
7	34112001	Foam Seal
8	34223002	Felt Seal
9	169250AG	Brush Housing
10	169253AY	Rib Shoe
11	169256	Brush Back
12	169247JR	Furniture Guard
	169247JM	Furniture Guard - S3207, S3257
13	169251	Gasket
14	169538	Bottom Plate
15	21481464	Screw
16	21481465	Screw
17	169243AG	Roller
18	21312758	Washer
19	169244AW	Roller Shaft
20	24735081	Lock Ring
21	166649FW	Spring
22	34513001	Foam Seal - L.H.
23	34513002	Foam Seal - R.H.
24	169240AY	Wheel Shaft
25	169249JM	Connector Tube
26	34122006	Seal
27	169254JM	Control Knob

Rug & Floor Nozzle



Ref. No.	Part No.	Description
1	43414121	Standard Rug & Floor Nozzle Assem. - AAP
	43414139	Standard Rug & Floor Nozzle Assem. - AAP
	43414140	Standard Rug & Floor Nozzle Assem. - ABE (S3393-020, S3521)
	0M114169	Standard Rug & Floor Nozzle - ABX - S1221, S1315, S1337, S3393-040
	43414170	Standard Rug & Floor Nozzle AG - S1339, S3547
2	43414172	Standard Rug & Floor Nozzle - AG
3	38646039	Nozzle Tube - AG
	38615153	Rug & Floor Nozzle - AAP
	38615182	Rug & Floor Nozzle - ABE S3393-020, S3521, S1339, S3547, S1221, S1315, S1337
4	38521018	Roller (2) (Nozzle 43414172 req's 4)
5	31511004	Roller Axle - AY (2) (Nozzle 43414172 req's 4)
6	36414018	Brush Housing S1221, S1315, S1337
7	166649FW	Spring (2)
8	48443003	Brush Back Assem. - AG
9	21447203	Screw - Self Tapping (2)
10	38454004	Brush Back Lever - MV
	38454006	Brush Back Lever - ABN S3393-020, S3521, S1221 S1339, S3547
11	21329105	Felt Washer

Ref. No.	Part No.	Description
1	43414101	Deluxe Rug & Floor Nozzle Assem. - AAP
2	38646045	Nozzle Connector - AAP
3	43244043	Wheel & Bearing Assem. (2)
4	38511016	Wheel Bearing - AAT (2)
5	38615180	Rug & Floor Nozzle - AAP
6	38521018	Roller (2)
7	31511004	Roller Axle - AY (2)
8	38451008	Slider - AG
9	36414013	Brush Housing - MV
10	166649FW	Spring (2)
11	48443004	Brush Back Assem. - AG
12	21447203	Screw - Self Tapping (3)
13	34122013	Seal (2)
14	38434015	Pedal - MV