


This Owner's Manual is provided and hosted by [Appliance Factory Parts](#).



HOOVER S3441-070 Owner's Manual

[Shop genuine replacement parts for HOOVER
S3441-070](#)



[Find Your HOOVER Vacuum Cleaner Parts - Select From 1456 Models](#)


----- Manual continues below part list -----

Available Replacement Parts for HOOVER S3441-070

H-4010028K	BAG OEM HOOVER (3 PACK) K
H-43414073	Floor brush.
H-43414064	DUSTING BRUSH (ONE PEICE)
HR-5000	EXTENSION TUBE

Spirit

S3441-031 External Tool Rack
S3441-070 Internal Tool Storage



CLEANING TOOLS - (P-92)


38617017	Crevice Tool - AG
43414057	Furniture Nozzle - AG
43414064	Dusting Brush - AG
43414073	Floor Brush - AG
43433111	Hose - 2W - AG
43453052	Extension Tube - 20 - AX
48438224	Power Nozzle - MT - S3423 - (P-147)
48438024	Power Nozzle - MX - S3475 - (P-155)
48438190	Power Nozzle - LZ - S3441-031, S3441-070 (P-173)

Ref. No.	Part No.	Description
1	21447041	Screw
2	37195074	Motor Cover - AG - S3423, S3475
	37195068	Motor Cover - AAR - S3441-031, S3441-070
3	34163003	Diffuser
4	21366004	Speed Nut
5	38422073	Switch Pedal - Push Switch - AG - S3423, S3441-031, S3475
	38422149	Switch Pedal - Slide Switch - WW - S3441-031, S3441-070
6	38314002	Spring - Push Switch - S3423, S3441-031, S3475
	38319002	Spring - Slide Switch - S3441-031, S3441-070

Models S3423, S3441-031, S3441-070, S3475

Ref. No.	Part No.	Description
7	37214130	Control Panel - Push Switch - WW - S3423, S3441-031, S3475
	37214142	Control Panel - Slide Switch - WW - S3441-031, S3441-070
8	28212026	Switch - Push
	28177019	Switch - Slide - S3441-031, S3441-070
9	38422104	Cord Reel Pedal - Push Switch - WW - S3423, S3441-031, S3475
	38422117	Cord Reel Pedal - Slide Switch - WW - S3441-031, S3441-070
10	34287021	Exhaust Muffler
11	18972	Insulated Terminal (3 Wire)
12	21447072	Screw
13	36321012	Motor Retainer
14	34143003	Seal
15	43578051	Motor - 3.1 - (P- 1 56)
16	47534018	Thermal Protector
17	34132015	Pad
18	36222008	Brake Pad
19	38458008	Brake Arm
20	38353009	Spring
21	37215170	Cord Reel Support - AG
22	46383311	Cord - AG - 20
23	46831106	Cord Reel - AAP
24	47348076	Brush Block
25	34165004	Insulator
26	21447003	Screw - 5/8
	21447072	Screw - 7/8
27	38511015	Wheel Bearing
28	38522061	Wheel - AG
	38522058	Wheel - AAP - S3441-031, S3441-070
29	37223193	Main Body - MU - S3423
	37223198	Main Body - AAK - S3475
	37231072	Main Body - AAP - S3441-031, S3441-070
30	41432040	Wheel Carrier
31	46326079	Receptacle Assem. - AG
32	36151015	Latch
33	4010028K	Paper Bag - 3 Pk.
34	31114010	Filter
35	36426014	Bulkhead
36	34133007	Seal
37	51861017	Nameplate
38	21447027	Screw
39	36172046	Spring Clip
40	51151010	Bag Indicator
41	38781010	Seal
42	42212034	Bag Housing Lid - LZ - S3475, S3423
	42212072	Bag Housing Lid - AAR - S3441-031
	42212105	Bag Housing Lid - AAR - S3441-070
43	21447003	Screw
44	36433049	Tool Rack - MT - S3423
	36433046	Tool Rack - KR - S3475
	36433062	Tool Rack - AAR - S3441-031
45	51375110	Nameplate
46	46831076	Commutator Block
47	38561003	Axle - S3441-031, S3441-070
48	37258082	Terminal Shield S3441-031, S3441-070
49	34361001	Switch Actuator - S3441-031, S3441-070
50	42262075	Actuator Housing - S3441-031, S3441-070
51	38458002	Depressor - S3441-031, S3441-070
52	36433071	Tool Storage Tray - S3441-070
	56513242	Owner Manual
	56513249	Owner Manual - S3441-031
	56513282	Owner Manual - S3441-070
	58184016	Carton - S3423
	58184020	Carton - S3475
	58173377	Carton - S3441-031
	58173397	Carton - S3441-070
	58366069	Bottom Support
	58366061	Mid Pad
	58366069	Mid Pad - S3441-031, S3441-070
	58461023	Top Support

**Motor 43578051 (3.1)
43578069 (4.0)**



Ref. No.	Part No.	Description
1	21429406	Screw
2	168038AG	Brush Carrier
3	168506--	Brush Holder
4	38353004	Spring
5	167679	Carbon Brush
6	169702BZ	Bushing
7	36112003	Bolt 3.1
	21563061	Bolt 4.0
8	42192016	Motor Housing
9	21345116	Spring Washer
10	21312778	Thrust Washer
11	24198002	Star Ring
12	45311048	Field Coil 3.1
	45311022	Field Coil 4.0
13	44765185	Armature 3.1
	44765225	Armature 4.0
14	31195003	Motor Mount Insulator 3.1
	31195004	Motor Mount Insulator 4.0
15	43551013	Diffuser
16	31148009	Spacer
17	21312701	Washer
18	43566017	Fan
19	42192033	Interstage
20	31743003	Spacer
21	33426001	Nut
22	37196087	Fan Cover



Motor:

	43578051	43578069
	S3259	S3269-036
	S3269	S3269-070
	S3269-060	S3271-036
	S3271	S3271-070
	S3271-060	S3483
	S3295-031	S3485
	S3299-031	S3485-070
	S3405	S3487
	S3419	S3499
	S3423	S3501
	S3441-031	S3503
	S3441-070	S3505
	S3473	S3621
	S3475	S3629
	S3481	S3631
	S3627	

Power Nozzle

48438112 + (Use 48438044) - MN - S3281, S3283, S3283-040


48438224 - MT - S3405, S3423



Ref. No.	Part No.	Description
	48438056	Power Nozzle - MT - (Same as 48438224 except 4.5' Cord)
1	46321088	Cord - AG - Standard Plug
2	46321005	Attachment Cord
	36231104	Furniture Guard - MZ
	36231106	Furniture Guard - MW - S3483, S3283-040
3	48416030	Agitator - 4B
4	163768	Strain Relief
5	21447041	Screw
6	27479307	Wire Tie
7	36131024	Retainer Housing - MT
8	43461021	Nozzle Connector - AG
9	34112005	Seal
10	34337003	Seal
11	47171009	Lamp Socket
12	18972	Insulated Terminal (3 Wire)
13	45517	Wire Holder
14	42256098	Dust Cover
15	34123017	Seal
16	35276001	Detent Spring
17	32175025	Wheel - AG
18	31523005	Wheel Shaft
19	32761001	Wheel
20	31522004	Wheel Shaft
21	21447007	Screw
22	42246121	Base Plate Assm. (Incl. Items 17,18,19,20,23,24)
23	34337004	Lower Seal
	34378010	Upper Seal
24	13261AY	Rib Shoe
25	36218005	Grommet
26	27317307	Lamp - 15
27	43177073	Motor
28	51865003	Indicator Lens
	51865004	Indicator Lens - S3283-040
29	27666702	Terminal
30	37258082	Shield
31	281770KD	Switch
32	51151053	Indicator - PH
33	34361001	Switch Actuator
34	42262032	Housing
35	36131017	Retainer
36	38353007	Torsion Spring
37	31523006	Pivot Pin
38	38458002	Depressor
39	38433066	Switch Pedal - MZ
	38433067	Switch Pedal - MW - S3283, S3283-040, S3423
40	38528011	Belt
41	42252189	Nozzle Body - AG
42	52125092	Nameplate
	52125091	Nameplate - S3405, S3423
	52125114	Nameplate - S3283-040
43	39383060	Lens
44	43457037	Swivel Tube - AG

Agitator 48416030

1	48495AY	Thread Guard
2	43267002	Bearing
3	21347003	Washer
4	36422001	End
5	48445017	Agitator Brush
6	41435018	Thread Guard
7	38537008	End Pulley
8	48418001	Brush Ring
9	31722019	Spacer
10	32724005	Shaft



Ref. No.	Part No.	Description
1	43433085	Hose - AAP - Celebrity
2	43433032	Hose - JM - Spirit - 5-1/2'
3	43433067	Hose - AAP - Spirit - 5-1/2'
	43433081	Hose - MV -S/C- Spirit - 5-1/2'
	43433084	Hose - AAP - S/C - Spirit - 7'
	43433111	Hose - 2W - AG -S/C - Spirit
4	46321076	Cord Repair Kit
5	34777005	Suction Reg. Control - AG
	34777007	Suction Reg. Control - MV
6	36153009	Latch Ring - AG
7	43468055	Hose Tube - BL - 14
8	43453086	Extension Tube - BL - 22
	43453035	Extension Tube - AX - 22
	43453052	Extension Tube - 20 - AX (Gray Clip)
	43453058	Extension Tube - BL - 20 (Gray Clip)
9	3863801P	Extension Tube -Poly - AG
10	43453027	Extension Tube
11	43414073	Floor Brush - AG
12	38614023	Furniture Nozzle - 1 Pc. - 17
	43414057	Furniture Nozzle - AG
	38614024	Furniture Nozzle - AG
13	43414064	Dusting Brush - AG
14	38617017	Crevice Tool - AG
15	43414015	Furniture Brush - JM
	43414016	Furniture Brush - AG
16	38644040	Swivel Connector - JM
	38644020	Swivel Connector - AG
17	33712007	Split Ring
18	48447001	Brush Back
19	12845JM	Gasket
20	12783	Rivet
21	36171008	Cord Clip - MV
	36171005	Cord Clip - AG
22	13275	Screw
23	13142AG	Suction Control
24	13257BZ	Support