


This Owner's Manual is provided and hosted by [Appliance Factory Parts](#).



HOOVER S3485-070 Owner's Manual

[Shop genuine replacement parts for HOOVER
S3485-070](#)



[Find Your HOOVER Vacuum Cleaner Parts - Select From 1456 Models](#)


----- Manual continues below part list -----

Available Replacement Parts for HOOVER S3485-070

H-4010028K	BAG OEM HOOVER (3 PACK) K
H-43414073	Floor brush.
H-43414064	DUSTING BRUSH (ONE PEICE)
HR-5000	EXTENSION TUBE

Spirit

S3431, S3485, S3627 External Tool Rack
S3485-070 Internal Tool Storage




Ref. No.	Part No.	Description
1	21447041	Screw
	37195084	Motor Cover - AAM - S3431
	37195075	Motor Cover - AG - S3485, S3485-070
	37195089	Motor Cover - WW - S3627
3	34163003	Diffuser
4	21366004	Speed Nut
5	34133007	Seal
6	34132015	Pad
7	34143002	Seal
	43578051	Motor - 3.1 - S3431, S3627 - (P-156)
	43578069	Motor - 4.0 - S3485, S3485-070 (P-156)
9	12227	Insulated Terminal (2W)
	48969	Wire Nut (2W)

Ref. No.	Part No.	Description
10	46363039	Attach Cord - AAP - 16 - S3431, S3485
	46363305	Attach Cord - AG - 20 - S3485-070, S3627
11	27482301	Strain Relief
12	38511015	Wheel Bearing - AG
13	38522058	Wheel - AAP - S3431
	38522061	Wheel - AG S3485, S3485-070, S3627
15	41432040	Wheel Carrier
16	47534018	Thermal Protector
17	37231069	Main Body - AAP - S3431, S3627
	37223213	(Incl. Item 16) Main Body - AG - S3485, S3485-070
		(Incl. Item 16)
18	36151015	Latch
19	31114010	Filter
20	36426014	Bulkhead
21	36321012	Motor Retainer
22	21447072	Screw
23	34287021	Foam Muffler
24	28164276	Switch
25	37214052	Control Panel
	37214167	Control Panel - AG - S3627
26	21447027	Screw - S3485, S3485-070
27	36172046	Spring Clip - S3485, S3485-070
28	51151010	Bag Indicator - S3485, S3485-070
29	38781010	Lid Seal
30	42212075	Bag Housing Lid - AAM - S3431
	42212096	Bag Housing Lid - AG - S3485
	42212102	Bag Housing Lid - AG - S3485-070
	42212118	Bag Housing Lid - WW - S3627
31	52125112	Nameplate
	51375064	Nameplate - S3485, S3485-070
	52125123	Nameplate - S3431, S3627
32	4010028 K	Paper Bag - 3 Pk.
33	36433059	Tool Rack - AAM - S3431
	36433060	Tool Rack - AG - S3485
34	21447003	Screw - S3431, S3485
35	160472	Switch Insulating Pod
36	36433071	Tool Storage Tray - S3485-070, S3627
	56513252	Owner Manual - S3431, S3485
	56513281	Owner Manual - S3485-070
	56513310	Owner Manual - S3627
	58173375	Carton - S3431, S3485
	58173374	Carton - S3485-070
	59814027	Carton - S3627
	58351015	Mid Pad
	58353007	Bottom Support
	58364015	Front Support - S3431, S3485
	58364013	Front Support - S3485-070, S3627
	58461023	Top Support - S3431, S3485
	58461021	Top Support - S3485-070, S3627

CLEANING TOOLS - (P-93)

38614024	Furniture Nozzle - AG
38617017	Crevice Tool - AG
43414064	Dusting Brush - AG
43414073	Floor Brush - AG
43414101	Rug & Floor Nozzle - AAP
0M114169	Rug & Floor Nozzle - S3627
43434233	Hose - AG/ABX - 6 - Molded - S/C - Spirit
43434013	Hose - S3431
3863801P	Ext. Tube - Poly - AG
43453027	Extension Tube

**Motor 43578051 (3.1)
43578069 (4.0)**





Ref. No.	Part No.	Description
1	21429406	Screw
2	168038AG	Brush Carrier
3	168506--	Brush Holder
4	38353004	Spring
5	167679	Carbon Brush
6	169702BZ	Bushing
7	36112003	Bolt 3.1
	21563061	Bolt 4.0
8	42192016	Motor Housing
9	21345116	Spring Washer
10	21312778	Thrust Washer
11	24198002	Star Ring
12	45311048	Field Coil 3.1
	45311022	Field Coil 4.0
13	44765185	Armature 3.1
	44765225	Armature 4.0
14	31195003	Motor Mount Insulator 3.1
	31195004	Motor Mount Insulator 4.0
15	43551013	Diffuser
16	31148009	Spacer
17	21312701	Washer
18	43566017	Fan
19	42192033	Interstage
20	31743003	Spacer
21	33426001	Nut
22	37196087	Fan Cover

Motor:

	43578051	43578069
	S3259	S3269-036
	S3269	S3269-070
	S3269-060	S3271-036
	S3271	S3271-070
	S3271-060	S3483
	S3295-031	S3485
	S3299-031	S3485-070
	S3405	S3487
	S3419	S3499
	S3423	S3501
	S3441-031	S3503
	S3441-070	S3505
	S3473	S3621
	S3475	S3629
	S3481	S3631
	S3627	

Rug & Floor Nozzle



Ref. No.	Part No.	Description
1	43414121	Standard Rug & Floor Nozzle Assem. - AAP
	43414139	Standard Rug & Floor Nozzle Assem. - AAP
	43414140	Standard Rug & Floor Nozzle Assem. - ABE (S3393-020, S3521)
	0M114169	Standard Rug & Floor Nozzle - ABX - S1221, S1315, S1337, S3393-040
	43414170	Standard Rug & Floor Nozzle AG - S1339, S3547
2	43414172	Standard Rug & Floor Nozzle - AG
3	38646039	Nozzle Tube - AG
	38615153	Rug & Floor Nozzle - AAP
	38615182	Rug & Floor Nozzle - ABE S3393-020, S3521, S1339, S3547, S1221, S1315, S1337
4	38521018	Roller (2) (Nozzle 43414172 req's 4)
5	31511004	Roller Axle - AY (2) (Nozzle 43414172 req's 4)
6	36414018	Brush Housing S1221, S1315, S1337
7	166649FW	Spring (2)
8	48443003	Brush Back Assem. - AG
9	21447203	Screw - Self Tapping (2)
10	38454004	Brush Back Lever - MV
	38454006	Brush Back Lever - ABN S3393-020, S3521, S1221 S1339, S3547
11	21329105	Felt Washer

Ref. No.	Part No.	Description
1	43414101	Deluxe Rug & Floor Nozzle Assem. - AAP
2	38646045	Nozzle Connector - AAP
3	43244043	Wheel & Bearing Assem. (2)
4	38511016	Wheel Bearing - AAT (2)
5	38615180	Rug & Floor Nozzle - AAP
6	38521018	Roller (2)
7	31511004	Roller Axle - AY (2)
8	38451008	Slider - AG
9	36414013	Brush Housing - MV
10	166649FW	Spring (2)
11	48443004	Brush Back Assem. - AG
12	21447203	Screw - Self Tapping (3)
13	34122013	Seal (2)
14	38434015	Pedal - MV