

This Owner's Manual is provided and hosted by [Appliance Factory Parts](#).



Electrolux EL6985A Owner's Manual


[Shop genuine replacement parts for Electrolux
EL6985A](#)



[Find Your Electrolux Vacuum Cleaner Parts - Select From 68 Models](#)


----- Manual continues below -----

PARTS - EL6985A



Ref #	Part	Description	Comments
1	1130550-01	HANDLE CPL.	
2	1130511-02	PIN - HANDLE	
3	1130509-00	LID - FILTER	
4	1130529-01	ABSORBENT - FILTER LID	
5	EL012	HEPA FILTERS	
6	1130289-01	SEAL	
7	1130512-01	SLIDER	
8	1130515-15	DISPLAY	
9	1131175-01	PCB	
10	1130514-12	PEDAL - ON/OFF	
11	1130513-05	PEDAL - CORD WINDER	
12	1050326-02	SWITCH - POWER	
13	61403-1	SPRING - PKGD	Pkg of 5
14	1130502-02	HOUSING - MOTOR	
15	1130521-01	ABSORBENT	
16	1050808-01	SUPPORT - MOTOR	
17	1130517-02	HOOD - MOTOR	
18	1130516-01	SEAL - MOTOR	
19	1130527-12	LID - CATCH	
20	1130551-02	FRONT & REAR COVER CPL.	
21	61415-1	FLAP SPRING - PKGD	Pkg of 5
22	1130523-01	DEVICE - SAFETY	
23	117966-02	INDICATOR CPL.	
24	1130522-01	HOLDER - DUST BAG	
25	1130535-01	FILTER - MOTOR	
26	1130538-01	HOLDER - MOTOR FILTER	
27	115857-04	SEAL	
28	1130500-02	MODULE - DUST BAG	
29	1130506-01	WHEEL - REAR	
30	1130548-12	BOTTOM PART CPL.	
31	1096042-03	HOLDER - WHEEL	
32	1129038-01	FRONT WHEEL CPL.	
33	1128341-30	CORDWINDER CPL.	
34	1130526-06	AREA - CABLE RECESS	
35	62109-2	ELECTROLUX SCREW PACKAGE	
36	1129023-01	SUPPORT - MOTOR	
37	60650-3	MOTOR ASSEMBLY - CARTONED	

ACCESSORIES - EL6985A



Ref #	Part	Description	Comments
1	39843	TELESCOPIC CREVICE TOOL A	
3	39845	SIVO HIGH FLOOR TOOL ASSY	
4	39846	DUPRO TURBO BT NOZZLE ASS	
5	39844	TELESCOPIC WAND ASSY	
6	39840	HOSE ASSEMBLY	
8	EL200B	S BAG CLASSIC	
2	39842	TOOL COMBINATION	
	39841	CADDY - TOOL	Not illustrated.
7	73400		

E-2193423-01 Belt for Turbo Nozzle