


This Owner's Manual is provided and hosted by [Appliance Factory Parts](#).



HOOVER U6625-900 Owner's Manual

[Shop genuine replacement parts for HOOVER
U6625-900](#)



[Find Your HOOVER Vacuum Cleaner Parts - Select From 1456 Models](#)

----- Manual continues below part list -----


Available Replacement Parts for HOOVER U6625-900

HR-1028	BELT, FLAT, UPRIGHTS, 1PK
HR-1805	FITLER HOOVER 2 PACK AFTERMARKET
H-40140201	Filter for Hepa Bagless
K-109289	BULB
FA-3035	ATTACHMENT CORD ASSY
H-43244005	Rear wheel
HR-2003	AGITATOR ASSY, COMPLETE

Original **HOOVER**

SELF PROPELLED - BAGLESS

Models U6625-900, U6630-900, U6655-900, U6660-900



KEY	PART NO	DESCRIPTION	KEY	PART NO	DESCRIPTION
1	H-37253365	Hood Assembly - AEX - U6625-900, U6630-900 (Inc. Items 2, 3, 4)	18	H-37243034	Agitator Housing - U6625-900, U6630-900, U6660-900 (Inc. Item 31)
1	H-37253367	Hood Assembly - AEM - U6655-900 (Inc. Items 2, 3, 4)	18	H-37243035	Agitator Housing - U6655-900 (Inc. item 31)
1	H-37253368	Hood Assembly - AG - U6660-900 (Inc. Items 2, 3, 4)	19	H-38718013	Valve Door
2	H-38421099	Adjustment Knob	20	H-38715017	Valve Cover
3	H-38563026	Nozzle Adjustment Cam	21	H-39511004	Litter Picker
4	H-36143004	Idler Arm Lock	22	H-42245030	Bottom plate (Includes Item 31)
5	H-38671022	Lower Hose	23	H-48414069	Agitator Assembly Complete
6	H-38434023	Handle Release Lever	24	H-21479446	Screw
7	H-32434008	Rear Axle	25	H-37243013	Duct Cover Nozzle
8	H-38522077	Rear Wheel - U6625-900, U6630-900, U6660-900	26	H-21447242	Screw
8	H-43244005	Rear Wheel - U6655-900	27	H-21447228	Screw
9	H-160017	Retaining Ring	28	H-21447121	Screw- Bottom Plate
10	H-36131096	Trunnion Cover	29	H-21751010	Screw - Special
11	H-37241164	Main Body- ABE	30	H-36128002	Washer
12	H-38528035	Flat Belt	31	H-38781053	Agitator Pulley Seal
13	H-43241004	Idler Arm Assembly	32	H-51438015	Hood Nameplate
	H-43241006	Idler Arm Pulley (Only)	33	H-38537013	Drive Pulley
14	H-38356014	H-Torsion Spring	34	H-36131101	Control Cable Support
15	H-34125004	Retainer - Control Cable	35	H-21447263	Screw
16	H-43124016	Power Drive Assembly	36	H-160031	Nut
17	H-38528034	V Belt - Agitator	37	H-38313037	Spring
			38	H-21479345	Screw
			39	H-38719049	Valve Arm - Front
			40	H-38358001	Spring
			41	H-38719048	Valve Arm - Rear
			42	H-43143046	Actuator Arm
			43	H-163340	Power Drive Wheel

