

This Owner's Manual is provided and hosted by [Appliance Factory Parts](#).



HOOVER U6632-900 Owner's Manual

[Shop genuine replacement parts for HOOVER
U6632-900](#)





[Find Your HOOVER Vacuum Cleaner Parts - Select From 1456 Models](#)

----- Manual continues below part list -----

Available Replacement Parts for HOOVER U6632-900


HR-1028	BELT, FLAT, UPRIGHTS, 1PK
E-39483	EXHAUST FILTER
H-40201200	V BELT, W/POWER DRIVE, 1PK
H-40140201	Filter for Hepa Bagless
K-109289	BULB
HR-2003	AGITATOR ASSY, COMPLETE
HR-5310	UPRIGHT DUST BRUSH AFTERMARKET





Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
1		Note: Hood Assembly includes Items 2,3 and 4.	23.	48414069	Agitator Assembly Complete
	37253365	Hood Assembly - AEX - U6625-900, U6626-900, U6630-900, U6630-960	24.	21479446	Screw
	37253A19	Hood Assembly - AEF - U6632-900	25.	37243013	Duct Cover Nozzle
	37253367	Hood Assembly - AEM - U6655-900	26.	21447242	Screw
	37253368	Hood Assembly - AG - U6660-900	27.	21447228	Screw
	37253A08	Hood Assembly - ADJ - U6616-900	28.	21447121	Screw - Bottom plate
	37253A15	Hood Assembly - ADR - U6617-900	29.	21751010	Screw - Special
	37253400	Hood Assembly - ADM - U6607-900	30.	36128002	Washer
2.	38421099	Adjustment Knob (2)	31.	38781053	Agitator Pulley Seal
3.	38563026	Nozzle Adjustment Cam	32.	51438015	Hood Nameplate
4.	36143004	Idler Arm Lock	33.	38537013	Drive Pulley
5.	38671022	Lower Hose	34.	36131101	Control Cable Support
6.	38434023	Handle Release Lever	35.	21447263	Screw
7.	32434008	Rear Axle (2)	36.	160031-	Nut
8.	38522077	Rear Wheel (2) - U6625-900, U6630-900, U6660-900	37.	38313037	Spring
	43244005	Rear Wheel (2) - U6626-900, U6630-960, U6632-900, U6655-900	38.	21447229	Screw
9.	160017	Retaining Ring	39.	38719049	Valve Arm - Front
10.	36131096	Trunnion Cover (2)	40.	38358001	Spring
11.	37241164	Main Body - ABE	41.	38719048	Valve Arm - Rear
12.	38528035	Flat Belt	42.	43143046	Actuator Arm
13.	43241004	Idler Arm Assembly			
	43241006	Idler Arm Pulley (Only)			
14.	38356014	Torsion Spring			
15.	34125004	Retainer - Control Cable			
16.	43124016	Power Drive Assembly			
17.	38528034	V Belt - Agitator			
18.		Note: Agitator Housings include item 31			
	37243034	Agitator Housing - U6625-900, U6626-900, U6630-900, U6630-960, U6660-900			
	37243035	Agitator Housing - U6632-900, U6655-900			
19.	38718013	Valve Door			
20.	38715017	Valve Cover			
21.	39511004	Litter Picker			
22.	42245030	Bottom plate (Includes Item 31)			

Turbine Driven Hand Tool Model U5456-900,U5460-900,U5458-900,U5462-900,U5750-900,U5757-900,U5755-900, U5761-900,U6425-920,U6431-900,U6445-920,U6446-900,U6455-960, U6458-900, U6470-900, U6470-910, U6616-900, U6617-900, U6625-900, U6630-900, U6632-900, U6655-900, U6660-900



Ref: No.	Part No.	Description
	49129010	Hand Tool - Dark Spruce - U5460-900, U6425-920, U6445-920, U6458-900, U6655-900
	40200013	Hand Tool - Sapphire - U5456-900, U5458-900, U5462-900, U5750-900, U5755-900, U5757-900, U5761-900, U6446-900, U6455-960, U6470-900, U6470-910, U6616-900, U6625-900, U6630-900
	49129014	Hand Tool - Copper Translucent - U6431-900 after 6/01, U6660-900

Ref: No.	Part No.	Description
	49129018	Hand Tool - Ruby- U6617-900
	49129019	Hand Tool - Mist Gray Transparent U6632-900
1	38528037	Belt
2.	48414088	Agitator Assembly
3.	38632011	Connector - Friction Fit Style