

This Owner's Manual is provided and hosted by [Appliance Factory Parts](#).



Wolf D030UB-2 Owner's Manual

[Shop genuine replacement parts for Wolf D030UB-2](#)



[Find Your Wolf Electric Range Parts - Select From 82 Models](#)

----- Manual continues below -----

**30" Oven Control Panel Parts List
Single and Double Oven**

<u>Ref #</u>	<u>Part #</u>	<u>Description</u>
1	805081	Control Head, 30, Sngl, Sst
	805104	Control Head, 30, Dbl, Sst
	805106	Control Head, 30, Sngl, Plt
	805107	Control Head, 30, Dbl, Plt
	805109	Control Head, 30, Sngl, Blk
	805110	Control Head, 30, Dbl, Blk
2	805178	Wall Oven Display Pinion Rpl. Pkg.
3	809725	Motor, Drive Assy., Sst
	809727	Motor, Drive Assy., Plt
	809726	Motor, Drive Assy., Blk
4	801231	C-Channel Bottom, 30", Sst
	801738	C-Channel Bottom, 30", Plt
	801740	C-Channel Bottom, 30", Blk
5	801230	C-Channel Top, 30", Sst
	801737	C-Channel Top, 30", Plt
	801739	C-Channel Top, 30", Blk
6	802964	Pin, Stop, Control Panel
7	801538	Screw, 8-32x1/2"
8	802791	Mtg, Control Panel, Rt SS
	801555	Mtg, Control Panel, Rt Black
	801556	Mtg, Control Panel, Rt Plat.
9	803484	Bearing, Flange, Control Panel
10	801920	Bracket, Switch, Control Panel
11	801549	Screw, 8-18x1/2"
12	809116	Switch, Actuation, Control Panel
13	801677	Screw, 2-56x3/8"
14	800704	Plunger, Control Display

**36" Oven Control Panel Parts List
Single Oven**

<u>Ref #</u>	<u>Part #</u>	<u>Description</u>
1	805105	Control Head, 36, Sngl, Sst
	805108	Control Head, 36, Sngl, Plt
	805111	Control Head, 36, Sngl, Blk
2	805178	Wall Oven Display Pinion Rpl. Pkg.
3	809725	Motor, Drive Assy., Sst
	809727	Motor, Drive Assy., Plt
	808726	Motor, Drive Assy., Blk
4	801525	C-Channel Bottom, 36", Sst
	801742	C-Channel Bottom, 36", Plt
	801744	C-Channel Bottom, 36", Blk
5	801526	C-Channel Top, 36", Sst
	801741	C-Channel Top, 36", Plt
	801743	C-Channel Top, 36", Blk
6	802964	Pin, Stop, Control Panel
7	801538	Screw, 8-32x1/2"
8	802791	Mtg, Control Panel, Rt SS
	801555	Mtg, Control Panel, Rt Black
	801556	Mtg, Control Panel, Rt Plat.
9	803484	Bearing, Flange, Control Panel
10	801920	Bracket, Switch, Control Panel
11	801549	Screw, 8-18x1/2"
12	809116	Switch, Actuation, Control Panel
13	801677	Screw, 2-56x3/8"
14	800704	Plunger, Stainless Steel

Not Shown

- 803319 Spring, Ribbon Cable, Short
- 803357 Mount, Cable-Tie, Adhesive

**30" Oven Modules Parts List
Single and Double Oven**

<u>Ref #</u>	<u>Part #</u>	<u>Description</u>
1	801542	Screw, 8-18x3/8"
2	800381	Fan, Cooling, Upper
3	801224	Bracket, Air Diverter Top
4	801363	Control Board, Stepper Motor
5	800950	Transformer, Light
6	801912	Strain Relief, Plastic
7	800385	Cover, Latch
8	803356	Plate, Mounting Hardware
9	806822	Board, Relay, 30"/36"
10	806551	Controller, Oven, Single, 30"
	806552	Controller, Oven, Double, 30"
11	820130	Bracket-Z, Latch, Top Oven
12	800383	Bracket, Support, Top Module
13	800375	Bracket, Cord, Power
14	804537	Thermal Cut Out (Lower)
15	800263	Latch, Motorized
16	807542	Pan, Module, 30"
17	800386	Pan, Middle, DO
18	801212	Bracket, Air Diverter, DO
19	820129	Bracket-Z, Latch, Bottom Oven, DO

**36" Oven Modules Parts List
Single Oven**

<u>Ref #</u>	<u>Part #</u>	<u>Description</u>
1	801542	Screw, 8-18x3/8"
2	800381	Fan, Cooling, Upper
3	801224	Bracket, Air Diverter Top
4	801363	Control Board, Stepper Motor
5	800950	Transformer, Light
6	801912	Strain Relief, Plastic
7	800385	Cover, Latch
8	803356	Plate, Mounting Hardware
9	806822	Board, Relay, 30"/36"
10	806560	Oven controller, Single 36"
11	820130	Bracket-Z, Latch
12	800383	Bracket, Support, Top Module
13	800375	Bracket, Cord, Power
14	804537	Thermal Cut Out
15	800263	Latch, Motorized
16	807543	Pan, Module, 36"

Not Shown

800714	Cable, Relay to Controller, 28"
809450	Cable, Relay to Controller, 21"
801714	Power Cord Conduit, Single
812348	Power Cord Conduit, Double

**30" Oven Cavity Parts List
Single and Double Oven**

<u>Ref #</u>	<u>Part #</u>	<u>Description</u>
1	803140	Receptacle, Pizza Element
2	N/A	Cavity, Oven (Contact Factory)
3	800307	Light, Oven
4	800943	Cover, Probe Switch
5	800942	Switch, Probe
6	800304	Catalyst, Smoke
7	809982	Sensor, Temperature
8	800701	Fan, Convection Assy., Cw
9	801544	Screw, 8-32x1/2"
10	801122	Pan, Broil Element
11	808643	Element, Broil, 30"
12	800368	Guide, Rack, Right
13	802704	Screw, 8-32x1/2 Lo Profile
14	801141	Guide, Rack, Left
15	802898	Convection Baffle Assembly, 30"
16	801417	Plate, Retainer
17	803141	Receptacle, Plug, Ceramic
18	801049	Nut, 8-32 Keps
19	809818	Fan, Convection Assy., Ccw
20	808652	Probe, Temperature
21	802988	Rack, Oven 30"
22	803062	Rack, Oven Flat 30"
23	803859	Stone, Pizza
24	800735	Rack, Pizza Stone, 30"
25	800717	Element, Pizza 3500 Watt 230V
26	803373	Clip, Retainer Hinge
27	802929	Screw 6-20X5/8 PH TRS HD T-AB, Black
28	803323	Cover, Plate
29	804712	Accessory Pkg Broiler Pan Set


**36" Oven Cavity Parts List
Single Oven**

<u>Ref #</u>	<u>Part #</u>	<u>Description</u>
1	803140	Receptacle, Pizza Element
2	N/A	Cavity, Oven (Contact Factory)
3	800307	Light, Oven
4	800493	Cover, Probe Switch
5	800942	Switch, Probe
6	800304	Catalyst, Smoke
7	809982	Sensor, Temperature
8	800701	Fan, Convection Assy., Cw
9	801544	Screw, 8-32x1/2"
10	801616	Deflector, Pan Broil
11	801615	Element, Broil, 36"
12	800734	Guide, Rack, Right
13	802704	Screw, 8-32x1/2 Lo Profile
14	801142	Guide, Rack, Left
15	802900	Convection Baffle Assembly, 36"
16	801417	Plate, Retainer
17	803141	Receptacle, Plug, Ceramic
18	801049	Nut, 8-32 Keps
19	809818	Fan, Convection Assy., Ccw
20	808652	Probe, Temperature
21	802989	Rack, Oven 36"
22	803063	Rack, Oven Flat 36"
23	803859	Stone, Pizza
24	800736	Rack, Pizza Stone, 36"
25	800717	Element, Pizza 3500 Watt 230V
26	803373	Clip, Retainer Hinge
27	802929	Screw 6-20X5/8 PH TRS HD T-AB, Black
28	803323	Cover, Plate
29	804712	Accessory Pkg Broiler Pan Set

Not Shown

803816	Light Bulb
801949	Pizza Peel
801554	Hard Fiber Flat Washer

**Oven Cavity Exploded View
Single and Double Oven**




**30" Oven Door Parts List
Single and Double Oven**

<u>Ref #</u>	<u>Part #</u>	<u>Description</u>
1		*Special order, Call Factory Parts Department
2	800523	Left Door Rack Guide, 30", assy
3	803324	Gasket, Door, 30"
4	800522	Right Door Rack Guide, 30"
5	803379	Screw, 8-18x1/2"
6	811010	Weldment, Liner, Door 30"
7	801102	Striker Plate, Door Latch
8	801542	Screw, 8-18x3/8"
9	800318	Gasket, Rope, Glass Pack, 30"
10	809115	Hydraulic Oven Door Hinge
11	809553	Triple Pane Oven Glass Pack, 30"
12	806610	Insulation, Door, Inner Top
13	806595	Insulation, Door, Inner, Sides, 30"
14	800319	Shield, Heat, Inner, Door, 30"
15	810794	Insulation, Door, Center, Top, 30"
16	820116	Heat Deflector, Center, 30"
17	800315	Shield, Heat, Door, 30"
18	806596	Insulation, Door, Outer, 30"
19	801540	Screw, 10-24x1/2"
20	800314	Bracket, Door, Outer, Mounting
21	802940	Door Skin, Outer w/window, 30" F/S
	803227	Door Skin, Outer w/window, 30" U/S
	803232	Door Skin, Outer w/window, 30" F/S, No Logo
	803235	Door Skin, Outer w/window, 30" U/S, No Logo
	803230	Door Skin, Outer w/window, 30" U/B
	803236	Door Skin, Outer w/window, 30" U/B, No Logo
	803231	Door Skin, Outer w/window, 30" U/P
	803237	Door Skin, Outer w/window, 30" U/P, No Logo
22	801204	Handle, Oven Door, Assy., 30", Sst
	801599	Handle, Oven Door, Assy., 30", Plt
	801600	Handle, Oven Door, Assy., 30", Blk
23	806606	Insulation, Door, Center, Back, 30"
24	806605	Insulation, Door, Center, Side, 30"
25	806615	Insulation, Door, Inner Top
26	800418	Nut, 8-32 Hex Nut W/Lock Washer
27	800689	Hinge, Wall Oven, 30"

**36" Oven Door Parts List
Single Oven**

<u>Ref #</u>	<u>Part #</u>	<u>Description</u>
1		*Special order, Call Factory Parts Department
2	801816	Left Door Rack Guide, 36", assy
3	803325	Gasket, Door, 36"
4	801815	Right Door Rack Guide, 36"
5	803379	Screw, 8-18x1/2"
6	801444	Weldment, Liner, Door 36"
7	801102	Striker Plate, Door Latch
8	801542	Screw, 8-18x3/8"
9	801764	Gasket, Rope, Glass Pack, 36"
10	809115	Hydraulic Oven Door Hinge
11	801448	Triple Pane Oven Glass Pack, 36"
12	806610	Insulation, Door, Inner Top
13	806617	Insulation, Door, Inner, Sides, 36"
14	801765	Shield, Heat, Inner, Door, 36"
15	810794	Insulation, Door, Center, Top
16	801766	Heat Deflector, Center, 36"
17	803378	Shield, Heat, Door, 36"
18	801577	Insulation, Door, Outer, 36"
19	801540	Screw, 10-24x2-1/4"
20	800314	Bracket, Door, Outer, Mounting
21	803245	Door Skin, Otr w/window, 36" U/S
	803246	Door Skin, Otr w/window, 36" U/B
	803247	Door Skin, Otr w/window, 36" U/P
22	801206	Handle, Oven Door, Assy., 36", Sst
	801893	Handle, Oven Door, Assy., 36", Plt
	801892	Handle, Oven Door, Assy., 36", Blk
23	806606	Insulation, Door, Center, Back, 36"
24	806623	Insulation, Door, Center, Side, 36"
25	806615	Insulation, Door, Inner Btm
26	800418	Nut, 8-32 Hex Nut W/Lock Washer
27	803335	Hinge, Wall Oven, 36"

**Oven Door Exploded View
Single and Double Oven**



**30" Back View Parts List
Single and Double Oven**

<u>Ref #</u>	<u>Part #</u>	<u>Description</u>
1	800374	Face Plate, Venting, Upper
2	800382	Stiffener, Top Module
3	801542	Screw, 8-18x3/8"
4	800379	Panel, Upper, Front
5	820118	Cover, Rear, Top Module
6	801705	Cover, Small, Top Module
7	801700	Catalyst, Sub Assembly
8	805976	Insulation, Cavity, Top
	805977	Insulation, Cavity, Top Dbl
	805978	Insulation, Cavity, Back
9	801913	Strain Relief, Metal
10	802919	Panel, Back, Top Insulation
11	802918	Panel, Inner, Back
12	801290	Channel, Divider, Side Exhaust
13	803074	Channel, Divider, Air, Single
14	820117	Panel, Back, Single Oven
15	801702*	Bake, Pan Assembly
16	800360*	Element, Bake
17	800388	Panel, Back, Double Oven
18	801169	Channel, Divider Side, Exhaust, Lrg
19	801208	Cover, Back Panel, Small
20	801143	Fan, Cooling, Lower
21	801209	Cover, Fan, Cooling
22	801170	Channel, Divider Side Exhaust, Sml
23	801171	Channel, Divider, Cooling
24	800393	Channel, Divider, Cooling, DO
25	804537	Thermal Cut Out
26	804254	Switch, Thermostat, Upper

Not Shown


801241 Plate, Vent Middle

**36" Back View Parts List
Single Oven**

<u>Ref #</u>	<u>Part #</u>	<u>Description</u>
1	801536	Face Plate, Venting, Upper, 36"
2	801582	Stiffener, Top Module, 36"
3	801542	Screw, 8-18x3/8"
4	801478	Panel, Top Module, Front, 36"
5	801331	Cover, Large, 36"
6	801803	Cover, Small, Top Module, 36"
7	801700	Catalyst, Sub Assembly
8	805979	Insulation, Cavity, Top, 36"
	805980	Insulation, Cavity, Back, 36"
9	801913	Strain Relief, Metal, 36"
10	803329	Panel, Insulation, Back, 36"
11	802918	Panel, Inner, Back, 36"
12	803334	Channel, Exhaust, 36"
13	803327	Channel, Cooling, 36"
14	801506	Panel, Cover, Back, 36"
15	802700*	Bake, Pan Sub Assembly, 36"
16	800360*	Element, Bake, 36"

* See Bake Pan Assembly exploded view page 14.

**Oven Back Exploded View
Single and Double Oven**




**30" Side and Base View Parts List
Single and Double Oven**

<u>Ref #</u>	<u>Part #</u>	<u>Description</u>
1	820125	Channel, Upper Venting
2	800890	Cover, Temperature Probe
3	801721	Enclosure, Rt Side 30"
4	801475	Bracket, Hold Down
5	801530	Insulation, Light
6	800926	Hinge, Pocket
7	806612	Insulation, Cavity, Hinge
8	800364	Stiffener, U-Wrap
9	806608	Insulation, Cavity, Right Side
10	808422	Base, Assembly Single
	804541	Base, Assembly, Double
11	806609	Insulation, Cavity, Left Side
12	801720	Enclosure, Left Side, 30"


**36" Side and Base View Parts List
Single Oven**

<u>Ref #</u>	<u>Part #</u>	<u>Description</u>
1	801335	Channel, Upper Venting
2	800890	Cover, Temperature Probe
3	801724	Enclosure, Rt Side
4	801475	Bracket, Hold Down
5	801530	Insulation, Light
6	800926	Hinge, Pocket
7	806612	Insulation, Cavity, Hinge
8	800364	Stiffener, U-Wrap
9	806619	Insulation, Cavity, Right Side
10	804553	Base, Assembly, 36"
11	806618	Insulation, Cavity, Left Side
12	801723	Enclosure, Left Side,

**Oven Side and Base Exploded View
Single and Double Oven**



**Bake Pan Assembly Exploded View
Single and Double Oven**





**30" Bake Pan Parts List
Single and Double Oven**

<u>Ref #</u>	<u>Part #</u>	<u>Description</u>
1	806598	Insulation, Bake Element , Behind
2	800360	Element, Bake
3	801159	Insulation, Bake Element, Under
4	800359	Pan, Bake Element
5	800358	Bracket, Bake Element
6	801542	Screw, 8-18x3/8"
7	806604	Insulation, Base, U-Wrap Sides
8	806634	Insulation, Base, U-Wrap Front
9	801722	Enclosure, Bottom, 30"
10	801553	Screw, 6-20x3/8"
11	806032	Support, Cavity Sump

**36" Bake Pan Parts List
Single Oven**

<u>Ref #</u>	<u>Part #</u>	<u>Description</u>
1	806598	Insulation, Bake Element , Behind
2	800360	Element, Bake
3	801159	Insulation, Bake Element, Under
4	800359	Pan, Bake Element
5	800358	Bracket, Bake Element
6	801542	Screw, 8-18x3/8"
7	806620	Insulation, Base, U-Wrap Sides
8	806621	Insulation, Base, U-Wrap Front
9	801725	Enclosure, Bottom, 36"
10	801553	Screw, 6-20x3/8"
11	806032	Support, Cavity Sump

Trim Exploded View



<u>Model #</u>	<u>Ref#</u>	<u>Part #</u>	<u>Description</u>
SO30F/S	1	800706	Extrusion, Side, Right
	2	800707	Extrusion, Side, Left
	3	805115	Extrusion, Bottom
SO36U/S	1	800939	Extrusion, Side, Right
	2	800938	Extrusion, Side, Left
	3	802731	Extrusion, Bottom
SO30U/B	1	800525	Extrusion, Side, Right
	2	800524	Extrusion, Side, Left
	3	805175	Extrusion, Bottom
SO36U/B	1	802740	Extrusion, Side, Right
	2	802739	Extrusion, Side, Left
	3	802743	Extrusion, Bottom

<u>Model #</u>	<u>Ref#</u>	<u>Part #</u>	<u>Description</u>
DO30F/S	1	800389	Extrusion, Side, Right
	2	800390	Extrusion, Side, Left
	3	802719	Extrusion, Middle,
	4	805115	Extrusion, Bottom
DO30U/S	1	800389	Extrusion, Side, Right
	2	800390	Extrusion, Side, Left
	2	803966	Extrusion, Side, Left
	4	805115	Extrusion, Bottom
SO30U/P	1	800518	Extrusion, Side, Right
	2	800519	Extrusion, Side, Left
	4	805174	Extrusion, Bottom
SO36U/P	1	802742	Extrusion, Side, Right
	2	802741	Extrusion, Side, Left
	4	802744	Extrusion, Bottom
DO30U/P	1	805186	Extrusion, Side, Right
	2	805185	Extrusion, Side, Left
	3	805184	Extrusion, Middle
	4	805174	Extrusion, Bottom
DO30U/B	1	805183	Extrusion, Side, Right
	2	805182	Extrusion, Side, Left
	3	805181	Extrusion, Middle
	3	805175	Extrusion, Bottom