

This Owner's Manual is provided and hosted by [Appliance Factory Parts](#).



Wolf W362418 Owner's Manual

[Shop genuine replacement parts for Wolf W362418](#)



[Find Your Wolf HVAC Parts - Select From 108 Models](#)

----- Manual continues below -----

MODEL W302418, W362418, W422418 PART LIST

<u>Ref #</u>	<u>Part #</u>	<u>Description</u>	<u>Ref #</u>	<u>Part #</u>	<u>Description</u>
1	805317	Screw, #8 X 1/2 Pan HD. Phil. S/M (6)	14	805328	Knob, Switch Control
2	805345	21 1/4" X 8 1/2" To 10" Rnd Trans.	15	805329	2-Hole Bezel, Switch
3	805392	Removable Back Panel 30"	16	805330	Fan Speed Control
	805393	Removable Back Panel 36"	17	805331	Light Switch Control #83
	805394	Removable Back Panel 42"	18	N/A	Top Partition (30",36",42",48")
4	805346	Electrical J-Box	19	805406	Grease Cup 30" Hood (22.832)
5	806336	Mounting Plate (included with 805086)		805490	Grease Cup 36"-42" Hood (16.885) (2)
6	805320	Nut, 10-24 Hex Flange Lock (8)	20	805334	Baffle Filter, 11-7/8" X 11-7/8" (**)
7	805086	900 CFM Blower (***)	21	805335	2-Hole Electrical Outlet (See SN Breaks)
8	805339	Nut, 1/4-20 Hex Flange Lock		805342	3-Hole electrical Outlet (See SN Breaks)
9	805323	Thermostat, Hi-Temp. Sensor	22	N/A	Lower Shroud (30", 36" 42")
10	805324	Electrical Terminal Block	23	N/A	Bottom Track (30", 36" 42")
11	805325	Light Socket, Ceramic (*)	24	N/A	Inner Side (Left & Right)
12	805326	Light Holder (*)	25	N/A	Front Cover (30", 36" 42")
13	805327	Halogen Light, 50 Par. 20/Cap (*)	26	806339	Runner, 30" Wallhood (2)
				806340	Runner, 42", 54", 66" Wallhoods (2) (36" Does Not Use Runners)


NOTES:

(*) (2) 30", 36", 42" wide

(**) (2) 30" wide
(3) 36", 42" wide

(***) Not Included with Hood (Sold Separately)

MODEL W302418, W362418, W422418 EXPLODED VIEW



NOTE: Can use 900 CFM internal blower with these models (not included), or remote blower (not included).