

This Owner's Manual is provided and hosted by [Appliance Factory Parts](#).



# KARCHER K50 Owner's Manual

[Shop genuine replacement parts for KARCHER K50](#)




[Find Your KARCHER Vacuum Cleaner Parts - Select From 5 Models](#)

----- Manual continues below -----

Original

**KARCHER**

K50 ELECTRIC BROOM



# **KARCHER** Original

## **K50 ELECTRIC BROOM**

<u>KEY</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>
1	KA-28842190	Switch Cover
2	KA-40804730	Nozzle Housing W/Switch
3	KA-40703990	Dirt Cup (Includes #4)
4	KA-45150880	Wheel W/Axle 2 Pk
5	KA-46234710	Motor
6	KA-63894340	Handle Ass'y
7	KA-66541180	Battery Pack
8	KA-66825560	Charger
9	KA-47622750	Brushroll Complete
10	KA-73120720	Washer
11	KA-63483510	Geared Belt
12	KA-73030920	Screw
13	KA-40804620	Bottom Plate (Includes #4)
14	KA-46721050	Charging Stand