


This Owner's Manual is provided and hosted by [Appliance Factory Parts](#).



Kenmore 116.32189203 Owner's Manual

[Shop genuine replacement parts for Kenmore
116.32189203](#)




[Find Your Kenmore Vacuum Cleaner Parts - Select From 746 Models](#)

----- Manual continues below -----

KENMORE Original & Replacement

UPRIGHT VACUUM Model 116.32189203




Original & Replacement **KENMORE** UPRIGHT VACUUM Model 116.32189203

KEY	PART NO.	DESCRIPTION
1	KE-8192088	Compartment, dust
2	KE-4369561	Shaft, rear wheel
3	KE-4370240	Cushion, rubber
4	KE-4370177	Wheel, rear
5	KE-4370264	Screw-taptite
6	KE-4369562	Washer, wheel
7	KE-4369564	Stopper, wheel (2)
9	KE-4368563	Screw, motor, case mounting
10	KE-4369051	On-off switch,
11	KE-4370085	Protector, assembly
13	NLA	Wire, lead, black
14	SS-3270	Connector, wire
17	NLA	Fitting, handle
18	KE-4368661	Supporter, handle
19	KE-4369923	Cover, switch
20	KE-4370270	Motor, unit
21	KE-4370266	Flange, motor
22	KE-4369569	Suppressoer, noise
23	KE-4370248	Support, rubber motor
24	KE-4370265	Support, rubber motor
25	KE-4370241	Housing, motor
26	NLA	Bumper
27	KE-4368748	Cord, connection
28	KE-8192089	Filter electrostatic
29	KE-4369056	Cover, front filter
30	KE-4368671	Filter, secondary
31	KE-4368672	Filter, exhaust
35	KE-4370510	Handle, carrying
36	KE-4370511	Tray, attachment
37	KE-4370173	Plate, support
38	KE-4369726	Cord, power
39	KE-4369058	Protector, rubber
40	NLA	Cover, dust
41	KE-4369064	Cover, button
45	KE-4368718	Screw, handle
46	KER-1468	Bag, dust sears no. 20-50688
48	KE-4368606	Packing, motor case
49	KE-4368607	Packing, right
50	KE-4148999	Screw
51	KE-4370978	Lead Wire Assy
52	KE-4369065	Handle Assy
53	KE-4369068	Cord Hook Base
54	KE-4368938	Screw
55	KE-4369068	upper Cord Hook
56	KE-4368713	Cord Hook Spring
57	KE-4368714	Waher
58	KE-4369068	Lower Cord Hook
59	KE-4370188	Screw

NLA = No Longer Available

KENMORE Original & Replacement

UPRIGHT VACUUM Model 116.32189203




Original & Replacement **KENMORE** UPRIGHT VACUUM Model 116.32189203

KEY	PART NO.	DESCRIPTION
1	KE-8192066	Nozzle housing
2	KE-4370410	Window
3	KE-4370382	Guard, furniture
4	KE-4370274	Spring, pedal
5	PR-1015	Belt, sears no. 20-5275
6	KE-8192391	Agitator assembly
7	KE-8192392	Bearing holder
8	KE-8192393	Spacer (felt washer)
9	KE-4370263	Bearing, nozzle
10	KE-4369526	Socket, bolt
11	FA-3515	Bulb, light sears no. 20-5240
12	KE-4369527	Shaft, wheel (as of 5/16/08)
13	KE-4368563	Screw, motor, case mounting
14	KE-8192067	Lower plate
15	KE-4370273	Cover, belt
18	KE-4369542	Sliding knob height adjustment
19	KE-4370073	Support, slider
20	KE-4369543	Cam, height adjustment
21	KE-4370182	Wheel, cam (2)
22	KE-4369499	Shaft, roller (2)
23	KE-4370280	Screw, motor case mounting
24	KE-4370835	Body, lower plate
25	KE-8191879	Cover, light
26	KE-4370183	Cushion, cam rubber
27	NLA	Nut/lock washer
28	KE-4370253	Spring
29	NLA	Screw, shoulder
30	KE-8195180	Pedal assembly
31	NLA	Screw, relay
32	KE-4370256	Frame
33	KE-4370394	Pedal
34	KE-4370258	Spring, pedal
35	KE-4370259	Shaft, pedal
36	KE-4370260	Cover, foot pedal
38	NLA	Spring, shifter
39	KE-4370280	Screw, motor case mounting
40	KE-4370285	Spring

NLA = No Longer Available

KENMORE Original & Replacement

UPRIGHT VACUUM Model 116.32189203



Original & Replacement **KENMORE**
UPRIGHT VACUUM Model 116.32189203

KEY	PART NO.	DESCRIPTION
1	KE-8191584	Hose, flexible
2	KE-4388884	Tool, crevice *sears no. 20-52631
3	KE-4388888	Wand, telescopic
4	KE-4388996	Regulatory, suction
5	KE-4388881	Brush, combination
6	KE-4388609	Brush, combination
7	KE-4388610	Holder, brush