



1	KE-4370473	WAND AND CORD, MOUNT ASSEMBLY
3	KE-4370474	WAND AND CORD, LOWER
4	KE-4370336	HOUSING BULB (INCLUDES NO 55)
5	KE-681550	SCREW 8-18 X 1-7/8 (2)
6	KE-4370579	NOZZLE (INCLUDES NO 7)
7	KE-4155587	BUMPER
8	KE-4153195	FOOT PEDAL
10	KE-4153196	SWIVEL
11	KE-742019	SWIVEL SEAL (2)
12	KE-4370577	PAD, FOOT PEDAL
13	KE-747287	INDICATOR LEVER
14	KE-747291	INDICATOR CAM
15	KE-742015	INDICATOR BLOCK
16	KE-725775	SPRING ASSIST
17	KE-742454	BRUSH ASSEMBLY
18	KE-681424	WASHER, METAL (12 X 1/2) (2)
19	KE-743395	BEARING AND HOUSING ASSEMBLY (2) (INCLUDES ILLUS 18)
20	KE-742013	LIFTER
21	KE-4370578	HANDLE RELEASE
22	KE-742332	OVERLOAD PROTECTOR
23	KE-4368522	WIRE CONNECTOR
24	KE-4370364	ROLLER, REAR (2)
25	KE-742006	REAR AXEL (2)
26	KE-4369752	BASE
27	KE-744029	FRONT AXEL ASSEMBLY
28	KE-4370340	SWIVEL CAP
29	KE-722909	WASHER, THRUST
30	KE-725635	WASHER
31	KE-722955	CATCH INDEXING
32	KE-742016	RATCHET CATCH
33	KE-681605	SCREW TYPE 25 #6 PAN (2)
34	KE-742509	END BRUSH TUFTED
35	KE-742506	BRUSH SPROCKET
36	KE-742031	BRUSH SPROCKET FLANGE
38	KE-742030	BEATER BRUSH (2)
39	KE-742029	BAR, BEATER
40	KE-681297	SCREW 8-18 X 5/8 (2)
41	KE-705093	MOTOR BRIDGE
42	KE-742024	BELT, COGGED - SEARS NO 20-5285 (AVAILABLE AT ANY SEARS RETAIL STORE)
43	KE-4370112	MOTOR
44	KE-742002	MOTOR ADJUSTMENT SPRING
45	KE-4369687	LENS, HEIGHT ADJUSTER
46	KE-4370580	EXTENSION, BUTTON
47	KE-747096	SOCKET, BULB
48	KE-4370342	CORD AND PLUG
50	N/P	HOSE ASSEMBLY (REFER TO YOUR CANISTER MODEL NUMBER FOR ORDERING REPLACEN
51	KE-4370018	BULB, LIGHT (15 WATT) SEARS NO 20-5240 (AVAILABLE AT ANYSEARS RETAIL STORE)

55	KE-747286	LENS LIGHT
56	KE-4153194	COVER, PLUG HOUSING