

This Owner's Manual is provided and hosted by [Appliance Factory Parts](#).



# Koblenz P-2500 Owner's Manual

[Shop genuine replacement parts for Koblenz P-2500](#)



[Find Your Koblenz Vacuum Cleaner Parts - Select From 30 Models](#)


----- Manual continues below part list -----

## Available Replacement Parts for Koblenz P-2500

<a href="#">apr2410</a>	AIR CLEANER COMPLETE UNIT
<a href="#">10063</a>	Hood handle
<a href="#">KO-130076</a>	hose .
<a href="#">240144P</a>	TRANSFORMER
<a href="#">KO-0908111</a>	Rod, Valve control

# KOBLENZ Original & Replacement

Models P-1500, P-1800, P-2000, P-2500, P-2600



# Original & Replacement **KOBLENZ**

Models P-1500, P-1800, P-2000, P-2500, P-2600

KEY	PART NO.	DESCRIPTION	KEYPART NO.	DESCRIPTION	
1	KO-130585	Handle Grip	46	KO-1309483	Container Base P-2600
2	KO-2303915	Upper Handle Tube Chromed P-1500, P-1800	47	KO-0110932	Self Tapping Screw P-2000, P-2500, P-2600
2	KO-2302578	Upper Handle Tube Chromed P-2000, P-2600	48	KO-120694	Container Base Seal
2	KO-2307056	Upper Handle Tube Painted P-2500			P-2000, P-2500, P-2600
3	KO-0530402	Lower Handle Tube Chromed P-1500, P-1800	49	KO-1305820	Tank Hose Connector
3	KO-0527101	Lower Handle Tube Chromed P-2000, P-2600			P-2000, P-2500, P-2600
3	KO-0536862	Lower Handle Tube Painted P-2500	50	KO-130076	Hose P-2000, P-2500, P-2600
4	KO-0105361	Self Tapping Screw 6" X 3/4"	51	KO-9410	Hose Connector Elbow
5	KO-130755	Switch Box P-1500, P-2000			P-2000, P-2500, P-2600
5	KO-1309509	Switch Box P-1800, P-2500, P-2600	52	KO-2460	Shampoo Brushes 6"
6	KO-010154	Self Tapping Screw 6" X 5/16"	52	KO-2450	Scrub Brushes 6"
7	SS-3270	Wire Nut	53	KO-2400*	Lambs Wool Pads 6" (Includes Key #54)
8	KO-110082	Switch	53	FA-2400*	Lambs Wool Pads 6" (Includes Key #54)
9	KO-1309517	Switch Box Cover	54	KO-1301415	Pad Clips
10	KO-1720432	Switch Box Label 1-Speed P-1500, P-2000,	55	KO-4616843	Motor Assembly 1-Speed P-1500, P-2000
10	KO-1720853	Switch Box Label 2-Speed P-1800, P-2500, P-2600	55	KO-4618971	Motor Assembly 2-Speed
11	KO-130845	Switch Knob			P-1800, P-2500, P-2600
12	KO-4618658	Valve Lever Control Ass'y P-2000, P-2500, P-2600	56	KO-1300680	Valve Cover P-2000, P-2500, P-2600
13	KO-0504829	Cord Hook P-1500, P-1800	57	KO-0404202	Concave Washer P-2000, P-2500, P-2600
14	KO-0302083	Pop Rivet P-1500, P-1800	58	KO-0200923	Nut P-2000, P-2500, P-2600
15	KO-0604645	Dispensing Lever P-2000, P-2500, P-2600	59	KO-4605903	Brush Support
16	KO-0100628	Self Tapping Screw 6 X 3/8	60	KO-1301159	Motor Cover
17	KO-0908111	Dispensing Rod P-2000, P-2500, P-2600	61	KO-4601043	Carbon Brush & Spring
18	KO-0521971	Valve Hook P-2000, P-2500, P-2600	62	KO-4618476	Brush Holder Assembly
19	KO-0522235	Valve Hook Spacer P-2000, P-2500, P-2600	63	KO-2802635	Armature
21	KO-0107458	Handle Screw	64	KO-0114926	Self Tapping Screw 8" x 1/2"
22	KO-0200675	Handle Screw Nut	65	KO-0528620	Rear Field Support
23	KO-1000991	Cord	66	KO-0528646	Front Field Support
24	KO-2804227	Motor Cord P-1500, P-2000	67	KO-2802536	Field 1-Speed P-1500, P-2000
24	KO-2804235	Motor Cord P-1800, P-2500, P-2600	67	KO-2803088	Field 2-Speed P-1800, P-2500, P-2600
25	KO-010063	Self Tapping Screw 6" X 1/2"	68	KO-0114900	Self Tapping Screw 8" x 5/16"
26	KO-2301554	Handle Yoke & Socket Ass'y Chromed	69	KO-0506071	Bearing Clamp
		P-1500, P-1800	70	KO-1201334	Armature Bearing Seal
26	KO-2301562	Handle Yoke & Socket Ass'y Chromed	71	KO-2600260	Armature Bearing
		P-2000, P-2600	72	KO-2600013	Thrust Ball
26	KO-2301570	Handle Yoke & Socket Ass'y Painted P-2500	73	KO-250059	Thick Thrust Plate
27	KO-0532945	Yoke Chrome P-1500, P-1800, P-2000, P-2600	74	KO-2500601	Thin Thrust Plate
27	KO-0532952	Yoke Painted P-2500	75	KO-1000512	Connector Block 1-Speed P-1500, P-2000
28	KO-011431	Special Screw	75	KO-1000546	Connector Block 2-Speed
29	KO-0523795	Socket Plate			P-1800, P-2500, P-2600
30	KO-0528869	Socket Chromed P-1500, P-1800	76	KO-0200162	Hex Nut
30	KO-0523910	Socket Chromed P-2000, P-2600	77	KO-420011	Bronze Gear Right
30	KO-0523928	Socket Painted P-2500	78	KO-420012	Bronze Gear Left
31	KO-0108837	Hex Head Screw 1/4" - 20 x 3/4"	79	KO-250849	Spindle
32	KO-0532978	Yoke Spring Cover Chromed	80	KO-250640	Spindle Key
		P-1500, P-1800, P-2000, P-2600	81	KO-040018	Washer
32	KO-0532986	Yoke Spring Cover Painted P-2500	82	KO-040238	Spindle Retainer
33	NLA	Spacer	83	KO-130058	Frame Insulator
34	KO-240144	Yoke Spring	84	KO-050480	Gear Case Cover (Comm.-End)
35	KO-0606475	Cover Chromed Die Casting	85	KO-2304616	Gear Case Cover (Fan-End)
		P-1500, P-1800, P-2000, P-2600	86	KO-370029	Cork Gasket
35	KO-0606467	Cover Painted Die Casting P-2500	87	KO-0527176	Connector Support P-1500, P-2000
36	KO-0114835	Self Tapping Screw 6" X 3/8"	87	KO-0527184	Connector Support
37	KO-120054	Furniture Guard			P-1800, P-2500, P-2600
38	KO-171434	Head Label P-1500, P-1800	88	KO-2303303	Motor Frame Assembly
38	KO-1720028	Head Label P-2000, P-2500, P-2600	89	KO-1300599	Frame Spacer
39	KO-130865	Container Top P-2000, P-2500	90	KO-130167	Motor Support
39	KO-1309491	Container Top P-2600	91	KO-130758	Base Insulator
40	KO-450015	120 Oz. Tank Ass'y P-2500	92	KO-0533745	Base Plate
40	KO-4501409	144 Oz. Tank Ass'y P-2000, P-2600	93	KO-011489	Self Tapping Screw 8" x 1/2"
41	KO-1300649	Tank Cap P-2000, P-2500, P-2600	94	KO-1305515	Screw Insulator
42	KO-0401364	Rubber Washer P-2000, P-2500, P-2600	95	KO-130216	Dispensing Tray P-2000, P-2500, P-2600
43	NLA	Dispensing Lever Support	96	KO-461452	Spindle Cap Kit
		P-2000, P-2500, P-2600 (Order KO-4618658)	97	KO-0400028	Washer
44	KO-2506616	Spiral Pin P-2000, P-2500, P-2600	98	KO-0115832	Self Tapping Screw 6 x 7/8
45	KO-2401586	Dispensing Lever Spring P-2000, P-2500, P-2600	99	KO-2510634	Thin Thrust Plate 0.005
46	KO-1305549	Container Base P-2000, P-2500			