


This Owner's Manual is provided and hosted by [Appliance Factory Parts](#).



Oreck 888G Owner's Manual

[Shop genuine replacement parts for Oreck 888G](#)



[Find Your Oreck Vacuum Cleaner Parts - Select From 249 Models](#)

----- Manual continues below part list -----

Available Replacement Parts for Oreck 888G


OR-1000	BELT, FLAT, UPRIGHTS, 1PK
OR-2000	BRUSHROLL ASSEMBLY O-016-1152

Original & Replacement **ORECK**

Models 888, 888G, 5000, 5300, 8300G

KEY	PART NO.	DESCRIPTION
1	O-010-4173	Grip White
1	NLA	Grip Black
2	O-896-0273	Handle Ass'y Black
3	O-014-1131	Cord Wrap Bracket
4	O-880-7023	Screw
5	O-010-1506	Cord Clip
6	O-010-2878	Cord 2 Wire White 888/5000
6	OR-3030-1	Cord 2 Wire White 30'
6	O-010-2870	Cord 3 Wire 30' Red 5300/8300
7	O-880-7122	Screw
8	O-80009	Disposable Dust Bag 9 Pk
8	O-80009DW	Disposable Hypoallergenic 9 Pk
8	OR-1435	Disposable Micro Filtration 8 Pk
9	O-010-0216	Outer Bag 888/5000
9	OR-1225	Outer Bag Hypoallergenic Gray
10	O-014-2663	Connector
11	O-013-2503	Collar
12	NLA	Seal
13	O-016-9546	Tube Ass'y
14	O-013-2460	Bag Clip Black
14	O-013-2456	Bag Clip White
14	O-013-2463	Bag Clip Red
15	O-015-4965	Fan Housing Ass'y W/Spring
16	O-010-8418	Spring
17	O-880-6134	Rivet
18	O-097530001	Fan Plastic
18	OR-2800	Fan Plastic
18	OR-2820	Fan Metal
19	O-013-7714	Fan Seal
20	O-013-2941	Cover
21	O-017-0020	Motor
21	OR-6000	Motor
22	O-010-1186	Motor Carbon Brush
23	O-010-7716	Motor Seal
24	O-010-9605	Felt Washer
25	O-880-5037	Nut
26	O-010-2942	Switch Cover
27	O-010-8823	Switch
28	NLA	Switch Plate
29	O-880-7026	Screw
30	O-010-5300	Name Plate 888/5000
30	O-010-5301	Name Plate 5300/8300
31	NLA	Housing Black (Order O-013-4723 White)
31	O-013-4950	Housing Red
32	O-014-0359	Bumper White
32	O-014-0367	Bumper Clear
33	O-013-6977	Intake Pivot
34	O-010-7713	Felt Seal
35	O-013-7360	Cord Retainer
36	O-010-2652	Wire Connector
37	O-010-0604	Drive Belt
37	OR-1000	Drive Belt
38	O-880-9000	Washer & Screw
39	O-880-9000	Washer & Screw
40	O-016-1152	Brushroll Ass'y
40	OR-2000	Brushroll Ass'y
41	NLA	Seal & Eyelet Ass'y
42	O-015-5565	Wire Ass'y 5300/8300
43	NLA	Bearing Plate R.H.
44	O-010-7727	Bearing Seal
45	O-010-7721	Seal
46	O-013-0475	Base Plate Ass'y W/Micro Sweep
47	O-013-2353	Channel
48	O-013-9758	Wheel
48	OR-7100	Wheel

NLA = No Longer Available



49	O-010-0159	Axle
50	O-015-0456	Corner Brush 5300/8300
51	O-880-7029	Screw 5300/8300
52	NLA	Washer
53	O-010-1266	Bushing
54	O-010-2650	Connector 5300/8300
55	O-010-8423	Bag Retainer Wire
56	O-880-5027	Nut 5300/8300
57	O-010-8425	Spring Detent

HANDLE ASS'Y FOR 888G/8300G

58	NLA	Handle Grip Left Gray
59	NLA	Handle Grip Right Gray
60	O-880-7027	Screw
61	O-013-7075	Post Grip
62	O-013-1121	Cord Wrap