

# Original & Replacement **ORECK**

## POWER BROOM Model DP-460

KEY	PART NO.	DESCRIPTION
1	O-63602	Handle
2	O-61576	Cord - Power
3	O-63630	Housing - Right
4	O-63631	Housing - Left
5	O-63234	Screw - Short
6	O-63571	Screw - Long
7	O-62941	Fiberglass Sleeveing
8	O-80058	Slide Switch Ass'y
8	O-63883	Rocker Switch Ass'y
9	O-63674	Motor
10	D-63550	Fan
11	O-63528	Washer
12	O-62620	#10 Hex Nut
13	O-63655	Button Release
14	O-63654	Seal - Dust
15	O-63653	Frame - Filter
16	D-63221A	Filter
17	O-80355	Dust Cup Ass'y
18	O-63691	Tube - Air Passage
19	O-63651	Body - Lower
20	O-63656	Housing Upper Floor Tool
21	NLA	Plate - Lower Floor Tool
22	NLA	Shaft
23	NLA	Roller
24	NLA	Spring - Brush Strip
25	NLA	Brush - Strip
26	NLA	Cap - Switch, Glamour
27	O-80330C	Floor Tool

NLA = No Longer Available

