


This Owner's Manual is provided and hosted by [Appliance Factory Parts](#).




Proteam CX420 Owner's Manual

[Shop genuine replacement parts for Proteam CX420](#)



[Find Your Proteam Vacuum Cleaner Parts - Select From 40 Models](#)

----- Manual continues below -----



	PART NUMBER	
1	103925	Accessory Lid (Red)
2	103926	Filter Compartment Cover (Black)
3	103927	Cover Leaf Spring
4	103928	Filter Compartment Lid Latch (Blk)
5	103929	Micro Filter-Holder
6	103744	Micro Filter, 5-Pack
7	103931	HEPA Filter
8	103932	Cord Reel
9	103933	Cord Reel Guide
10	103934	Suction Control Knob
11	103935	Wattage Indicator Face Plate(200W-1300W)
12	103936	Full Filter Indicator
13	103937	Sensor Tube
14	103938	Screw
15	103939	Hinge Cover Set
16	103940	Filter Compartment Gasket
17	103941	Cord Release Pedal (Red)
18	103942	On/Off Pedal (Red)
19	103943	Pedal Spring
20	103944	Exhaust Grill Latch
21	103945	Exhaust Grill (Red)

22	103946	Exhaust Foam
23	103947	Exhaust Filter Set (4 pcs.)
24	103948	Upper Filter Compartment Housing
25	103949	Gasket Ring (Blower)
26	103950	Circuit Board (1 20 V)
27	103951	Screw
28	103952	Motor Housing
29	103953	Vibration Pad
30	103954	On/Off Switch
31	103955	Motor Housing Insert
32	103956	Insulating Mat (Motor)
33	103957	Motor Mount Bearing (Blk)
34	103958	Motor (1 20 V)
35	103959	Motor Gasket
36	103960	Lower Housing
37	103961	Rear Wheel (Blk)
38	103962	Swivel Caster
39	103964	Crevice Tool
40	103965	Upholstery Tool
41	103966	Upholstery Tool Brush
42	103967	Floor Tool
43	103968	Vacuum Hose
44	103969	Telescopic Wand (32 mm)
45	103904	Docking Clip