


Easy Steam™

EXPRESS II



- PD20000
- PD20000BBC
- PD20000BPC
- PD20001
- PD20001BLK
- PD20002BLK
- PD20010
- PD20015
- PD20030
- PD20031

Easy Steam™

EXPRESS II

Item	Part Number	Models To Fit	Part Description
1	001361001	ALL PD20000, PD20000BPC	HANDLE ASSEMBLY - RED HANDLE TELESCOPIC
		PD20000BBC	HANDLE ASSEMBLY - BLUE HANDLE TELESCOPIC
		PD20001, PD20030, PD20031	HANDLE ASSEMBLY - RED HANDLE NON - TELESCOPIC
		PD20001BLK, PD20002BLK	HANDLE ASSEMBLY - BLACK HANDLE NON - TELESCOPIC
		PD20010	HANDLE ASSEMBLY - BLUE HANDLE NON - TELESCOPIC
		PD20015	HANDLE ASSEMBLY - RED HANDLE NON - TELESCOPIC
2	1PD1102000	ALL	FILL CUP
3	001364001	ALL	FUNNEL
4	001365001	ALL	WATER TANK CAP - RED
5	001362001	ALL	CARPET GLIDE
6	AD50000	ALL	STANDARD MOP PADS - 2 PACK
7	AD50005	ALL	SHAGGY MOP PADS - 2 PACK

PD20000
PD20000BBC
PD20000BPC
PD20001
PD20001BLK
PD20002BLK
PD20010
PD20015
PD20030
PD20031