


ASSEMBLY SCHEMATIC

SR30020






PART LISTING

Item	Part Number	Model's To Fit	Part Description
1	2KT2102000	SR30020	BAG LID ASSEMBLY WITH WIRING
2	303820001	SR30020	TOOL DOOR COVER ASSEMBLY
3	692577001	SR30020	TOOL DOOR COVER SPRING
4	303817001	SR30020	DISPLAY COVER ASSEMBLY
5	280136001	SR30020	DISPLAY PCB ASSEMBLY
6	280135001	SR30020	MAIN PCB ASSEMBLY
7	1KT2102000	SR30020	POWER SWITCH PEDAL
8	1KT2103000	SR30020	CORD REEL PEDAL
9	59142027	SR30020	PEDAL SPRING
10	59142031	SR30020	BAG HOUSING SEAL
11	521745001	SR30020	UPPER BAG HOUSING
12	59142034	SR30020	POWER SWITCH
13	1KT2104000	SR30020	EXHAUST FILTER COVER
14	521746001	SR30020	EXHAUST FILTER RETAINER
15	1RY3610000	SR30020	EXHAUST FILTER - CHARCOAL
	AR40110	SR30020	EXHAUST FILTER - CHARCOAL 1 PACK
16	59142015	SR30020	MOTOR ASSEMBLY
17	303818001	SR30020	BOTTOM HOUSING ASSEMBLY
18	59142037	SR30020	SWIVEL CASTER ASSEMBLY
19	521744001	SR30020	HOLDER - WAND STORAGE
20	59142033	SR30020	CORD REEL ASSEMBLY
21	59142035	SR30020	CORD GUIDE ASSEMBLY
22	59142017	SR30020	BAG HOLDER ASSEMBLY
23	RO-RY3620	SR30020	TYPE S HEPA BAG
	RO-AR10130	SR30020	TYPE S HEPA BAG - 2 PACK
24	1KT2101000	SR30020	INLET / SECONDARY FILTER RETAINER
25	1KT2100000	SR30020	INLET / SECONDARY FILTER
	AR40105	SR30020	INLET / SECONDARY FILTER - 1 PACK
26	303941001	SR30020	HOSE ASSEMBLY COMPLETE
27	303016001	SR30020	TELESCOPIC WAND ASSEMBLY
28	303819001	SR30020	BARE FLOOR BRUSH
29	59142020	SR30020	UPHOLSTERY / DUSTING TOOL
30	59142021	SR30020	CREVICE TOOL
31	303822001	SR30020	CREVICE DUSTER TOOL
32	303823001	SR30020	TURBO TOOL ASSEMBLY
	48414088	SR30020	BRUSH ROLL - TURBO TOOL
	38528037	SR30020	BELT - TURBO TOOL

SR30020

ASSEMBLY SCHEMATIC

SR30020
P.N.





PART LISTING

Item	Part Number	Model's To Fit	Part Description
1	303815001	SR30020	NOZZLE COVER ASSEMBLY
2	303816001	SR30020	NOZZLE BASE ASSEMBLY
3	2KT2101000	SR30020	PIVOT ASSEMBLY WITH WIRING
4	000511004	SR30020	PIVOT COVER WITH SEAL - CLEAR
5	672893001	SR30020	HANDLE RELEASE LEVER SPRING
6	303821001	SR30020	HEIGHT ADJUSTMENT ASSEMBLY
7	001532003	SR30020	FRONT WHEEL ASSEMBLY
8	633168001	SR30020	FRONT WHEEL SHAFT CLAMP
9	660208057	SR30020	FRONT WHEEL SHAFT CLAMP SCREW
10	001018034	SR30020	PCB ASSEMBLY
11	741266001	SR30020	MOTOR ASSEMBLY
12	001251015	SR30020	NOZZLE GUARD ASSEMBLY
13	660294006	SR30020	NOZZLE BASE SCREW
14	303543001	SR30020	BRUSH ROLL ASSEMBLY - WOOD
15	562206001	SR30020	BELT - POLY V
	2KT2100000	SR30020	POWER NOZZLE ASSEMBLY COMPLETE

SR30020
P.N.