


HANDLE ASSEMBLY



47705

04787

47695

13346

13185

47027

47026

47704

47696

04788

01749

42920

01750

47703

13185

13300

47702

47697

13300

SHAMPOO TANK
SEE PAGE 11

CORDWINDER
SEE PAGE 13

13300

43268

47698

*Spring

47700

47699

*Bushing

*Handle Latch

13300

43496

47701

11034


*Rivet

*These parts are not replaceable - included with Lower Handle 47697

ProStar HANDLE ASSEMBLY PARTS LIST

Order Number:	Description:
01749	Washer
01750	Roll Pin
04787	Screw
04788	Screw
11034	Screw
13185	Washer
13300	Screw
13346	Screw
42920	Handle Lock Shaft
43268	Tank Support Seal
43496	Dispenser Tube
47026	Screw
47027	Lockwasher
47696	Cord Holder
47696	Upper Handle
47697	Lower Handle (w/Latch)
47698	Boot
47699	Cord and Tube Clip
47700	Tank Support Bracket
47701	Cordwinder Housing Cover
47702	Front Dispenser Cover Assembly
47703	Handle Lock
47704	Upper Dispenser Assembly
47705	Handle Bar


~ HOOD & BASE ASSEMBLY-



ProStar BASE ASSEMBLY PARTS LIST

Order Number:	Description:	
11034	Screw	11034
11100	Screw	11100
11535	Felt Washer	11535
11687	Retaining Ring	11687
12477	Foaming Brush	12477
12875	Screw	12875
13297	Screw	13297
13298	Cord Clamp	13298
13299	Screw	13299
13327	Push-On Nut	13327
40010	Washer	40010
40011	Washer	40011
41162	Trunnion	41162
42832	Motor Assembly	42832
42899	Driven Pulley	42899
42901	Handle Latch Bracket	42901
42903	Cord Clamp	42903
42906	Sealing Cup	42906
42908	Baffle	42908
42946	Shield Seal	42946
44065	Lead Assembly	44065
44231	Switch	44231
45418	Screw	45418
45775	Hood Baffle	45775
45989	Screw	45989
46324	Belt	46324
47331	Base Cord	47331
47348	Switch Bracket	47348
47350	Cam	47350
47711	Bumper	47711
47712	Nut (Bottom Shield)	47712
47713	Bottom Shield	47713
47714	Polisher Bottom	47714
47744	Base	47744
48337	Hood	48337


~ SHAMPOO TANK ASSEMBLY ~



ProStar SHAMPOO TANK PARTS LIST

Order Number:	Description:
13306	Retaining Ring
13307	Washer
13308	Washer
13309	Seal
42939	Measuring Cap Seal
42940	Plunger Spring
42947	Tank Handle Pin
42948	Tank Handle Spring
45541	Lower Tank Seal
47706	Tank Handle
47707	Measuring Cap
47708	Tank Plunger
71020	Shampoo Tank Assembly

~ CORDWINDER ASSEMBLY-



SEE PAGES 3 & 4
FOR REPAIR INSTRUCTIONS.

TAB ON SPRING FITS INTO GROOVE IN CORDWINDER SHAFT. PRE-WIND SPRING THREE TURNS WHEN RE-ASSEMBLING.

B

CORD SIDE

A


ProStar CORDWINDER PARTS LIST

Order Number:	Description:
13300	Screw
13304	Screw
42911	Cord Reel Flange
42913	Drum Assembly
42915	Cordwinder Shaft
47338	Contact Spring Assembly
47339	Contact Ring Assembly
47340	Cord Reel
47341	Power Cord
47715	Front Cordwinder Plate
47716	Grommet
47717	Cordwinder Housing


**Order
Number:**

Description:


42828 Shampoo Brush (Set of 3)
42831 Nap Lifter (Set of 3)
42827 Scrub / Polish Brush (Set of 3)
01722 Scrub Pads (Set of 3)
01773 Lambs Wool Buff Pads (Set of 3)
01729 Disposable Polish Pads (12)
71018 Shampoo - Liter




42828
SHAMPOO BRUSH




42832
NAP LIFTER




42827
SCRUB / POLISH BRUSH




71018
SHAMPOO
(Liter)



01722
SCRUB PADS






01773
LAMBS WOOL
BUFF PADS



01729
DISPOSABLE
POLISH PADS

ProStar ACCESSORIES PARTS LIST


Order Number:	Description:
47718	Splash Guard
47719	Storage Tray Clip
47720	Storage Tray (w/Clips)
01730	Mist Sprayer (w/Bottle Support)
47741	Bottle Support
71017	Carton
71019	Owner's Manual



71017
CARTON



MIST SPRAYER
(Includes Bottle Support)
01730



71019
OWNER'S
MANUAL