

- Dimensioni: 21x29,7 cm
- Cartoncino: 300 g, plastificato opaco
- stampato fronte e retro
- stampa: quadricromia

- Dimensions: 21x29,7 cm
- Paper: 300 g, uncoated plastic film
- both side printing
- printing: 4-colour

die-cut line
do not print

DeLonghi

ACCESSORIES

11 WALL FLANGE W/CAP FOR WALL MOUNT 12 AIR EXHAUST HOSE 13 HOSE ADAPTOR 14 ACCESSORY FOR WALL MOUNT

15 ADD'L WINDOW BRACKET 16 ADD'L WINDOW BRACKET 17 WINDOW OUTLET 18 REMOTE CONTROL

A) screw part 13 into part 12 (hose)
B) screw part 17 into other end of hose (part 12)
C) follow instructions below

FOR HELP WITH SET UP OPERATION, REFER TO THE INSTRUCTION MANUAL.

STEP-BY-STEP

Appearance of actual model may vary

5min

1 STEP Bring the unit near a window. Extend part 15 & install to window.

2 STEP Attach PART 13 to the back of the unit.

3 STEP Insert PART 17, into the oval opening of the window bracket (PART 15).

4 STEP Be sure to have a 3-hole grounded outlet no more than 5 3/8 feet from the window, and plug in the unit.

5 STEP Turn the unit on and adjust the temperature for your desired comfort. See the user manual for further instruction on using the features and settings of the unit and remote control.

FOR OPTIMAL PERFORMANCE: The hose should be as close to the window as possible, without any kinks that could obstruct the flow of exhausted air thereby reducing cooling performance.

3 feet max

FOR HELP WITH SET UP, OPERATION,
CALL OUR CUSTOMER SERVICE CENTER AT:
TOLL FREE **1-800-322-3848** (U.S. only)
Monday – Friday 8:30am – 5:00pm EST

5715110941_01/0312

DeLonghi

A: ON/OFF button
B: MODE selection button
C: Fan speed selection button
D: TIMER button
E: Programmed operation increase temperature/time button
F: Programmed operation decrease temperature/time button
G: Display
H: Timer in operation indicator light
I: Fan speed lights
L: Fan speed lights
M: Fan speed lights
N: Fan mode light
O: Air-conditioning mode light
P: Dehumidifying mode light
Q: Alarm light
R: Remote control receiver
S: Light: the inner temperature is shown on the display
T: Light: the outdoor temperature is shown on the display

- | | |
|---|---|
| A ON/OFF | L Fan speed lights |
| B MODE selection button: Air conditioning, dehumidifying, fan | M Fan speed lights |
| C Fan speed selection button (MAX/MED/MIN) | N Fan mode light |
| D TIMER | O Air-conditioning mode light |
| E Programmed operation increase temperature/time button | P Dehumidifying mode light |
| F Programmed operation decrease temperature/time button | Q Alarm light |
| G Display: Displays the temperature values set and the programmed operating time | R Remote control receiver |
| H Timer in operation indicator light I/L/M Fan speed lights | S Light: the inner temperature is shown on the display |
| I Fan speed lights | T Light: the outdoor temperature is shown on the display |