


This Owner's Manual is provided and hosted by [Appliance Factory Parts](http://Appliance Factory Parts).



# ROPER GL3030WW1 Owner's Manual

[Shop genuine replacement parts for ROPER  
GL3030WW1](#)



3394551


2

[Find Your ROPER Dryer Parts - Select From 202 Models](#)

----- Manual continues below -----

# PARTS LIST

for



## GAS DRYER

**MODEL**  
**GL3030WW1**

▲ W-White, L-Almond



FOR CUSTOMER SATISFACTION ALWAYS USE  
FACTORY SPECIFICATION PARTS




**Whirlpool** CORPORATION

Benton Harbor, Michigan.

# TOP AND CONSOLE PARTS

For Models:GL3030WW1



1	386367	Panel, Rear Console
2	693994	Screw, Hex Washer Head
3	355326	Screw, 13/16 x 5/8
4	63790	Cap, End (L.H.)
5	358472	Stop, Push-In (2)
7	63796	Cap, End (R.H.)
8	358473	Nut, Push-In (2)
10	337448	Screen, Lint
11		Cover, Lint Screen
	688150	White
	689310	Almond
12	339229	Hinge, R.H.
	339230	Hinge, L.H.
13	688983	Screw, 8-18 x 5/8
14	64211	Screw, 8-18 x 1
16		Top
	3393385	White
	3393386	Almond
18	94614	Terminal
19	3348416	Knob, Temperature Selector
21	3393916	Timer Assembly, 60 Hz.
23	3393990	Harness, Wiring
29	339554	Screw
39	660936	Relay, Push-To-Start
48	3387906	Timer Knob & Dial
53	3394061	Bracket, Control
54	3387695	Panel, Control
62	688805	Clip
67	689559	Nut, Push-On (4)
72	690853	Wire, Ground
75	691707	Receptacle, Latching (3-Way) (Uses Terminal 94614)
79	694720	Switch, Temperature Selector
81	696075	Knob, Push-To-Start

LITERATURE PARTS

LIT3395433	Use & Care Guide
LIT3395320	Instructions, Installation
LIT3394551	List, Service Parts

OPTIONAL PARTS NOT INCLUDED

PAINT, TOUCH UP (1/2 oz.)

72017	White
72107	Almond

PAINT PRESSURIZED SPRAY (13 oz.)

350930	White
350956	Almond
350938	Primer, Gray
350941	Leveler (Thinner)

PAINT, BULK (1 qt.)

799344	White (Uncut)
978883	Almond (Uncut)

Following May Be Purchased: DO-IT-YOURSELF-REPAIR-MANUALS

LIT677813	Automatic Washer (Belt Drive)
LIT677818	Dryer
LIT677821	Compactor
LIT677967	Dishwasher
LIT677971	Ice Maker (In Refrigerator)



1	343641	Screw, 10-16 x 1/2
2	697776	Screw, 10-16 x 1/2 (External Ground)
3	693995	Screw, Hex Head
4		Plug, Front Panel
	3394975	White
	3394976	Almond
5	690893	Cover, Block
6	3393657	Restrainer, Belt
7	347736	Panel, Rear
9	691581	Clip, Door Switch
10	347207	Switch, Door
11	98129	Screw, 6-20 x 7/8 (2)
16	3392100	Foot, Dryer (4)
18		Cabinet
	3394109	White
	3394110	Almond
19	98234	Clip, Ground (2)
20	690363	Lock, Front Top (2)
21		Front Panel Assembly
	3394895	White
	3394896	Almond
23	685203	Clip, Felt Pad
24	3389441	Catch, Door
25	693994	Screw, Hex Head
28	348023	Hinge & Pin Assembly (2)
31	98997	Clip, Harness
32	694091	Screw
33	696144	Strike, Door
35	695656	Door, Rear
36		Door, Front
	348205	White
	689314	Almond
37		Handle, Door
	686711	White
	689306	Almond
38	349462	Seal & Bearing Assembly
40	132848	Screw, 10-24 x 1
41	22965	Strap, Ground
42	685763	Seal, Door
45	344020	Cord, Power
46	364089	Wire, Ground
48	3394083	Clip, Front Panel
51	238088	Hinge, Top (2)
53	691366	Idler & Pulley Assembly
56	3394651	Belt, Drive
57	348780	Base, Motor
58	172455	Bolt, 5/16-18 x 3/4
59	3389627	Pulley, 60 Hz.
61	3388235	Switch (Use W/3391888 Motor)
62	3391888	Motor, 60 Hz.
63	660658	Clamp, Motor (2)
	343481	(Alt.)
	685441	(Alt.)
64	690236	Wire, Ground (Motor)
67	694670	Burner Assembly, 60 Hz. (Refer To Pages 6 & 7 For Further Breakdown)
68	341029	Clamp, Pipe

69	694572	Kit, Conversion (Type 1, 2 & 3 To Type 4)
	279243	Kit, Conversion (Type 1 To Type 3)
84	688412	Clip, Retainer
85	694054	Valve, Gas 60 Hz. (Complete)
86	660991	Ignitor
	686590	(Alt.)
87	686953	Screw & Washer
88	694539	Coil, 60 Hz. (Split) (3 Terminal) (Pilot Position)
89	694540	Coil, 60 Hz. (2 Terminal) (Main)
90	694421	Screw, Bracket Mounting (8-32 x 1/2)
91	694538	Bracket, Coil
92	694426	Harness, Wiring
93	694424	Leak Limiter
94	694423	Screw, Regulator Adjustment
95	694422	Spring, Regulator
96	694510	Clip, Harness
97	239822	Plug, Pipe




1	694670	Burner Assembly 60 Hz. (Type 1, 2 & 3) (White Rodgers)
2	688617	Tube, Burner
3	694298	Bracket, Ignitor
4	660991	Ignitor
	686590	(Alt.)
5	686953	Screw & Washer (8-32 x 5/8)
6	343641	Screw, 10-16 x 1/2
7	693986	Base, Burner
8	339527	Screw, 8-32 x 3/8 (2)
9		Orifice, Burner
	234826	Type 1
	15775	Type 2
	15419	Type 3
	229742	Type 4 (Butane)
	234868	Type 4 (Propane)
10	694054	Valve, 60 Hz.
11	694421	Screw, 8-32 x 1/2 (2)
12	694538	Bracket, Coil
13	694540	Coil, 60 Hz. (2 Terminal) (Main)
14	694539	Coil, 60 Hz. (Split) (3 Terminal) (Pilot Position)
15	694424	Leak Limiter
16	694423	Screw, Regulator Adjustment
17	694422	Spring, Regulator
18	694426	Harness, Wiring (Complete)
19	694510	Clip, Harness
20	239822	Plug, Pipe
21	233273	Pipe, Gas Supply
22	345062	Valve & Union, Shut-Off
23	3393767	Pipe, Tail
24	233076	Nut, Compression
25	341029	Clamp, Pipe

FOLLOWING PARTS NOT ILLUSTRATED

279243	Conversion Kit Type (1) Natural to Type (3) Manufactured
694572	Conversion Kit (Type 1, 2 & 3) to Type (4) L.P.G.

# BULKHEAD PARTS

For Models:GL3030WW1



1	694283	Lint Chute Assembly
2	343641	Screw, 10-16 x 1/2
3	98460	Nut, Push-In
4	686889	Pad, Cabinet
5	90767	Screw, 8A x 3/8
6	3392519	Fuse, Thermal
7	3392247	Pad, Blower Housing
8	3387134	Thermostat, Internal-Bias
9	347139	Seal, Lint Chute
10	694089	Wheel, Blower
11	695081	Housing, Blower
12	337272	Clip
13	687128	Screw, 10-16 x 1/2
14	685458	Box, Heater
15	660036	Thermostat, 205~F (96~C)
	338471	(Alt.)
	341196	(Alt.)
16	337445	Support, Heater Box (2)
17	337450	Collar, Funnel
18	347389	Funnel, Burner
19	686770	Supp\ort Pr\otector
23	695239	Screw, 8-18 x 3/8
24	696302	Shield, Exhaust
25	3392123	Seal, Blower Shaft
41	690997	Ring, Tri
42	347364	Shaft, L.H.
43	339489	Shaft, R.H.
44	3389901	Roller, Support
46	348197	Washer, Support
47	120377	Nut, 3/8-16
48	685775	Bulkhead
49	338906	Sensor, Radiant
62	3394508	Ring, Bearing
63	690372	Screw, 11-16 x 7/8
66	337449	Seal, Rear Drum
67	695584	Drum Assembly
68	342847	Baffle, Drum
69	348945	Bracket, Support
70	90296	Clip
73	339956	Seal