


This Owner's Manual is provided and hosted by [Appliance Factory Parts](http://ApplianceFactoryParts.com).




# COMFORT-AIRE AHG H41 Owner's Manual

[Shop genuine replacement parts for COMFORT-AIRE  
AHG H41](#)



[Find Your COMFORT-AIRE HVAC Parts - Select From 1486 Models](#)

----- Manual continues below -----



ITEM NUMBER	PART NAME	DESCRIPTION
1	R87BDM001	CONTROL PANEL
2	R87BCE002	TERMINAL BOARD
3	R68DC0013	C,W,W2,G,R, TERMINAL BLOCK
4	R68DF0012	BLOWER TIME DELAY
5	R68AB0001	BLOWER RELAY HT
6	R68AB0003	RELAY
7	R68AA0002	120/110V TO 24V TRANSFORMER
8	R68DC0018	2 POLE TERMINAL BLOCK
9	R68DC0001	GROUND LUG
10	R87BAT002	LOW VOLTAGE SHIELD