


This Owner's Manual is provided and hosted by [Appliance Factory Parts](#).



COMFORT-AIRE A-DVH12SD-0 Owner's Manual

[Shop genuine replacement parts for COMFORT-AIRE
A-DVH12SD-0](#)



[Find Your COMFORT-AIRE HVAC Parts - Select From 1486 Models](#)

----- Manual continues below -----

HEAT CONTROLLER


**REPLACEMENT
PARTS LIST**

Single Zone Inverter Mini-Splits

A-DVH12SD-0

Outdoor Condenser

EXPLODED VIEW



REPLACEMENT PARTS

Location	Part Name	Quantity	Part No.
1	Rear net	1	201137300179
2	Condenser assembly	1	201537591112
3	Right clapboard assembly	1	201237500257
4	Big handle	1	201237390104
6	Chassis assembly	1	2012372A0045
7	Front panel	1	201237500196
7.1	Air outlet grille	1	201137500010
8	Axial flow fan	1	201100300034
9	Asynchronous motor	1	202400400990
10	Supporter assembly of fan motor	1	201237500176
11	Left supporter	1	201237500180
12	Top cover assembly	1	201237500177
13	Partition board assembly	1	201237500258
13.1	Capacitor of compressor 45/250	1	202401090021
13.2	Capacitor clip	1	201200100026
13.3	Reactance (reactor)	1	202301000860
16	Electronic control box assembly	1	2033373A0100
17	Liquid valve assembly	1	201637591330
17.1	Liquid valve	1	201600700076
17.2	Valve plate	1	2012373N0005
18	4-way valve assembly	1	201637591332
18.1	4-Ways valve	1	201600690008
19	Gas valve	1	201600720194
20	Compressor	1	201400601230
22	Ambient temperature sensor assembly	1	202301310075
23	Pipe temperature sensor assembly	1	202301300445
24	Discharge temperature sensor assembly	1	202301310068

Design, material, performance data and components subject to change without notice.

HEAT CONTROLLER

1900 Wellworth Ave., Jackson MI 49203 • Ph. 517-787-2100 • www.heatcontroller.com

A  Company