


HEAT CONTROLLER, INC.

**REPLACEMENT  
PARTS**

**Room Air Conditioner  
RADS-51B**

# Exploded View



# Replacement Parts List

RADS-51B		
LOC. NO.	PART DESCRIPTION	PART NO.
130410	Base Assembly, Weld	3041A20036G
130910	Cabinet Assembly, Single	3091AR6055M
135312	Grille Assembly, Front	3531A20087D
135313	Grille, Inlet	3530A10039H
147581	Link	4520AR3191A
147582-1	Louver, Vertical	5990AR3190C
147582-2	Louver, Vertical	5990AR3190D
149980	Shroud	4998AR1608A
152302	Filter, Air	5231AR2148A
237200	Panel, Control	3720A20017A
238310	Escutcheon	3831A10001F
249950	Case Assembly, Control	ABQ30999202
263230	Thermistor, Ntc	6323A20003S
264110	Power Cord Assembly	6411A20056A
267110	Remote Controller Assembly	6711A20066C
268711-2	Pcb Assembly, Main	EBR39266506
268711-1	Pcb Assembly, Display	6871A20432B
346811	Motor Assembly, AC, Single	4681A10016N
349480	Orifice	4948A10016B
352111	Tube Assembly, Capillary	5211AR3332N
352113	Tube Assembly, Discharge	5211A10129A
352115	Tube Assembly, Evaporator (In)	5211A10063E
35211A	Tube Assembly, Suction	5211A10062G
352380	Guide, Air	5238A20013A
352390	Guide Assembly, Air	5239A30003G
354210	Evaporator Assembly, First	5421A20016L
359012	Fan, Turbo	5900A10005B
550140	Damper, Compressor	5040AR4195A
554030	Condenser Assembly, First	5403A20009R
554160	Compressor Set, KOREA	2520UABC2JA
559011	Fan Assembly, Axial	5901A20011B
567502	Overload Protect	6750U-L050A
731273	Install Part Assembly, Single	3127A20074A
749740	Guide	5210AR3196C
W0CZZ	Capacitor, Film, Box	0CZZA20005B
W48602	Clamp, Spring	3H02932B

**Design, material, performance data and components  
subject to change without notice.**

## **HEAT CONTROLLER, INC.**

1900 Wellworth Ave., Jackson, Michigan 49203 • Ph. 517-787-2100 • Fax 517-787-9341

THE QUALITY LEADER IN CONDITIONING AIR

**[www.heatcontroller.com](http://www.heatcontroller.com)**