

This Owner's Manual is provided and hosted by [Appliance Factory Parts](http://ApplianceFactoryParts.com).



# COMFORT-AIRE HCH024 Owner's Manual

[Shop genuine replacement parts for COMFORT-AIRE  
HCH024](#)



[Find Your COMFORT-AIRE HVAC Parts - Select From 1487 Models](#)

----- Manual continues below -----

**PARTS LIST**  
**WATER SOURCE HEAT PUMPS**  
**HCH/HCV**

**HEAT CONTROLLER, INC.**

1900 Wellworth Ave. Jackson, MI 49203  
[www.heatcontroller.com](http://www.heatcontroller.com)  
517-787-2100

HC PARTS LIST		Rev Level	006	009	012	018	024			030			036			041			042			048			060												
			265	230	265	230	265	230	265	460	230	265	460	230	265	460	230	265	460	230	265	460	230	265	460	230	265	460	230	265							
Part #	Item Description		1	1	1	1	1	1	1	3	1	3	1	3	1	3	1	3	3	1	3	3	3	1	3	3	3	1	3	3	3	1	3	3	1	3	3

**Compressors**

34B0018N02	COMPRESSOR HG 1PH	B	1																																				
34B0018N01	COMPRESSOR HG 1PH	B		1																																			
34B0019N02	COMPRESSOR HG 1PH	B			1																																		
34B0019N01	COMPRESSOR HG 1PH	B				1																																	
34B0020N02	COMPRESSOR HG 1PH	B					1																																
34B0020N01	COMPRESSOR HG 1PH	B						1																															
34B0042N02	COMPRESSOR CR 1PH	B							1																														
34B0042N01	COMPRESSOR CR 1PH	B								1																													
34B0043N06	COMPRESSOR CR 1PH	B									1																												
34B0043N04	COMPRESSOR CR 3PH	B										1																											
34B0043N01	COMPRESSOR CR 1PH	B											1																										
34B0043N03	COMPRESSOR CR 3PH	B												1																									
68832726	COMPRESSOR CR 1PH	B													1																								
68832729	COMPRESSOR CR 3PH	B														1																							
68832727	COMPRESSOR CR 1PH	B															1																						
68832728	COMPRESSOR CR 3PH	B																1																					
34B0045N02	COMPRESSOR CR 1PH	B																	1																				
34B0045N04	COMPRESSOR CR 3PH	B																		1																			
34B0045N01	COMPRESSOR CR 1PH	B																			1																		
34B0045N03	COMPRESSOR CR 3PH	B																				1																	
34B0026N03	COMPRESSOR CR 3PH	B																					1																
34B0026N01	COMPRESSOR CR 1PH	B																						1															
34B0026N02	COMPRESSOR CR 3PH	B																							1														
34B0026N04	COMPRESSOR CR 3PH	B																								1													
34B0041N03	COMPRESSOR CR 3PH	B																									1												
34B0041N01	COMPRESSOR CR 1PH	B																										1											
34B0041N02	COMPRESSOR CR 3PH	B																											1										
34B0041N04	COMPRESSOR CR 3PH	B																												1									
34B0027N03	COMPRESSOR CR 3PH	B																													1								
34B0027N01	COMPRESSOR CR 1PH	B																														1							
34B0027N02	COMPRESSOR CR 3PH	B																															1						
34B0027N04	COMPRESSOR CR 3PH	B																																1					
34B0028N03	COMPRESSOR ZR 3PH	B																																			1		
34B0028N01	COMPRESSOR ZR 1PH	B																																			1		
34B0028N02	COMPRESSOR ZR 3PH	B																																			1		
34B0028N04	COMPRESSOR ZR 3PH	B																																				1	

**Compressor Mounting Hardware**

68154406	GROMMET, COMPRESSOR	B	4	4	4	4	4	4	4	4	4	4	4	4	4	4	4	4	4	4	4	4	4	4	4	4	4	4	4	4	4	4	4	4	4	4	4	4	
69127079	BOLT, COMPRESSOR	B	4	4	4	4	4	4	3	3	3	3	3	3	3	3	3	3	3	3	3	3	3	3	3	3	3	3	3	3	3	3	3	3	3	3	3	3	3

**Compressor Contactors**

13B0002N02	CONTACTOR 2 POLE 40A 1PH	B	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	
13B0003N01	CONTACTOR 3 POLE 30A 3PH	B								1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1

**Compressor Run Capacitors (Not req. for 3 phase)**

24280806	CAPACITOR 15 MFD 370V	B	1	1	1	1																																	
24280817	CAPACITOR 15 MFD 440V	B					1																																
24280808	CAPACITOR 20 MFD 370V	B						1	1																														
24280809	CAPACITOR 25 MFD 370V	B								1	1																												
24280810	CAPACITOR 30 MFD 370V	B										1																											
24280820	CAPACITOR 30 MFD 440V	B											1																										
24280811	CAPACITOR 35 MFD 370V	B												1																									
24280821	CAPACITOR 35 MFD 440V	B													1																								
68583200	CAPACITOR BOOT	A, B	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	







**Top Panel**

**Access Panel, Front**



**Divider Panel, Blower Side**

**Access Panel, Side**

**Corner Post, Electrical**

**HCH Sheetmetal Parts**



**Corner Post, Air Handler**

**Access Panel, Blower**

**Panel, Blower Discharge**

**HCH Sheetmetal Parts**



**Corner Panel, Water Coil**

**Divider Panel-Air Coil Side**

**HCH Sheetmetal Parts**

HCH Sheetmetal

Part #	Description	HCH006	HCH009	HCH012	HCH018	HCH024	HCH030	HCH036	HCH042	HCH048	HCH060
<b>1&amp;2 Access Panels, Front and Side</b>											
41F0168GFN	(1&2) Front Panel	1	1	1							
41F0167GFN	(1&2) Side Panel	1	1	1							
41F0077GFN	(1&2) Front and Side Panel				2	2	2				
41F0079GFN	(1&2) Front and Side Panel							2	2		
41F0081GFN	(2) Front Panel									1	1
41F0084GFN	(1) Side Panel									1	1
<b>3 Corner Panel, Water Coil</b>											
44F0155GFN	(3) Corner Panel, Water Coil	1	1	1							
44F0095GFN	(3) Corner Panel, Water Coil				1	1	1				
44F0098GFN	(3) Corner Panel, Water Coil							1	1		
44F0101GFN	(3) Corner Panel, Water Coil									1	1
<b>4 Corner Posts, Electrical</b>											
44F0156GNN	(4) Control Post (4) Control Box	1	1	1							
44F0094GNN	(4) Control Post (4) Control Box				1	1	1				
44F0097GNN	(4) Control Post (4) Control Box							1	1		
44F0100GNN	(4) Control Post (4) Control Box									1	1
<b>5 Corner Posts, Air Handler</b>											
44F0157GFN	(5) Corner Post, Air Handler	1	1	1							
44F0093GFN	(5) Corner Post, Air Handler				1	1	1				
44F0096GFN	(5) Corner Post, Air Handler							1	1	1	1
<b>6 Blower Discharge Panel</b>											
S43S0260GFN	(6) Blower Panel	1	1								
S43S0251GFN	(6) Blower Panel			1							
S43S0106GFN	(6) Blower Panel				1	1	1				
S43S0117GFN	(6) Blower Panel							1	1		
S43S0114GFN	(6) Blower Panel									1	
S43S0116GFN	(6) Blower Panel										1
<b>7 Drain Pan Assembly</b>											
49S0168GAP	(7) Drain Pan Assembly, Painted	1	1	1							
49S0065AFP	(7) Drain Pan Assembly, Painted				1	1	1				
49S0066AFP	(7) Drain Pan Assembly, Painted							1	1	1	
49S0067AFP	(7) Drain Pan Assembly, Painted										1
<b>8 Duct Collar</b>											
47F0407GNN	(8) Duct Collar	1	1	1							
47F0182GNN	(8) Duct Collar				1	1	1				
47F0177GNN	(8) Duct Collar							1	1		
47F0188GNN	(8) Duct Collar									1	1
<b>9 Divider, Air Coil Side</b>											
43F0250GFN	(9) Divider, One Piece	1	1	1							
43F0107GFN	(9) Divider, Air Coil Side				1	1	1				
43F0109GFN	(9) Divider, Air Coil Side							1	1		
43F0112GFN	(9) Divider, Air Coil Side									1	1

HCH Sheetmetal

Part #	Description	HCH006	HCH009	HCH012	HCH018	HCH024	HCH030	HCH036	HCH042	HCH048	HCH060
<b>10 Divider, Blower Side</b>											
43F0108GFN	(10) Divider, Blower Side				1	1	1				
43F0110GFN	(10) Divider, Blower Side							1	1		
43F0115GFN	(10) Divider, Blower Side									1	1
<b>11 Filter Bracket</b>											
46F0202GNN	(11) Filter bracket	2	2	2							
46F0148GNN	(11) Filter bracket				1	1	1				
46F0149GNN	(11) Filter bracket							1	1	1	
46F0150GNN	(11) Filter bracket										1
<b>12 Top Panels</b>											
42F0104GFN	(12) Top Panel	1	1	1							
42F0043GFN	(12) Top Panel				1	1	1				
42F0044GFN	(12) Top Panel							1	1		
42F0046GFN	(12) Top Panel									1	1
<b>13 Access Panels, Blower</b>											
41F0168GFN	(13) Air Handler Panel	1	1	1							
41F0078GFN	(13) Air Handler Panel				1	1	1				
41F0080GFN	(13) Air Handler Panel							1	1		
41F0085GFN	(13) Air Handler Panel									1	1

**Panel Access, Top**



**Corner Post, Water**

**Panel Water Coil**

**Front Panel, Access Controls**

**HCV Sheetmetal Parts**



**Wrapper, Rear**

**Panel Access Side**

**HCV Sheetmetal Parts**

**Blower Panel**



**HCV Sheetmetal Parts**



**Panel Access  
Full Side**

**Corner Post, Electrical**

**HCV Sheetmetal Parts**

**HCV Sheetmetal**

Part #	Description	HCV009	HCV012	HCV 018, 24 & 030	HCV 041	HCV 036 & 042	HCV 048	HCV 060
--------	-------------	--------	--------	-------------------	---------	---------------	---------	---------

**1 Panel, Access Side**

41F0173GFP	(1) Panel, Access Side	1	1					
41F0113GFP	(1) Panel, Access Side			1	1			
41F0108GFP	(1) Panel, Access Side					1		
41F0123GFP	(1) Panel, Access Side						1	1

**2 Panel, Access Top Side or Front**

41F0175GFP	(2) Panel, Access Top Side or Front	1	1					
41F0115GFP	(2) Panel, Access Top Side or Front			1	1			
41F0110GFP	(2) Panel, Access Top Front					1		
41F0125GFP	(2) Panel, Access Top Front						1	1

**3 Panel Access Full Side**

41F0174GFP	(3) Panel Access Full Side	1	1					
41F0116GFP	(3) Panel Access Full Side			1	1			
41F0111GFP	(3) Panel Access Full Side					1		
41F0126GFP	(3) Panel Access Full Side						1	1

**4 Panel, Water Connections**

41F0177GFP	(4) Panel, Water Connections	1	1					
41F0117GFP	(4) Panel, Water Connections			1				
41F0112GFP	(4) Panel, Water Connections					1		
41F0129GFP	(4) Panel, Water Connections				1			
41F0127GFP	(4) Panel, Water Connections						1	1

**5 Blower Panel Assembly**

S43S0262GFP	(5) Blower Panel Assembly, Left Return	1						
S43S0261GFP	(5) Blower Panel Assembly, Left Return		1					
S43S0171N01	(5) Blower Panel Assembly, Left Return			1				
S43S0168N01	(5) Blower Panel Assembly, Left Return					1		
S43S0191N01	(5) Blower Panel Assembly, Left Return				1			
S43S0178N01	(5) Blower Panel Assembly, Left Return						1	
S43S0189N01	(5) Blower Panel Assembly, Left Return							1
S43S0264GFP	(5) Blower Panel Assembly, Right Return	1						
S43S0263GFP	(5) Blower Panel Assembly, Right Return		1					
S43S0172N01	(5) Blower Panel Assembly, Right Return			1				
S43S0169N01	(5) Blower Panel Assembly, Right Return					1		
S43S0192N01	(5) Blower Panel Assembly, Right Return				1			
S43S0179N01	(5) Blower Panel Assembly, Right Return						1	
S43S0190N01	(5) Blower Panel Assembly, Right Return							1
43S0264GFP	(5) Blower Panel Assembly, Front Return	1						
43S0263GFP	(5) Blower Panel Assembly, Front Return		1					
S43S0173N01	(5) Blower Panel Assembly, Front Return			1				
S43S0193N01	(5) Blower Panel Assembly, Front Return				1			

**HCV Sheetmetal**

Part #	Description	HCV009	HCV012	HCV 018, 24 & 030	HCV 041	HCV 036 & 042	HCV 048	HCV 060
--------	-------------	--------	--------	-------------------	---------	---------------	---------	---------

**6 Corner Post, Electrical**

44F0159GFP	(6) Corner Post, Electrical	1	1					
44F0133GFP	(6) Corner Post, Electrical			1	1			
44F0130GFP	(6) Corner Post, Electrical					1		
44F0138GFP	(6) Corner Post, Electrical						1	1

**7 Corner Post Water**

44F0160GFP	(7) Corner Post, Water	1	1					
44F0134GFP	(7) Corner Post, Water			1	1			
44F0131GFP	(7) Corner Post, Water					1		
44F0139GFP	(7) Corner Post, Water						1	1

**8 Wrapper, Rear**

44F0161GFP	(8) Wrapper, Rear	1	1					
44F0135GFP	(8) Wrapper, Rear			1	1			
44F0132GFP	(8) Wrapper, Rear					1		
44F0140GFP	(8) Wrapper, Rear						1	1
44F0135GTP	(8) Wrapper, Rear - Mute			1	1			
44F0132GTP	(8) Wrapper, Rear - Mute					1		
44F0140GTP	(8) Wrapper, Rear - Mute						1	1

**9 Panel, Access Controls**

41F0176GFP	(9) Panel, Access Bottom Front	1	1					
45F0064GFP	(9) Panel, Access Bottom Front			1	1			
45F0063GFP	(9) Panel, Access Bottom Front					1		
45F0065GFP	(9) Panel, Access Bottom Front						1	1

**10 Filter Rack, Bottom**

46F0205GNP	(10) Filter Rack, Bottom	1	1					
46F0171GNP	(10) Filter Rack, Bottom			1	1			
46F0168GNP	(10) Filter Rack, Bottom					1		
46F0175GNP	(10) Filter Rack, Bottom						1	1

**11 Filter Rack, Top**

46F0206GNP	(11) Filter Rack, Top	1	1					
46F0172GNP	(11) Filter Rack, Top			1	1			
46F0169GNP	(11) Filter Rack, Top					1		
46F0176GNP	(11) Filter Rack, Top						1	1