


This Owner's Manual is provided and hosted by [Appliance Factory Parts](http://www.appliancefactoryparts.com).



COMFORT-AIRE HCV 041 Owner's Manual

[Shop genuine replacement parts for COMFORT-AIRE
HCV 041](#)



Front Panel, Access Controls

HCV Sheetmetal Parts

[Find Your COMFORT-AIRE HVAC Parts - Select From 1487 Models](#)

----- Manual continues below -----

PARTS LIST

WATER SOURCE HEAT PUMPS

HCH/HCV

HEAT CONTROLLER, INC.

1900 Wellworth Ave. Jackson, MI 49203
www.heatcontroller.com
517-787-2100

Top Panel

Access Panel, Front



Divider Panel, Blower Side

Access Panel, Side

Corner Post, Electrical

HCH Sheetmetal Parts



Corner Post, Air Handler

Access Panel, Blower

Panel, Blower Discharge

HCH Sheetmetal Parts



Corner Panel, Water Coil

Divider Panel-Air Coil Side

HCH Sheetmetal Parts

HCH Sheetmetal

Part #	Description	HCH006	HCH009	HCH012	HCH018	HCH024	HCH030	HCH036	HCH042	HCH048	HCH060
1&2 Access Panels, Front and Side											
41F0168GFN	(1&2) Front Panel	1	1	1							
41F0167GFN	(1&2) Side Panel	1	1	1							
41F0077GFN	(1&2) Front and Side Panel				2	2	2				
41F0079GFN	(1&2) Front and Side Panel							2	2		
41F0081GFN	(2) Front Panel									1	1
41F0084GFN	(1) Side Panel									1	1

3 Corner Panel, Water Coil

44F0155GFN	(3) Corner Panel, Water Coil	1	1	1							
44F0095GFN	(3) Corner Panel, Water Coil				1	1	1				
44F0098GFN	(3) Corner Panel, Water Coil							1	1		
44F0101GFN	(3) Corner Panel, Water Coil									1	1

4 Corner Posts, Electrical

44F0156GNN	(4) Control Post (4) Control Box	1	1	1							
44F0094GNN	(4) Control Post (4) Control Box				1	1	1				
44F0097GNN	(4) Control Post (4) Control Box							1	1		
44F0100GNN	(4) Control Post (4) Control Box									1	1

5 Corner Posts, Air Handler

44F0157GFN	(5) Corner Post, Air Handler	1	1	1							
44F0093GFN	(5) Corner Post, Air Handler				1	1	1				
44F0096GFN	(5) Corner Post, Air Handler							1	1	1	1

6 Blower Discharge Panel

S43S0260GFN	(6) Blower Panel	1	1								
S43S0251GFN	(6) Blower Panel			1							
S43S0106GFN	(6) Blower Panel				1	1	1				
S43S0117GFN	(6) Blower Panel							1	1		
S43S0114GFN	(6) Blower Panel									1	
S43S0116GFN	(6) Blower Panel										1

7 Drain Pan Assembly

49S0168GAP	(7) Drain Pan Assembly, Painted	1	1	1							
49S0065AFP	(7) Drain Pan Assembly, Painted				1	1	1				
49S0066AFP	(7) Drain Pan Assembly, Painted							1	1	1	
49S0067AFP	(7) Drain Pan Assembly, Painted										1

8 Duct Collar

47F0407GNN	(8) Duct Collar	1	1	1							
47F0182GNN	(8) Duct Collar				1	1	1				
47F0177GNN	(8) Duct Collar							1	1		
47F0188GNN	(8) Duct Collar									1	1

9 Divider, Air Coil Side

43F0250GFN	(9) Divider, One Piece	1	1	1							
43F0107GFN	(9) Divider, Air Coil Side				1	1	1				
43F0109GFN	(9) Divider, Air Coil Side							1	1		
43F0112GFN	(9) Divider, Air Coil Side									1	1

HCH Sheetmetal

Part #	Description	HCH006	HCH009	HCH012	HCH018	HCH024	HCH030	HCH036	HCH042	HCH048	HCH060
10 Divider, Blower Side											
43F0108GFN	(10) Divider, Blower Side				1	1	1				
43F0110GFN	(10) Divider, Blower Side							1	1		
43F0115GFN	(10) Divider, Blower Side									1	1
11 Filter Bracket											
46F0202GNN	(11) Filter bracket	2	2	2							
46F0148GNN	(11) Filter bracket				1	1	1				
46F0149GNN	(11) Filter bracket							1	1	1	
46F0150GNN	(11) Filter bracket										1
12 Top Panels											
42F0104GFN	(12) Top Panel	1	1	1							
42F0043GFN	(12) Top Panel				1	1	1				
42F0044GFN	(12) Top Panel							1	1		
42F0046GFN	(12) Top Panel									1	1
13 Access Panels, Blower											
41F0168GFN	(13) Air Handler Panel	1	1	1							
41F0078GFN	(13) Air Handler Panel				1	1	1				
41F0080GFN	(13) Air Handler Panel							1	1		
41F0085GFN	(13) Air Handler Panel									1	1

Panel Access, Top



Corner Post, Water

Panel Water Coil

Front Panel, Access Controls

HCV Sheetmetal Parts



Wrapper, Rear

Panel Access Side

HCV Sheetmetal Parts

Blower Panel



HCV Sheetmetal Parts



**Panel Access
Full Side**

Corner Post, Electrical

HCV Sheetmetal Parts

HCV Sheetmetal

Part #	Description	HCV009	HCV012	HCV 018, 24 & 030	HCV 041	HCV 036 & 042	HCV 048	HCV 060
--------	-------------	--------	--------	-------------------	---------	---------------	---------	---------

1 Panel, Access Side

41F0173GFP	(1) Panel, Access Side	1	1					
41F0113GFP	(1) Panel, Access Side			1	1			
41F0108GFP	(1) Panel, Access Side					1		
41F0123GFP	(1) Panel, Access Side						1	1

2 Panel, Access Top Side or Front

41F0175GFP	(2) Panel, Access Top Side or Front	1	1					
41F0115GFP	(2) Panel, Access Top Side or Front			1	1			
41F0110GFP	(2) Panel, Access Top Front					1		
41F0125GFP	(2) Panel, Access Top Front						1	1

3 Panel Access Full Side

41F0174GFP	(3) Panel Access Full Side	1	1					
41F0116GFP	(3) Panel Access Full Side			1	1			
41F0111GFP	(3) Panel Access Full Side					1		
41F0126GFP	(3) Panel Access Full Side						1	1

4 Panel, Water Connections

41F0177GFP	(4) Panel, Water Connections	1	1					
41F0117GFP	(4) Panel, Water Connections			1				
41F0112GFP	(4) Panel, Water Connections					1		
41F0129GFP	(4) Panel, Water Connections				1			
41F0127GFP	(4) Panel, Water Connections						1	1

5 Blower Panel Assembly

S43S0262GFP	(5) Blower Panel Assembly, Left Return	1						
S43S0261GFP	(5) Blower Panel Assembly, Left Return		1					
S43S0171N01	(5) Blower Panel Assembly, Left Return			1				
S43S0168N01	(5) Blower Panel Assembly, Left Return					1		
S43S0191N01	(5) Blower Panel Assembly, Left Return				1			
S43S0178N01	(5) Blower Panel Assembly, Left Return						1	
S43S0189N01	(5) Blower Panel Assembly, Left Return							1
S43S0264GFP	(5) Blower Panel Assembly, Right Return	1						
S43S0263GFP	(5) Blower Panel Assembly, Right Return		1					
S43S0172N01	(5) Blower Panel Assembly, Right Return			1				
S43S0169N01	(5) Blower Panel Assembly, Right Return					1		
S43S0192N01	(5) Blower Panel Assembly, Right Return				1			
S43S0179N01	(5) Blower Panel Assembly, Right Return						1	
S43S0190N01	(5) Blower Panel Assembly, Right Return							1
43S0264GFP	(5) Blower Panel Assembly, Front Return	1						
43S0263GFP	(5) Blower Panel Assembly, Front Return		1					
S43S0173N01	(5) Blower Panel Assembly, Front Return			1				
S43S0193N01	(5) Blower Panel Assembly, Front Return				1			

HCV Sheetmetal

Part #	Description	HCV009	HCV012	HCV 018, 24 & 030	HCV 041	HCV 036 & 042	HCV 048	HCV 060
--------	-------------	--------	--------	-------------------	---------	---------------	---------	---------

6 Corner Post, Electrical

44F0159GFP	(6) Corner Post, Electrical	1	1					
44F0133GFP	(6) Corner Post, Electrical			1	1			
44F0130GFP	(6) Corner Post, Electrical					1		
44F0138GFP	(6) Corner Post, Electrical						1	1

7 Corner Post Water

44F0160GFP	(7) Corner Post, Water	1	1					
44F0134GFP	(7) Corner Post, Water			1	1			
44F0131GFP	(7) Corner Post, Water					1		
44F0139GFP	(7) Corner Post, Water						1	1

8 Wrapper, Rear

44F0161GFP	(8) Wrapper, Rear	1	1					
44F0135GFP	(8) Wrapper, Rear			1	1			
44F0132GFP	(8) Wrapper, Rear					1		
44F0140GFP	(8) Wrapper, Rear						1	1
44F0135GTP	(8) Wrapper, Rear - Mute			1	1			
44F0132GTP	(8) Wrapper, Rear - Mute					1		
44F0140GTP	(8) Wrapper, Rear - Mute						1	1

9 Panel, Access Controls

41F0176GFP	(9) Panel, Access Bottom Front	1	1					
45F0064GFP	(9) Panel, Access Bottom Front			1	1			
45F0063GFP	(9) Panel, Access Bottom Front					1		
45F0065GFP	(9) Panel, Access Bottom Front						1	1

10 Filter Rack, Bottom

46F0205GNP	(10) Filter Rack, Bottom	1	1					
46F0171GNP	(10) Filter Rack, Bottom			1	1			
46F0168GNP	(10) Filter Rack, Bottom					1		
46F0175GNP	(10) Filter Rack, Bottom						1	1

11 Filter Rack, Top

46F0206GNP	(11) Filter Rack, Top	1	1					
46F0172GNP	(11) Filter Rack, Top			1	1			
46F0169GNP	(11) Filter Rack, Top					1		
46F0176GNP	(11) Filter Rack, Top						1	1