


This Owner's Manual is provided and hosted by [Appliance Factory Parts](#).



# COMFORT-AIRE OLRA125BHA Owner's Manual

[Shop genuine replacement parts for COMFORT-AIRE  
OLRA125BHA](#)



[Find Your COMFORT-AIRE HVAC Parts - Select From 1487 Models](#)


----- Manual continues below part list -----

## Available Replacement Parts for COMFORT-AIRE OLRA125BHA

[R41789-001H](#)

FRONT ACCESS PANEL

# PATRIOT 80 PARTS LIST



- OLFA
- OLRA
- OUFA
- OHHA
- ODHA

# PATRIOT 80 OIL FURNACE PARTS LIST

## OUFA-D

REVISED  
1/3/02

TO SELECT PART # Last letter of the Model # is the Service Level OUFA125D5 <u>A</u> First find Model #. _____> OUFA125D5(*) Then match Service Level for desired part.---->			REC STOCKING PART	SERVICE LEVEL # *	OUFA75D3(*)	OUFA95D4-1(*)	OUFA125D5(*)
REF	PART #	DESCRIPTION					
38	2060-0009	ASSY-HEAT EXCHANGER		A	1	1	
38	2060-0010	ASSY-HEAT EXCHANGER		A			1
48	2062-0001	CHAMBER-COMBUSTION		A	1	1	
48	2062-0002	CHAMBER-COMBUSTION		A			1
50	2015-0019	CONTROL-F&L W/CVR (LN 9)	+	A	1	1	1
68	2051-0027	ASSY-BLOWER		A			1
68	2051-0029	ASSY-BLOWER		A		1	
68	2051-0030	ASSY-BLOWER		A	1		
69	2010-0041	MOTOR 3/4 HP, 1 PHASE	+	A			1
69	2010-0043	MOTOR 1/3 HP, 1 PHASE	+	A	1		
69	2010-0042	MOTOR 1/2 HP, 1 PHASE	+	A		1	
71	2040-0147	BAND-MOTOR MOUNTING		A	1	1	
71	2040-0148	BAND-MOTOR MOUNTING		A			1
72	2040-0149	ARM-MOTOR MOUNTING		A	3	3	
72	2040-0150	ARM-MOTOR MOUNTING		A			4
73	2051-0036	WHEEL-BLOWER		A	1		
73	2051-0037	WHEEL-BLOWER		A		1	
73	2051-0034	WHEEL-BLOWER		A			1
74	2053-0014	ASS'Y BLOWER HOUSING		A	1		
74	2053-0012	ASS'Y BLOWER HOUSING		A			1
74	2053-0015	ASS'Y BLOWER HOUSING		A		1	
75	2021-0239	RAIL-BLOWER SUPPORT (20)		A	1	1	
75	2021-0240	RAIL-BLOWER SUPPORT (20)		A			1
76	2021-0239	RAIL-BLOWER SUPPORT (20)		A	1	1	
76	2021-0240	RAIL-BLOWER SUPPORT (20)		A			1
86	2013-0027	CAPACITOR 7.5 MFD@370V	+	A	1	1	
86	2013-0028	CAPACITOR-RUN 12.5	+	A			1
96	2063-0001	INSULATION-MTG PLATE BRNR	+	A	1	1	1
97	2061-0010	ARM-1501 OIL BURNER		A	1		
97	2061-0011	ARM1502 OIL BURNER		A		1	
97	2061-0012	ARM1503 OIL BURNER		A			1
100	2063-0002	CONTROL DRAFT	+	A	1	1	1
101	2063-0004	PLATE INNER POUCH		A	1	1	1
104	2041-0008	GASKET FLUE PIPE	+	A	1	1	1

# PATRIOT 80 OIL FURNACE PARTS LIST

OUFA-D	REVISED 1/3/02
--------	-------------------

TO SELECT PART # Last letter of the Model # is the Service Level OUFA125D5 <u>A</u> First find Model #. _____> OUFA125D5(*) Then match Service Level for desired part. ____>			REC STOCKING PART	SERVICE LEVEL = *	OUFA75D3(*)	OUFA85D4-1(*)	OUFA125D5(*)
REF	PART #	DESCRIPTION					
106	2041-0010	GASKET-COVER PLATES	+	A	3	3	3
121	2012-0021	RELAY	+	A	1	1	1
127	2040-0153	FILTER 24.63 X 15.63 X .50	+	A	1	1	1
135	2021-0242	ASSY OBSERVATION COVER		A	1	1	1
136	2021-0243	COVER-CLEANOUT		A	2	2	2
138	2063-0005	WELDMENT-BURNER MTG		A	1	1	1
991	2021-0247	PANEL - RIGHT SIDE		A	1	1	
991	2021-0248	PANEL - RIGHT SIDE		A			1
992	2021-0252	PANEL - LEFT SIDE		A	1	1	
992	2021-0253	PANEL - LEFT SIDE		A			1
993	2021-0259	WELD-BLWR DECK		A	1		
993	2021-0260	WELD-BLWR DECK		A			1
993	2021-0261	WELD-BLWR DECK		A		1	
994	2021-0270	PANEL-VEST (1)		A	1	1	
994	2021-0271	PANEL-VEST (1)		A			1
995	2021-0284	REAR PANEL		A	1	1	
995	2021-0285	PANEL-REAR		A			1
997	2021-0295	PANEL-TOP		A	1	1	
997	2021-0296	PANEL-TOP		A			1
999	2021-0300	PANEL-DOOR PAINTED		A	1	1	
999	2021-0301	PANEL-DOOR		A			1

# PATRIOT 80 OIL FURNACE PARTS LIST

## OLFA-D

REVISED  
1/3/02

TO SELECT PART # Last letter of the Model # is the Service Level OLFA125D5 <u>A</u> First find Model #. _____→ OLFA125D5(*) Then match Service Level for desired part.→			REC STOCKING PART	SERVICE LEVEL = *	OLFA95D4(*)	OLFA125D5(*)
REF	PART #	DESCRIPTION				
38	2060-0009	ASSY-HEAT EXCHANGER		A	1	
38	2060-0010	ASSY-HEAT EXCHANGER		A		1
48	2062-0001	CHAMBER-COMBUSTION		A	1	
48	2062-0002	CHAMBER-COMBUSTION		A		1
50	2015-0019	CONTROL-F&L W/CVR (LN 9)	+	A	1	1
68	2051-0027	ASSY BLOWER		A		1
68	2051-0028	ASSY BLOWER		A	1	
69	2010-0041	MOTOR 3/4 HP, 1 PHASE	+	A		1
69	2010-0042	MOTOR 1/2 HP, 1 PHASE	+	A	1	
71	2040-0147	BAND-MOTOR MOUNTING		A	1	
71	2040-0148	BAND-MOTOR MOUNTING		A		1
72	2040-0149	ARM-MOTOR MOUNTING		A	3	
72	2040-0150	ARM-MOTOR MOUNTING		A		4
73	2051-0034	WHEEL BLOWER		A		1
73	2051-0035	WHEEL BLOWER		A	1	
74	2053-0012	ASSY BLOWER HOUSING		A		1
74	2053-0013	ASSY BLOWER HOUSING		A	1	
75	2021-0236	RAIL-FILTER SIDE		A	1	1
76	2021-0236	RAIL-FILTER SIDE		A	1	1
86	2013-0027	CAPACITOR 7.5 MFD@370V	+	A	1	
86	2013-0028	CAPACITOR-RUN 12.5	+	A		1
96	2063-0001	INSULATION-MTG PLATE BRNR	+	A	1	1
97	2061-0005	ARM1502 OIL-BURNER		A	1	
97	2061-0006	ARM1503 OIL-BURNER		A		1
100	2063-0002	CONTROL-DRAFT	+	A	1	1
101	2063-0004	PLATE-INNER POUCH		A	1	1
104	2041-0008	GASKET-FLUE PIPE	+	A	1	1
106	2041-0010	GASKET-COVER PLATES	+	A	3	1
121	2012-0021	RELAY	+	A	1	1
135	2021-0242	ASSY-OBSERVATION COVER		A	1	1
136	2021-0243	COVER-CLEANOUT		A	2	2

# PATRIOT 80 OIL FURNACE PARTS LIST

## OLFA-D

REVISED  
1/3/02

TO SELECT PART # Last letter of the Model # is the Service Level OLFA125D5 <u>A</u> First find Model #. _____> OLFA125D5(*) Then match Service Level for desired part.---->			REC STOCKING PART	SERVICE LEVEL # *	OLFA95D4(*)	OLFA125D5(*)
REF	PART #	DESCRIPTION				
991	2021-0244	PANEL-RIGHT SIDE		A	1	1
992	2021-0249	PANEL-LEFT SIDE		A	1	1
993	2021-0262	DECK-BLOWER (2)		A		1
993	2021-0263	DECK-BLOWER		A	1	
994	2021-0270	PANEL-VEST (1)		A	1	
994	2021-0271	PANEL-VEST (1)		A		1
995	2021-0286	PNL-HANG-REAR DOOR		A	1	
995	2021-0287	PNL-HANG REAR DOOR		A		1
997	2021-0295	PANEL-TOP		A	1	
997	2021-0296	PANEL-TOP		A		1
999	2021-0300	PAEL-DOOR PAINTED		A	1	
999	2021-0301	PANEL-DOOR		A		1
999	2021-0271	PANEL-VEST (1)		A		1

## Replacement Parts – OLFA95D4-2

Ref #	Part #	Description
38	R42510-003	HEAT EXCHANGER
48	R41917-001	CHAMBER-COMBUSTION
68	R44554-007	ASSY-BLOWER 10 X 9 ½HP
69	28M88	R47465-001 MOTOR 1/2HP 1PH 120V
71	98M75	R07407B000 BAND – MOTOR MOUNT
72	33H36	R07408B003 ARM-MOTOR MTG
73	47K30	R02592A023 WHEEL-BLOWER
74	R44777-006	ASSY-BLOWER HOUSING
86	RS39232D004	7.5MFD@370V CAPAC. & BOOT
100	R01207B001	CONTROL-DRAFT
101	R32227B000	PLATE-INNER POUCH
106	35K72	GASKET
121	21W89	R44298-001 Transformer/Relay
121	40L87	R07489B009 RELAY
130	R47323-002	LABEL-WIRING DIAGRAM
132	35K56	R38937B001 GASKET
135	R41812-001	COVER-OBSERVATION
136	R41811-001	COVER-CLEANOUT
138	R41821-001	WELDMENT-BURNER MTG
183	R41930-001	RAIL-FILTER SIDE
980	R41789-003H	PANEL-REAR DOOR
981	R41789-001H	PANEL-FRONT ACCESS
991	R43084-001H	PANEL-RIGHT SIDE
992	R43084-002H	PANEL-LEFT SIDE
993	R41913-013	PANEL-BLOWER
994	RS41796-001	ASSY-VEST PANEL
997	R41794-001H	PANEL-TOP
998	R41911-003	PANEL-BASE

## REPLACEMENT PARTS – OLFA125D5-2

Ref #	Part #	Description
38	R42510-004	HEAT EXCHANGER
48	R41924-001	CHAMBER-COMBUSTION
68	R44554-012	ASSY-BLOWER 12 X 10 3/4HP
69	33H45	R47466-001 MOTOR 3/4HP 1PH 115V
71	33H39	R38180C001 BAND-MOTOR
72	46K05	R07408B008 ARM-MTR MTG
73	47K31	R02592A024 WHEEL-BLOWER
74	R44777-009	ASSY-BLOWER HOUSING
86	RS39232D008	12.5MFD@370V CAP. & BOOT
100	R01207B001	CONTROL-DRAFT
101	R32227B000	PLATE-INNER POUCH
106	35K72	GASKET
121	21W89	R44298-001 Transformer/Relay
121	40L87	R07489B009 RELAY
130	R47323-002	LABEL-WIRING DIAGRAM
132	35K56	R38937B001 GASKET
135	R41812-001	COVER-OBSERVATION
136	R41811-001	COVER-CLEANOUT
138	R41821-001	WELDMENT-BURNER MTG
183	R41930-001	RAIL-FILTER SIDE
980	R41789-004H	PANEL-REAR ACCESS
981	R41789-002H	PANEL-FRONT ACCESS
991	R43084-001H	PANEL-RIGHT SIDE
992	R43084-002H	PANEL-LEFT SIDE
993	R41913-015	PANEL-BLOWER
994	R41796-002	PANEL-VEST
997	R41794-002H	PANEL-TOP
998	R41911-004	PANEL-BASE

# PATRIOT 80 OIL FURNACE PARTS LIST

OLRA-D	REVISED 1/3/02
--------	-------------------

<b>TO SELECT PART #</b> Last letter of the Model # is the Service Level OLRA200-BH <b>A</b> First find Model #. _____> OLRA200-BH(*) Then match Service Level for desired part.---->			REC STOCKING PART	SERVICE LEVEL = *	OLRA95D4(*)	OLRA125D5(*)	OLRA170D5(*)	OLRA125BH(*)	OLRA200-BH(*)
REF	PART #	DESCRIPTION							
38	2060-0005	ASSY-HEAT EXCHANGER		A	1				
38	2060-0006	ASSY-HEAT EXCHANGER		A		1	1		
38	2060-0007	HEAT EXCHANGER		A			1		
38	2060-0008	ASSY-HEAT EXCHANGER		A				1	
48	2062-0001	CHAMBER-COMBUSTION		A	1				
48	2062-0002	CHAMBER-COMBUSTION		A		1	1		
48	2062-0003	COMBUSTION-CHAMBER		A				1	
50	2015-0019	CONTROL-F&L W/CVR (LN 9)	+	A	1	1	1	1	
68	2051-0025	ASSY-BLOWER		A			1		
68	2051-0026	ASSY-BLOWER		A				1	
68	2051-0027	ASSY-BLOWER		A		1	1		
68	2051-0028	ASSY-BLOWER		A	1				
69	2010-0040	MOTOR-BD 3/4 HP	+	A			1	1	
69	2010-0041	MOTOR 3/4 HP, 1 PHASE	+	A		1	1		
69	2010-0042	MOTOR-1/2 HP, 1 PHASE	+	A	1				
71	2040-0147	BAND-MOTOR MOUNTING		A	1				
71	2040-0148	BAND-MOTOR MOUNTING		A		1	1		
72	2040-0149	ARM-MOTOR MOUNTING		A	3				
72	2040-0150	ARM-MOTOR MOUNTING		A		4	4		
72	2040-0151	MOTOR MOUNT		A			1		
72	2040-0152	MOTOR MOUNT		A				1	
73	2051-0033	WHEEL-BLOWER		A			1		
73	2051-0034	WHEEL-BLOWER		A		1	1		
73	2051-0035	WHEEL-BLOWER		A	1				
74	2053-0010	ASSY-BLOWER HOUSING		A			1		
74	2053-0011	ASSY-BLOWER HOUSING		A				1	
74	2053-0012	ASSY-BLOWER HOUSING		A		1	1		
74	2053-0013	ASSY-BLOWER HOUSING		A	1				
75	2021-0236	RAIL-FILTER SIDE		A	1	1		1	
75	2021-0237	RAIL-FILTER SIDE (18)		A			1		
75	2021-0238	RAIL-FILTER SIDE (18)		A				1	
76	2021-0236	RAIL-FILTER SIDE		A	1	1		1	
76	2021-0237	RAIL-FILTER SIDE (18)		A			1		
76	2021-0238	RAIL-FILTER SIDE (18)		A				1	
86	2013-0027	CAPACITOR 7.5 MFD@370V	+	A	1				
86	2013-0028	CAPACITOR -RUN 12.5	+	A		1	1		

# PATRIOT 80 OIL FURNACE PARTS LIST

OLRA-D	REVISED 1/3/02
--------	-------------------

<b>TO SELECT PART #</b> Last letter of the Model # is the Service Level OLRA200-BH <u>A</u> First find Model #. _____> OLRA200-BH(*) Then match Service Level for desired part.____>			REC STOCKING PART	SERVICE LEVEL = *	OLRA95D4(*)	OLRA125D5(*)	OLRA170D5(*)	OLRA125BH(*)	OLRA200-BH(*)
REF	PART #	DESCRIPTION							
96	2063-0001	INSULATION-MTG PLATE BRNR	+	A	1	1	1	1	
97	2061-0005	ARM1502 OIL-BURNER		A	1				
97	2061-0006	ARM1503 OIL-BURNER		A		1			
97	2061-0007	ARM1504 OIL BURNER		A		1			
97	2061-0008	ARM1505 OIL BURNER		A			1		
97	2061-0009	ARM1506 OIL BURNER		A				1	
100	2063-0002	CONTROL-DRAFT	+	A	1	1	1		
100	2063-0003	CONTROL-DRAFT	+	A				1	
101	2063-0004	PLATE-INNER POUCH		A	1	1	1	1	
104	2041-0008	GASKET-FLUE PIPE	+	A	1	1	1		
104	2041-0009	GASKET-FLUE PIPE	+	A				2	
106	2041-0010	GASKET-COVER PLATES	+	A	3	3	3	3	
121	2012-0021	RELAY	+	A	1	1			
135	2021-0242	ASSY-OBSERVATION COVER		A	1	1	1	1	
136	2021-0243	COVER-CLEANOUT		A	2	2	2	2	
138	2063-0005	WELDMENT-BURNER MTG		A	1	1	1	1	
991	2021-0244	PANEL-RIGHT SIDE		A	1	1	1		
991	2021-0245	PANEL-RIGHT SIDE		A		1			
991	2021-0246	PANEL-RIGHT SIDE		A				1	
992	2021-0249	PANEL-LEFT SIDE		A	1	1	1		
992	2021-0250	PANEL-LEFT SIDE		A		1			
992	2021-0251	PANEL-LEFT SIDE		A				1	
993	2021-0254	DECK-BLOWER (2)		A		1			
993	2021-0255	DECK-BLOWER (2)		A		1			
993	2021-0256	PANEL-BLOWER (2)		A			1		
993	2021-0257	DECK-BLOWER (2)		A				1	
993	2021-0258	DECK-BLOWER		A	1				
994	2021-0266	PANEL-VEST (1)		A	1				
994	2021-0267	PANEL-VEST (1)		A		1	1		
994	2021-0268	PANEL-VEST (2)		A		1			
994	2021-0269	PANEL-VEST (2)		A				1	
995	2021-0275	PANEL-REAR ACCESS		A				1	
995	2021-0276	PANEL-REAR ACCESS		A	1				
995	2021-0277	PANEL-REAR ACCESS		A		1			
995	2021-0278	PANEL-REAR ACCESS		A		1			

# PATRIOT 80 OIL FURNACE PARTS LIST

OLRA-D	REVISED 1/3/02
--------	-------------------

<b>TO SELECT PART #</b> Last letter of the Model # is the Service Level OLRA200-BH <b>A</b> First find Model #. _____→ OLRA200-BH(*) Then match Service Level for desired part.→			REC STOCKING PART	SERVICE LEVEL = *	OLRA95D4(*)	OLRA125D5(*)	OLRA170D5(*)	OLRA125BH(*)	OLRA200-BH(*)
REF	PART #	DESCRIPTION							
995A	2021-0279	PANEL-UP REAR		A				1	
995A	2021-0280	PANEL-UP REAR		A				1	
995A	2021-0281	PANEL-UP REAR		A	1				
995A	2021-0282	PANEL-UP REAR		A		1			
995A	2021-0283	PANEL-UP REAR		A			1		
997	2021-0291	PANEL-TOP		A	1				
997	2021-0292	PANEL-TOP		A		1	1		
997	2021-0293	PANEL-TOP PRE-PAINT		A			1		
997	2021-0294	PANEL-TOP		A				1	
999	2021-0300	PANEL-DOOR PAINTED		A	1				
999	2021-0301	PANEL-DOOR		A		1	1		
999	2021-0302	PANEL-DOOR PRE-PAINT		A			1		
999	2021-0303	PANEL-DOOR PREPAINT		A				1	

# PATRIOT 80 OIL FURNACE PARTS LIST

## OHHA-D

REVISED  
1/3/02

TO SELECT PART # Last letter of the Model # is the Service Level OHHA95D3 <u>A</u> First find Model #. _____> OHHA95D3(*) Then match Service Level for desired part.____>			REC STOCKING PART	SERVICE LEVEL # *	OHHA95D3(*)
REF	PART #	DESCRIPTION			
38	2060-0005	ASSY-HEAT EXCHANGER		A	1
48	2062-0001	CHAMBER-COMBUSTION		A	1
50	2015-0020	CONTROL-F&L T2481 W/COVER	+	A	1
51	2015-0021	SWITCH-LIMIT GREEN/WHITE	+	A	1
68	2015-0031	ASSY BLOWER		A	1
69	2010-0044	MOTOR 1/2 HP, 1 PHASE	+	A	1
71	2040-0147	BAND-MOTOR MOUNTING		A	1
72	2040-0149	ARM-MOTOR MOUNTING		A	3
73	2051-0037	WHEEL BLOWER		A	1
74	2053-0016	ASS'Y BLOWER HOUSING		A	1
75	2021-0241	RAIL BLOWER SUPPORT (13)		A	1
76	2021-0241	RAIL BLOWER SUPPORT (13)		A	1
86	2013-0027	CAPACITOR 7.5 MFD@370V	+	A	1
96	2063-0001	INSULATION MTG PLATE BRNR	+	A	1
97	2061-0005	ARM1502 OIL BURNER		A	1
100	2063-0002	CONTROL DRAFT	+	A	1
101	2063-0004	PLATE INNER POUCH.		A	1
104	2041-0008	GASKET FLUE PIPE	+	A	1
106	2041-0010	GASKET COVER PLATES	+	A	3
121	2012-0021	RELAY	+	A	1
135	2021-0242	ASSY OBSERVATION COVER		A	1
136	2021-0243	COVER-CLEANOUT		A	2
138	2063-0005	WELDMENT BURNER MTG		A	1
993	2063-0264	PANEL BLWR DECK (4)		A	1
994	2021-0272	PANEL-VEST		A	1
995	2021-0288	PANEL BACK		A	1
997	2021-0297	PANEL TOP		A	1
999	2021-0304	PANEL-DOOR (3)		A	1

# PATRIOT 80 OIL FURNACE PARTS LIST

## ODHA-D

REVISED  
1/3/02

TO SELECT PART # Last letter of the Model # is the Service Level ODHA125D5 <b>A</b> First find Model #. _____> ODHA125D5(*) Then match Service Level for desired part. ____>			REC STOCKING PART	SERVICE LEVEL # *	ODHA95D3(*)	ODHA125D5(*)
REF	PART #	DESCRIPTION				
38	2060-0009	ASSY HEAT EXCHANGER		A	1	
38	2060-0010	ASSY HEAT EXCHANGER		A		1
48	2062-0001	CHAMBER COMBUSTION		A	1	
48	2062-0002	CHAMBER COMBUSTION		A		1
50	2015-0020	CONTROL F&L T2481 W/COVER	+	A	1	1
51	2015-0021	SWITCH LIMIT GREEN/WHITE	+	A	1	1
68	2051-0031	ASSY BLOWER		A	1	
68	2051-0032	ASSY BLOWER		A		1
69	2010-0041	MOTOR 3/4 HP, 1 PHASE	+	A		1
69	2010-0044	MOTOR 1/2 HP, 1 PHASE	+	A	1	
71	2040-0147	BAND MOTOR MOUNTING		A	1	
71	2040-0148	BAND MOTOR MOUNTING		A		1
72	2040-0149	ARM MOTOR MOUNTING		A	3	
72	2040-0150	ARM MOTOR MOUNTING		A		4
73	2051-0037	WHEEL BLOWER		A	1	
73	2051-0034	WHEEL BLOWER		A		1
74	2053-0016	ASSY BLOWER HOUSING		A	1	
74	2053-0017	ASSY BLOWER HOUSING		A		1
75	2021-0241	RAIL-BLOWER SUPPORT (13)		A	1	1
76	2021-0241	RAIL-BLOWER SUPPORT (13)		A	1	1
86	2013-0027	CAPACITOR 7.5 MFD@370V	+	A	1	
86	2013-0028	CAPACITOR-RUN 12.5	+	A		1
96	2063-0001	INSULATION MTG PLATE BRNR	+	A	1	1
97	2061-0005	ARM1502 OIL BURNER		A	1	
97	2061-0006	ARM1503 OIL BURNER		A		1
100	2063-0002	CONTROL DRAFT	+	A	1	1
101	2063-0004	PLATE-INNER POUCH	+	A	1	1
104	2041-0008	GASKET FLUE PIPE	+	A	1	1
106	2041-0010	GASKET COVER PLATES	+	A	3	3
121	2012-0021	RELAY	+	A	1	1

# PATRIOT 80 OIL FURNACE PARTS LIST

<h2 style="margin: 0;">ODHA-D</h2>	REVISED 1/3/02
------------------------------------	-------------------

	REF	PART #	DESCRIPTION	REC STOCKING PART	SERVICE LEVEL *	ODHA95D3(*)	ODHA125D5(*)
	TO SELECT PART # Last letter of the Model # is the Service Level ODHA125D5 <u>A</u> First find Model #. _____> ODHA125D5(*) Then match Service Level for desired part.---->						
	135	2021-0242	ASSY OBSERVATION COVER		A	1	1
	136	2021-0243	COVER CLEANOUT		A	2	2
	138	2063-0005	WELDMENT BURNER MTG		A	1	1
	993	2021-0264	PANEL BLWR DECK (4)		A	1	
	993	2021-0265	PANEL BLWR DECK		A		1
	994	2021-0273	PANEL VEST		A	1	
	994	2021-0274	PANEL VEST		A		1
	995	2021-0289	PANEL BACK		A	1	
	995	2021-0290	PANEL BACK		A		1
	997	2021-0298	PANEL TOP		A	1	
	997	2021-0299	PANEL TOP		A		1
	999	2021-0304	PANEL - DOOR (3)		A	1	
	999	2021-0305	PANEL DOOR PRE PAINT		A		1