

This Owner's Manual is provided and hosted by [Appliance Factory Parts](#).



COMFORT-AIRE TGLS 05EAUER06 Owner's Manual

[Shop genuine replacement parts for COMFORT-AIRE
TGLS 05EAUER06](#)

The logo for Comfort-Aire is written in a blue, cursive script font. A registered trademark symbol (®) is located at the end of the word "Aire".

[Find Your COMFORT-AIRE HVAC Parts - Select From 1486 Models](#)

----- Manual continues below -----

RECOMMENDED PARTS TO STOCK FOR HCI GMUH/GMDA & RHEEM SERIES GAS FURNACES (50-150)

| HCI GMUH/GMDA MODELS RHEEM TGPS/TGLS MODELS | 50-E3N/A | 75-E3N/A | 75-E4N/A | 100-E3N/A | 100-E5N/A |
|--|----------------------|----------------------|----------------------|----------------------|----------------------|
| | 05EAUER06 | 07EAUER06 | 07EAMGR06 | 10EAMER06 | 10EBRJR06 |
| * DOOR SWITCH | 42-22692-01 | 42-22692-01 | 42-22692-01 | 42-22692-01 | 42-22692-01 |
| * INDUCER MOTOR | 70-24157-03 | 70-24157-03 | 70-24157-03 | 70-24157-03 | 70-24157-03 |
| * TRANSFORMER (FUSED) | 46-22863-04 | 46-22863-04 | 46-22863-04 | 46-22863-04 | 46-22863-04 |
| * TRANSFORMER FUSE | 46-22863-84 | 46-22863-84 | 46-22863-84 | 46-22863-84 | 46-22863-84 |
| BLOWER MOTOR | 51-23012-41 | 51-23012-41 | 51-24272-01 | 51-23012-41 | 51-25327-01 |
| MOTOR CAPACITOR | 43-25136-05 | 43-25136-05 | 43-25136-08 | 43-25136-05 | 43-25136-08 |
| BLOWER WHEEL | 70-22683-01 | 70-22683-01 | 70-21476-02 | 70-21476-02 | 70-20602-01 |
| * MOTOR MOUNTING LEG (4) | AE-61698-82 | AE-61698-82 | AE-61698-82 | AE-61698-82 | AE-61698-82 |
| BURNER (AFTER 3/1/97) | AS-60993-02 | AS-60993-03 | AS-60993-03 | AS-60993-04 | AS-60993-04 |
| * OVER TEMPERATURE SWITCH | 47-22861-01 QTY 1 | 47-22861-02 QTY 2 | 47-22861-01 QTY 2 | 47-22861-01 QTY 2 | 47-22861-01 QTY 2 |
| LIMIT CONTROL (N-SERIES) | 47-25349-03 | 47-25349-02 | 47-25349-01 | 47-25349-02 | 47-25349-02 |
| LIMIT CONTROL (A-SERIES) | 47-25349-11 | 47-25349-01 | 47-25349-01 | 47-25349-01 | 47-25349-03 |
| AUXILIARY LIMIT | 47-22860-01 | 47-22860-01 | 47-22860-01 | 47-22860-03 | 47-22860-01 |
| PRESSURE SWITCH (N-SERIES) | 42-24194-01 | 42-24194-02 | 42-24194-02 | 42-24194-02 | 42-24194-02 |
| PRESSURE SWITCH (A-SERIES) | 42-101082-01 | 42-101082-01 | 42-24194-01 | 42-101082-01 | 42-101082-01 |

IGNITION SYSTEMS FOR UNITS WITH SERIAL NUMBERS BEGINNING WITH GE, GA (HOT SURFACE IGNITION)

| HCI GMUH/GMDA MODELS | 50-E3N | 75-E3N | 75-E4N | 100-E3N | 100-E5N |
|----------------------|--------------|--------------|--------------|--------------|--------------|
| * CONTROL BOARD | 62-24268-03 | 62-24268-03 | 62-24268-03 | 62-24268-03 | 62-24268-03 |
| * GAS VALVE | 60-100394-01 | 60-100394-01 | 60-100394-01 | 60-100394-01 | 60-100394-01 |
| * IGNITOR | 62-22868-93 | 62-22868-93 | 62-22868-93 | 62-22868-93 | 62-22868-93 |
| * REMOTE SENSOR | 62-23543-01 | 62-23543-01 | 62-23543-01 | 62-23543-01 | 62-23543-01 |

IGNITION SYSTEMS FOR UNITS WITH SERIAL NUMBERS BEGINNING WITH GH (DIRECT SPARK IGNITION)

| HCI GMUH/GMDA MODELS RHEEM TGPS/TGLS MODELS | 50-E3A 05EAUER06 | 75-E3A 07EAUER06 | 75-E4A 07EAMGR06 | 100-E3A 10EAMER06 | 100-E5A 10EBRJR06 |
|--|---------------------|---------------------|---------------------|----------------------|----------------------|
| * CONTROL BOARD | 62-25338-01 | 62-25338-01 | 62-25338-01 | 62-25338-01 | 62-25338-01 |
| * GAS VALVE | 60-100394-02 | 60-100394-02 | 60-100394-0 | 60-100394-02 | 60-100394-02 |
| * IGNITOR | 62-24164-01 | 62-24164-01 | 62-24164-01 | 62-24164-01 | 62-24164-01 |
| * REMOTE SENSOR | 62-23543-01 | 62-23543-01 | 62-23543-01 | 62-23543-01 | 62-23543-01 |

- * INDICATES PARTS COMMON TO ALL HCI GMUH/GMDA & RHEEM TGPS/TGLS MODEL 80% GAS FURNACES
- HCI GMUH/GMDA "A" SERIES MODELS SAME AS RHEEM TGPS/TGLS MODELS

Wilenius/Aug. 2007/ GMUH/GMDA & TGPS/TGLS Parts to Stock