

This Owner's Manual is provided and hosted by [Appliance Factory Parts](#).




# VIKING DBCV30821 Owner's Manual

[Shop genuine replacement parts for VIKING  
DBCV30821](#)



[Find Your VIKING Range Hoods Parts - Select From 411 Models](#)

----- Manual continues below -----



Ref #	Part Number	Qty.	Description
1	UNSERVICEABLE	1	OVEN CAVITY, ASM 36
2	B2008158	1	HOOD I/S SIDE RH DBCV3082
3	PE070204	1	HEYCO STRAIN RELIEF - 7-P2
4	PE070205	1	3 PRONG FEMALE SUPPLY CORD
5	PD040005	2	SNAP BUSHING - 7/8
6	PE050064	2	LIGHT ASSEMBLY
7	B2008160	1	30 CONTROL PANEL DBCV3082
8	G31010266	2	30/42 FILTER ASSEMBLY 11.75 X 10.375
9	B2008197	1	FILTER SPACER DBCV3082 4.625 X 10.75
10	B2008165	1	30 FILTER SUPPORT DBCV3082
11	PA010089	2	KNOB (DESIGNER SERIES HOOD)
12	024862-000	1	FAN MOTOR CONTROL W/TIMER
13	004053-000	1	CONTROL PANEL TOP (DBC30)
14	B2008159	1	HOOD I/S SIDE LH DBCV3082
15	PE070196	1	FEMALE SOCKET (2 PRONG)
16	PE070197	1	MALE SOCKET (3 PRONG)
NI	PD020010	1	10 X 3/8 GREEN GROUNDING SCREW
NI	PD030010	4	NO.10-24 KEPS NUT
NI	PD020139	8	NO.8 X 1/2 P.H. FLAT TOP TRUSS U/C NO.2 TYPE AB 30 SS/...
NI	PD020032	26	SRW-8(A)X3/8PH.WFR HD 7/16DIAXNICL
NI	PC040010	25	POP RIVET