

This Owner's Manual is provided and hosted by [Appliance Factory Parts](#).




VIKING VIPR101 Owner's Manual

[Shop genuine replacement parts for VIKING VIPR101](#)



[Find Your VIKING Range Hoods Parts - Select From 411 Models](#)

----- Manual continues below -----



Ref #	Part Number	Qty.	Description
1	PV300231		TOP COVER ASSEMBLY - REMOTE (BEFORE 02/04)
	PS200002		TOP COVER ASSY - WIDE (VIPR101R) S97015502 (AFTER 02/04)
2	PV300228		TOP COVER ASSEMBLY (BEFORE 02/04)
	PS200005		TOP COVER ASSY - WIDE (VIPR101) S97015503 (AFTER 02/04)
3	PV300154		DNDFT FLTR KT 97015504 RE
4	PV300185		FILTER ASSY
5	PV300115		RIGHT END CAP
6	PV300116		LEFT END CAP
7	PV300117		TRIM PANEL (VIPR102RSS, VIPR102SS)
8	PV300120		CHIMNEY SLIDE
9	PV300121		PCB DOWN DRAFT LOWER 97015510
10	PV300122		GEAR MOTOR
11	PV300123		CRANK ASSEMBLY
12	PV300124		REMOTE ASSEMBLY 97015513
13	PV300125		TOUCH PAD SWITCH HARNESS 97015514
14	PV300148		REMOTE CABLE 97015545
15	PD210015		SWITCH-DOWN DRAFT (S97015839)
No.	PV300182		UP/DOWN CONTROL ASSEMBLY
16	PV300170		30 MAIN BACK ASSY 97015278
17	PV300167		30 CHIMNEY & SLIDE ASSY 97014962
No.	PV300163		GASKET FELT 30 VIPR101 99100535
No.	PV300166		INSTALLATION HARDWARE 97011305
No.	PS200001		SPACER (99710032) VIPR