


This Owner's Manual is provided and hosted by [Appliance Factory Parts](http://www.ApplianceFactoryParts.com).




VIKING VIPR181 Owner's Manual

[Shop genuine replacement parts for VIKING VIPR181](#)



[Find Your VIKING Range Hoods Parts - Select From 411 Models](#)

----- Manual continues below -----



Ref #	Part Number	Qty.	Description
1	PV300233		VIKING PRO TOP COVER ASSEMBLY (REMOTE)-NEW STYL...
	PS200004		TOP COVER ASSY - WIDE (VIPR181R) S97015538
2	PV300230		TOP COVER ASSEMBLY (BEFORE 02/04)
	PS200007		TOP COVER ASSY - WIDE (VIPR181) S97015540
3	PV300154		DNDFT FLTR KT 97015504 RE
4	PV300187		FILTER ASSEMBLY - VIPR181
5	PV300115		RIGHT END CAP
6	PV300116		LEFT END CAP
7	PV300119		TRIM PANEL (VIPR182RSS, VIPR182SS)
8	PV300120		CHIMNEY SLIDE
9	PV300121		PCB DOWN DRAFT LOWER 97015510
10	PS200015	1	GEAR MOTOR KIT (VIPR102RSS, VIPR162RSS, VIPR102SS,...
11	PV300123		CRANK ASSEMBLY
12	PV300124		REMOTE ASSEMBLY 97015513
13	PV300125		TOUCH PAD SWITCH HARNESS 97015514
14	PV300148		REMOTE CABLE 97015545
15	PD210015		SWITCH-DOWN DRAFT (S97015839)
NI	PV300182		UP/DOWN CONTROL ASSEMBLY
16	PV300172		48 MAIN BACK ASSY 97015273
17	PV300169		48 CHIMNEY & SLIDE ASSY 97015216
NI	PV300165		48 FELT GASKET (VIPR181) 99100539
NI	PV300166		INSTALLATION HARDWARE 97011305