

This Owner's Manual is provided and hosted by [Appliance Factory Parts](#).




VIKING VBCV60381 Owner's Manual

[Shop genuine replacement parts for VIKING
VBCV60381](#)



[Find Your VIKING Range Hoods Parts - Select From 411 Models](#)

----- Manual continues below -----



Ref #	Part Number	Qty.	Description
1	UNSERVICEABLE	1	OVEN CAVITY, ASM 36
2	B20012417	1	RH SIDE SPACER (VBCV60/6638)
3	B20011077	1	REAR FILTER SUPT TOP (VBCV60)
4	PD020032	4	SRW-8(A)X3/8PH.WFR HD 7/16DIAXNICL
5	B2003944	1	GREASE TROUGH (VWH6048/78)
6	B20011023	1	FILTER SUPPORT BOTTOM
7	PD020087	16	10 X 1/2 PAN PH. TEK ZINC
8	A2009301	1	RH LIGHT SUPPORT TOP (VCWH)
9	PC040010	24	POP RIVET
10	A2003889	2	COWLING BRKT
11	B2003888	2	HEAT LAMP COWLING (18 HIGH HOODS)
12	B2003837	1	HEAT SENSOR BRKT
13	PE070197	1	MALE SOCKET (3 PRONG)
14	PD020010	1	10 X 3/8 GREEN GROUNDING SCREW
15	PE050156	1	PRO BLOWER CONTROL
16	B20011001	1	CONTROL PANEL (VBCV60)
17	PD030010	4	NO.10-24 KEPS NUT
18	PE040134	1	CONTROL PANEL PLATE
19	PE050050	2	HEAT LAMP SWITCH (A111B1100000)
20	PA010071	2	LIGHT/MOTOR CONTROLLER KNOB
21	PE050048	2	FAN/LIGHT SWITCH (HOODS) EP0M11J
22	PE050141	1	PRO LIGHT CONTROL
23	PE070196	2	FEMALE SOCKET (2 PRONG)
24	A2103810	1	THERMODISC BRACKET
25	PE010165	1	VIKING CHROME PLATE LOGO
26	PD030006	2	CAPPED WASHER PAL NUT
27	PE050034	4	HALOGEN BULB 50W
28	013549-000	4	LIGHT SOCKET (125C LEADS)
29	A20011005	2	BOTTOM LIGHT SUPT BRKT (VWH/VBCV/VCWH)
30	A20011083	1	LIGHT SUPPORT
31	A2009300	1	LH LIGHT SUPPORT TOP (VCWH)
32	A2009307	1	LIGHT SUPPORT TOP (VCWH6048)
33	PD020087	4	10 X 1/2 PAN PH. TEK ZINC
34	B20012418	1	LH SIDE SPACER (VBCV60/6638)
35	G3104046	3	BAFFLE FILTER ASSY (18 HOODS) 13.375 X 14
36	B20012420	2	FILTER SPACER (VBCV6038)
NI	PE070380	1	WIRE HARNESS
NI	PE070204	1	HEYCO STRAIN RELIEF - 7-P2
NI	PE070205	1	3 PRONG FEMALE SUPPLY CORD
NI	019561-000	1	ENCLOSED JUNCTION BOX
NI	PJ030014	1	HEAT SENSOR (N.O.) 160 DEG.