


This Owner's Manual is provided and hosted by [Appliance Factory Parts](#).




VIKING VBCV66381 Owner's Manual

[Shop genuine replacement parts for VIKING
VBCV66381](#)



[Find Your VIKING Range Hoods Parts - Select From 411 Models](#)

----- Manual continues below -----



Ref #	Part Number	Qty.	Description
1	UNSERVICEABLE	1	OVEN CAVITY, ASM 36
2	G3108724	5	BAFFLE FILTER ASSY (VWH2448) 9.625 X 14
3	B20012417	1	RH SIDE SPACER (VBCV60/6638)
4	B20011078	1	REAR FILTER SUPT (VBCV66)
5	PD020087	6	10 X 1/2 PAN PH. TEK ZINC
6	B2003963	1	GREASE TROUGH (VWH6648/78)
7	B20011024	1	FILTER SUPPORT BOTTOM
8	PD020032	10	SRW-8(A)X3/8PH.WFR HD 7/16DIAXNICL
9	PC040010	22	POP RIVET
10	A2009301	1	RH LIGHT SUPPORT TOP (VCWH)
11	A2003889	1	COWLING BRKT
12	B2003888	1	HEAT LAMP COWLING (18 HIGH HOODS)
13	PE070197	1	MALE SOCKET (3 PRONG)
14	PD020010	1	10 X 3/8 GREEN GROUNDING SCREW
15	PE050156	1	PRO BLOWER CONTROL
16	B20011002	1	CONTROL PANEL (VBCV66)
17	PD030010	4	NO.10-24 KEPS NUT
18	PE040134	1	CONTROL PANEL PLATE
19	PE050050	2	HEAT LAMP SWITCH (A111B1100000)
20	PA010071	2	LIGHT/MOTOR CONTROLLER KNOB
21	PE050048	2	FAN/LIGHT SWITCH (HOODS) EP0M11J
22	PE050141	1	PRO LIGHT CONTROL
23	PE070196	2	FEMALE SOCKET (2 PRONG)
24	A2103810	1	THERMODISC BRACKET
25	PD030006	2	CAPPED WASHER PAL NUT
26	PE010165	1	VIKING CHROME PLATE LOGO
27	PE050034	4	HALOGEN BULB 50W
28	013549-000	4	LIGHT SOCKET (125C LEADS)
29	PC040010	4	POP RIVET
30	A20011005	2	BOTTOM LIGHT SUPT BRKT (VWH/VBCV/VCWH)
31	A20011084	1	BOTTOM LIGHT SUPT (VWH/VBCV/VCWH66)
32	B2003837	1	HEAT SENSOR BRKT
33	PD020032	2	SRW-8(A)X3/8PH.WFR HD 7/16DIAXNICL
34	A2009300	1	LH LIGHT SUPPORT TOP (VCWH)
35	A2009308	1	LIGHT SUPPORT TOP (VCWH6648)
36	B20012418	1	LH SIDE SPACER (VBCV60/6638)
NI	PE070380	1	WIRE HARNESS
NI	PE070204	1	HEYCO STRAIN RELIEF - 7-P2
NI	PE070205	1	3 PRONG FEMALE SUPPLY CORD
NI	019561-000	1	ENCLOSED JUNCTION BOX
NI	PJ030014	1	HEAT SENSOR (N.O.) 160 DEG.