


This Owner's Manual is provided and hosted by [Appliance Factory Parts](http://Appliance Factory Parts).




# VIKING DIPR100 Owner's Manual

[Shop genuine replacement parts for VIKING DIPR100](#)



[Find Your VIKING Range Hoods Parts - Select From 411 Models](#)

----- Manual continues below -----



Ref #	Part Number	Qty.	Description
1	PV300225 PS200008		VIKING DESIGNER TOP COVER ASSEMBLY-NEW STYLE-30`` TOP COVER ASSY - WIDE (DIPR100) S97015807
2	PV300111		SUB TO PV300154 - FLTR CLP NYL RIV
3	PV300179		FILTER ASSY DIPR
4	PV300115		RIGHT END CAP
5	PV300116		LEFT END CAP
6	PV300117		TRIM PANEL (VIPR102RSS, VIPR102SS)
7	PV300120		CHIMNEY SLIDE
8	PV300121		PCB DOWN DRAFT LOWER 97015510
9	PV300122		GEAR MOTOR
10	PV300123		CRANK ASSEMBLY
11	PV300175 PV300184		SRV ASSY. REMOTE DES. SER-S97015806 GRAY REMOTE ASSEMBLY (DIPR)
12	PV300125		TOUCH PAD SWITCH HARNESS 97015514
13	PV300148		REMOTE CABLE 97015545
14	PD210015		SWITCH-DOWNDRAFT (S97015839)
15	PV300170		30 MAIN BACK ASSY 97015278
16	PV300167		30 CHIMNEY & SLIDE ASSY 97014962
NI	PV300163		GASKET FELT 30 VIPR101 99100535
NI	PV300166		INSTALLATION HARDWARE 97011305
17	PV300189		AIRBOX FRONT (VIPR102RSS, VIPR102SS)