


This Owner's Manual is provided and hosted by [Appliance Factory Parts](#).




VIKING DIPR150_1 Owner's Manual

[Shop genuine replacement parts for VIKING DIPR150_1](#)



[Find Your VIKING Range Hoods Parts - Select From 411 Models](#)

----- Manual continues below -----



Ref #	Part Number	Qty.	Description
1	PV300227		TOP COVER ASSEMBLY (BEFORE 02/04)
	PS200010		TOP COVER ASSY - WIDE (DIPR150) S97015809
2	PV300111		SUB TO PV300154 - FLTR CLP NYL RIV
3	PV300181		SRV ASSY FILTER 46N DESIGNER (S97015812)
4	PV300115		RIGHT END CAP
5	PV300116		LEFT END CAP
6	PV300194		TRIM PANEL 45N (97015986)
7	PV300120		CHIMNEY SLIDE
8	PV300121		PCB DOWN DRAFT LOWER 97015510
9	PS200015	1	GEAR MOTOR KIT (VIPR102RSS, VIPR162RSS, VIPR102SS,...
10	PV300123		CRANK ASSEMBLY
11	PV300175		SRV ASSY. REMOTE DES. SER-S97015806
	PV300184		GRAY REMOTE ASSEMBLY (DIPR)
12	PV300125		TOUCH PAD SWITCH HARNESS 97015514
13	PV300148		REMOTE CABLE 97015545
14	PD210015		SWITCH-DOWNDRAFT (S97015839)
15	PV300193		AIRBOX WELDMENT 45N (97015935)
16	PV300192		CHIMNEY WELDMENT (DIPR151RSS)
NI	PV300165		48 FELT GASKET (VIPR181) 99100539
NI	PV300166		INSTALLATION HARDWARE 97011305
17	PV300195		FRONT AIRBOX BOTTOM 45N (98009997)