


This Owner's Manual is provided and hosted by [Appliance Factory Parts](http://www.appliancefactoryparts.com).




# VIKING DIPR160 Owner's Manual

[Shop genuine replacement parts for VIKING DIPR160](#)



[Find Your VIKING Range Hoods Parts - Select From 411 Models](#)

----- Manual continues below -----



Ref #	Part Number	Qty.	Description
1	PV300226		TOP COVER ASSEMBLY (BEFORE 02/04)
1	PS200009		TOP COVER ASSY - WIDE (DIPR160) S97015808
2	PV300111		SUB TO PV300154 - FLTR CLP NYL RIV
3	PV300180		SRV ASSY FILTER 36N (S97015811)
4	PV300115		RIGHT END CAP
5	PV300116		LEFT END CAP
6	PV300118		TRIM PANEL
7	PV300120		CHIMNEY SLIDE
8	PV300121		PCB DOWN DRAFT LOWER 97015510
9	PV300122		GEAR MOTOR
10	PV300123		CRANK ASSEMBLY
11	PV300175		SRV ASSY. REMOTE DES. SER-S97015806
11	PV300184		GRAY REMOTE ASSEMBLY (DIPR)
12	PV300125		TOUCH PAD SWITCH HARNESS 97015514
13	PV300148		REMOTE CABLE 97015545
14	PD210015		SWITCH-DOWNDRAFT (S97015839)
15	PV300171		36 MAIN BACK ASSY 97015277
16	PV300168		36 CHIMNEY & SLIDE ASSY 97014963
NI	PV300164		GASKET FELT 36 VIPR161 99100536
NI	PV300166		INSTALLATION HARDWARE 97011305
17	PV300190		FRONT BOX BOTTOM