


This Owner's Manual is provided and hosted by [Appliance Factory Parts](#).




VIKING VRHW600-EP Owner's Manual

[Shop genuine replacement parts for VIKING
VRHW600-EP](#)



[Find Your VIKING Range Hoods Parts - Select From 411 Models](#)

----- Manual continues below -----



Ref #	Part Number	Qty.	Description
1	PV110016		BACK DRAFT DAMPER (WITH 9 COLLAR) BD9
2	PV120004		BAFFLE FILTER P1506
3	PV100002		HEAT LAMP SOCKET (OPTIONAL)
4	PV110007		LIGHT ASSEMBLY (COMPLETE) P-1016
5	PV110008		FLUORESCENT LAMP
6	PV100023		FLUORESCENT LAMP SOCKET-R.H.
7	PV100024		FLUORESCENT LAMP SOCKET-L.H.
8	PV120002		STARTER
9	PV100003		STARTER SOCKET
10	PV120003		BALLAST (SP2)
11	PV120005		ROTARY SWITCH (FOR HEAT LAMPS)
12	PV120006		ROTARY SWITCH (FOR REMOTE LIGHTS)
13	PV120007		VARIABLE SPEED SWITCH (FOR BLOWER) P-1404
14	PV100018SS		FRONT TRIM (60) STAINLESS
	PV100018BR		FRONT TRIM (60) BRASS
15	PV100022SS		POP RIVET (FOR FRONT TRIM) STAINLES
	PV100022BR		POP RIVET (FOR FRONT TRIM) BRASS
16	PV100007SS		SUB TO PE030066 - SS 4 ACCESSORY RAIL
	PV100007BR		SUB TO PE030067 - BR 4 ACCESSORY RAIL
17	PV100008SS		SUB TO PE030068 - SS 6 ACCESSORY RAIL
	PV100008BR		SUB TO PE030069 - BR 6 ACCESSORY RAIL
18	PV100009SS		SUB PE030054 END CAP (SS)
	PV100009BR		SUB TO PE030053 - END CAP (BRASS)
19	PE030052		SUPPORT TUBE, HOLE THROUGH
	PE030055		END CAP - BR
20	PE030056		90 DEG.ELBOWSS REPL PV100011SS
	PE030057		90 DEG.ELBOW BR REPL PV100011BR
NI	PE030076		CHROME S HOOKS REPL PV100012SS
	PE030077		BR `S` HOOKS REPL PV100012BR
21	PE010020		LOGO - PROFESSIONAL - VRTR, XBKX ASSY
	PE010019		LOGO - PROFESSIONAL - VRTR, XWHX
	PE010056		2 LOGO/VIKING PROF XBKXXBRX
	PE010055		2 LOGO/VIKING PROF XWHXXBRX
22	PV120008		ROTARY SWITCH KNOB