

This Owner's Manual is provided and hosted by [Appliance Factory Parts](#).



VIKING VEWD102 Owner's Manual

[Shop genuine replacement parts for VIKING VEWD102](#)



[Find Your VIKING Small Appliance Parts - Select From 19 Models](#)

----- Manual continues below -----

Ref #	Part Number	Qty.	Description
1	G3004143		WARMING DRAWER WELD ASSY - (30)
2	PA030005		6OZ. STAINLESS STEEL BOWL (6960)
3	PC020022		WARMING DRAWER SLIDES
4	PD020150		NO.6 X 1/2 PH. CT. SK. SMS. ``SS``
5	PD040005		SNAP BUSHING - 7/8
6	A1004135		ACCESS PLATE (VEWD)
7	PB010171		BEZEL - SS
	PB010172		BEZEL NEW BR REPL PB010107
8	B9204178		CTRL PAN)SLK SCR) XSSX (VEWD102)
	C9204178AL		CTRL PAN (SLK SCR) XALX (VEWD102)
	C9204178BK		CTRL PAN (SLK SCR) XBKX (VEWD102)
	C9204178BT		CTRL PAN VEWD102/172BTXSLKSCREENX
	C9204178BU		CTRL PAN (SLK SCR) XBUX (VEWD102)
	C9204178CB		CTRL PAN VEWD102/172CBXSLKSCREENX
	C9204178EP		CTRL PAN VEWD102/172EPXSLKSCREENX
	C9204178FG		CTRL PAN (SLK SCR) XFGX (VEWD102)
	C9204178GG		CTRL PAN (SLK SCR) XGGX (VEWD102)
	C9204178LE		CTRL PAN VEWD102/172LEXSLKSCREENX
	C9204178LN		CTRL PAN (SLK SCR) XLNX (VEWD102)
	C9204178MJ		CTRL PAN VEWD102/172MJXSLKSCREENX
	C9204178PL		CTRL PAN (SLK SCR) XPLX (VEWD102)
	C9204178SG		CTRL PAN VEWD102/172SGXSLKSCREENX
	C9204178VB		CTRL PAN (SLK SCR) XVBX (VEWD102)
	C9204178WH		CTRL PAN (SLK SCR) XWHX (VEWD102)
9	PE030001		BRACKET, DOOR, HANDLE
	PE030001PVD		END CAP DOOR HANDLE XBR
10	B9204172		O/S DOOR PANEL XSLK SCREENXVEWD102
	C9204172AL		30 O/S DOOR PNL XALX SLKSCREEN
	C9204172BK		30 O/S DOOR PNL XBKX SLKSCREEN
	C9204172BT		30 O/S DOOR PNL XBTX SLKSCREEN
	C9204172BU		30 O/S DOOR PNL XBUX SLKSCREEN
	C9204172CB		30 O/S DOOR PNL XCBX SLKSCREEN
	C9204172EP		30 O/S DOOR PNL XEPX SLKSCREEN
	C9204172FG		30 O/S DOOR PNL XFGX SLKSCREEN
	C9204172GG		30 O/S DOOR PNL XGGX SLKSCREEN
	C9204172LE		30 O/S DOOR PNL XLEX SLKSCREEN
	C9204172LN		30 O/S DOOR PNL XLNX SLKSCREEN
	C9204172MJ		30 O/S DOOR PNL XMJX SLKSCREEN
	C9204172PL		30 O/S DOOR PNL XPLX SLKSCREEN
	C9204172SG		30 O/S DOOR PNL XSGX SLKSCREEN
	C9204172VB		30 O/S DOOR PNL XVBX SLKSCREEN
	C9204172WH		30 O/S DOOR PNL XWHX SLKSCREEN
11	G3004195		DOOR SLIDE ASSY (VEWD102/162)
12	PE030062		WARMING DRAWER HANDLE SS VEWD102
	F0005008		WARMING DRAWER HANDLE XBRX VEWD102
13	A2002195		POWER CORD MOUNTING BRKT (VDSC)
14	B2004126		DRAWER STOP 30
15	B2004147		ELEMENT BRACKET (VEWD)
16	B2004141		BRACKET
17	PJ010009		ELEMENT - 30 (VEWD)
18	G3104139		FRONT FRAME ASSY (VEWD102)
19	B2004179		GASKET FRAME (VEWD102)
20	PE010142		3 LOGO XBKXXCHROME
	PE010143		3 LOGO BK/BR
	PE010144		3 LOGO XWHXCHROME
	PE010145		LOGO - WH / BR
21	PE050024		OVEN IND. LIGHT (LIGHT HOUSING)
22	B2004177		INSIDE DOOR PANEL - 30 (VEWD)
23	B2004151		INSIDE PANEL RH (VEWD)
24	B2004152		INSIDE PANEL LH (VEWD)

Ref #	Part Number	Qty.	Description
24	B2004152		INSIDE PANEL LH (VEWD)
25	B2004174		BOTTOM INSIDE PANEL - 30 (VEWD)
26	B2004176		REAR INSIDE PANEL - 30 (VEWD)
27	B2004175		TOP INSIDE PANEL - 30
28	A2004160		INSULATION PANEL
29	PE050023		OVEN IND. LIGHT (LENS & BEZEL)
30	A2004169		OUTER BOTTOM PANEL
31	A2004157		OUTER SIDE PANEL - RH
32	A2004158		OUTER SIDE PANEL - LH
33	A2004171		OUTER TOP PANEL
34	B2004131		FRONT RACK - 30 (VEWD)
35	B2004132		REAR RACK - 30 (VEWD)
36	PE070147		TERMINAL BLOCK
37	B2004148		THERMAL BULB BRKT (VEWD)
38	B1004146		THERMOSTAT SPACER (VEWD)
39	PA010072		MOISTURE SELECTOR KNOB XBKX (VEWD)
	PA010073		MOISTURE SELECTOR KNOB XWHX (VEWD)
40	PB010168		T/STAT KB BK REPL PW100008BK
	PB010169		THERMOSTAT KNOB XWHX (VEWD)
41	PB070072		WARMING DRAWER GASKET 6"/UNIT
42	PB010167		THERMOSTAT
43	A1002457		POWER CORD MOUNTING STRAP (VDSC)
NI	PE070377		VEWD/DEWD WIRE HARNESS
44	PD020009		10 X 1 PH. HD. PAN HD. SMS INSTALL HARDWARE - QTY. 4
NI	PD950012		STRIKE PANEL ACCESS
NI	PD950013		LATCH PANEL ACCESS