

This Owner's Manual is provided and hosted by [Appliance Factory Parts](#).




VIKING VEWD172 Owner's Manual

[Shop genuine replacement parts for VIKING VEWD172](#)



[Find Your VIKING Small Appliance Parts - Select From 19 Models](#)

----- Manual continues below -----



Ref #	Part Number	Qty.	Description
1	G3004144		WARMING DRAWER WELD ASSY - (27)
2	PA030005		6OZ. STAINLESS STEEL BOWL (6960)
3	PC020022		WARMING DRAWER SLIDES
4	PD020150		NO.6 X 1/2 PH. CT. SK. SMS. ``SS``
5	PD040005		SNAP BUSHING - 7/8
6	A1004135		ACCESS PLATE (VEWD)
7	PB010171		BEZEL - SS
	PB010172		BEZEL NEW BR REPL PB010107
8	B9204178		CTRL PAN)SLK SCR) XSSX (VEWD102)
	G9004191AL		CTRL PAN (PAINTED) XALX (VEWD102)
	C9204178BK		CTRL PAN (SLK SCR) XBKX (VEWD102)
	C9204178BT		CTRL PAN VEWD102/172BTXSLKSCREENX
	C9204178BU		CTRL PAN (SLK SCR) XBUX (VEWD102)
	C9204178CB		CTRL PAN VEWD102/172CBXSLKSCREENX
	C9204178EP		CTRL PAN VEWD102/172EPXSLKSCREENX
	C9204178FG		CTRL PAN (SLK SCR) XFGX (VEWD102)
	C9204178GG		CTRL PAN (SLK SCR) XGGX (VEWD102)
	C9204178LE		CTRL PAN VEWD102/172LEXSLKSCREENX
	C9204178LN		CTRL PAN (SLK SCR) XLNX (VEWD102)
	C9204178MJ		CTRL PAN VEWD102/172MJXSLKSCREENX
	C9204178PL		CTRL PAN (SLK SCR) XPLX (VEWD102)
	C9204178SG		CTRL PAN VEWD102/172SGXSLKSCREENX
	C9204178VB		CTRL PAN (SLK SCR) XVBX (VEWD102)
	C9204178WH		CTRL PAN (SLK SCR) XWHX (VEWD102)
9	PE030001		BRACKET, DOOR, HANDLE
	PE030001PVD		END CAP DOOR HANDLE XBR
10	B9204183		O/S DOOR PANEL XSLK SCREENX VEWD172
	C9204183AL		27 O/S DOOR PNL XALX SLKSCREEN
	C9204183BK		27 O/S DOOR PNL XBKX SLKSCREEN
	C9204183BT		27 O/S DOOR PNL XBTX SLKSCREEN
	C9204183BU		27 O/S DOOR PNL XBUX SLKSCREEN
	C9204183CB		27 O/S DOOR PNL XCBX SLKSCREEN
	C9204183EP		27 O/S DOOR PNL XEPX SLKSCREEN
	C9204183FG		27 O/S DOOR PNL XFGX SLKSCREEN
	C9204183GG		27 O/S DOOR PNL XGGX SLKSCREEN
	C9204183LE		27 O/S DOOR PNL XLEX SLKSCREEN
	C9204183LN		27 O/S DOOR PNL XLNX SLKSCREEN
	C9204183MJ		27 O/S DOOR PNL XMJX SLKSCREEN
	C9204183PL		27 O/S DOOR PNL XPLX SLKSCREEN
	C9204183SG		27 O/S DOOR PNL XSGX SLKSCREEN
	C9204183VB		27 O/S DOOR PNL XVBX SLKSCREEN
	C9204183WH		27 O/S DOOR PNL XWHX SLKSCREEN
11	G3004196		DOOR SLIDE ASSY (VEWD172)
12	PE030060		WARMING DRAWER HANDLE SS VEWD172
	PE030061		WM DRW HNDLE BR (18 19/32) VEWD172
13	A2002195		POWER CORD MOUNTING BRKT (VDSC)
14	B2004125		DRAWER STOP 27
15	B2004147		ELEMENT BRACKET (VEWD)
16	B2004141		BRACKET
17	PJ010010		ELEMENT - 27 (VEWD)
18	PE040083		TOP/BOTTOM TRIM - 27 (VEWD)
19	B2004188		GASKET FRAME - (VEWD172)
20	PE010142		3 LOGO XBKXXCHROME
	PE010143		3 LOGO BK/BR
	PE010144		3 LOGO XWHXCHROME
	PE010145		LOGO - WH / BR
21	PE050024		OVEN IND. LIGHT (LIGHT HOUSING)
22	B2004187		INSIDE DOOR PANEL - 27 (VEWD)
23	B2004151		INSIDE PANEL RH (VEWD)
24	B2004152		INSIDE PANEL LH (VEWD)

Ref #	Part Number	Qty.	Description
24	B2004152		INSIDE PANEL LH (VEWD)
25	B2004185		BOTTOM INSIDE PANEL - 27 (VEWD)
26	B2004180		REAR INSIDE PANEL - 27 (VEWD)
27	B2004186		TOP INSIDE PANEL - 27 (VEWD)
28	A2004160		INSULATION PANEL
29	PE050023		OVEN IND. LIGHT (LENS & BEZEL)
30	A2004181		OUTER BOTTOM PANEL
31	A2004157		OUTER SIDE PANEL - RH
32	A2004158		OUTER SIDE PANEL - LH
33	A2004182		OUTER TOP PANEL
34	B2003180		FRONT RACK - (VEWD172)
35	B2003181		REAR RACK - (VEWD172)
36	PE070147		TERMINAL BLOCK
37	B2004148		THERMAL BULB BRKT (VEWD)
38	B1004146		THERMOSTAT SPACER (VEWD)
39	PA010072		MOISTURE SELECTOR KNOB XBKX (VEWD)
	PA010073		MOISTURE SELECTOR KNOB XWHX (VEWD)
40	PB010168		T/STAT KB BK REPL PW100008BK
	PB010169		THERMOSTAT KNOB XWHX (VEWD)
41	PB070072		WARMING DRAWER GASKET 6"/UNIT
42	PB010167		THERMOSTAT
43	A1002457		POWER CORD MOUNTING STRAP (VDSC)
NI	G4004149		WIRE HARNESS (VEWD)
NI	G4004150		SUB TO PE070377 - WIRE HARNESS (VEWD)
NI	G4004197		WIRE HARNESS (VEWD)
NI	G4004198		WIRE HARNESS (VEWD)
NI	G4004199		WIRE HARNESS (VEWD)
NI	PD950012	1	STRIKE PANEL ACCESS
NI	PD950013	1	LATCH PANEL ACCESS