


This Owner's Manual is provided and hosted by [Appliance Factory Parts](#).




VIKING VGRT4804K Owner's Manual

[Shop genuine replacement parts for VIKING VGRT4804K](#)



[Find Your VIKING Range Hoods Parts - Select From 411 Models](#)

----- Manual continues below -----



Ref #	Part Number	Qty.	Description
1	PA060083		WOK GRATE
	PA060084		WOK GRATE MATTE GRAY
2	PA060044		CENTER GRATE (24 WOK)
	PA060091		CENTER GRATE MATTE GRAY
3	G3204100		WOK BURNER ASSY (24 WOK)
4	PB040160		WOK IGNITER
5	A2004105		SPARK IGNITOR BRKT (24 WOK)
6	A2004104		WOK BURNER SUPT (24 WOK)
7	J5009557		VGRT4804K TUBING
8	PB030004		GRATE SUPPORT RING (VGWT)
9	E91010661BK		GRATE SUPPORT CENTER XBKX
10	G9109551AL		GRATE SUPPORT FRAME (AL)
	G9109551BK		SUB TO G91010658BK - GRATE SUPPORT FRAME (WELD A...
	G9109551BT		GRATE SUPPORT FRAME (BT)
	G9109551CB		GRATE SUPPORT FRAME (CB)
	G9109551EP		GRATE SUPPORT FRAME (EP)
	G9109551FG		GRATE SUPPORT FRAME (FG)
	G9109551GG		GRATE SUPPORT FRAME (GG)
	G9109551LE		GRATE SUPPORT FRAME (LE)
	G9109551MJ		GRATE SUPPORT FRAME (MJ)
	G9109551SG		GRATE SUPPORT FRAME (SG)
	G9109551VB		GRATE SUPPORT FRAME (VB)
	G9109551WH		GRATE SUPPORT FRAME (WH)
11	G9109555AL		GRATE SUPPORT OUTER FRAME (AL)
	G9109555BK		GRATE SUPPORT OUTER FRAME XBKX
	G9109555BT		GRATE SUPPORT OUTER FRAME (BT)
	G9109555CB		GRATE SUPPORT OUTER FRAME (CB)
	G9109555EP		GRATE SUPPORT OUTER FRAME (EP)
	G9109555FG		GRATE SUPPORT OUTER FRAME (FG)
	G9109555GG		GRATE SUPPORT OUTER FRAME (GG)
	G9109555LE		GRATE SUPPORT OUTER FRAME (LE)
	G9109555MJ		GRATE SUPPORT OUTER FRAME (MJ)
	G9109555SG		GRATE SUPPORT OUTER FRAME (SG)
	G9109555VB		GRATE SUPPORT OUTER FRAME (VB)
	G9109555WH		GRATE SUPPORT OUTER FRAME (WH)
12	A1001619		SPARK MODULE PLATE
13	PA020047		INVENSYS 0+4 RE-IGNITION SPARK MODULE
14	PA060037		GRATE BK REPL PA060024 (GEN.NO.2)
	PA060038		GRAY GRATES
15	PA080009		GLOSS BLACK BURNER CAP
	PA080016		BURNER CAP-VGRT (GRAY-MATT)
16	G50013584AL		BURNER GRATE SUPPORT ASSEMBLY - AL
	G50013584BK		GRATE SUPPORT SERVICE KIT (BK)
	G50013584BT		GRATE SUPPORT SERVICE KIT (BT) - NLA
	G50013584CB		BURNER GRATE SUPPORT ASSEMBLY - CB
	G50013584EP		BURNER GRATE SUPPORT ASSEMBLY - EP
	G50013584FG		BURNER GRATE SUPPORT ASSEMBLY - FG
	G50013584GG		BURNER GRATE SUPPORT ASSEMBLY - GG
	G50013584LE		BURNER GRATE SUPPORT ASSEMBLY - LE
	G50013584MJ		BURNER GRATE SUPPORT ASSEMBLY - MJ
	G50013584SG		BURNER GRATE SUPPORT ASSEMBLY - SG
	G50013584VB		BURNER GRATE SUPPORT ASSEMBLY - VB
	G50013584WH		GRATE SUPPORT SERVICE KIT (WH)
17	PA030002AL		BURNER BOWL - AL
	PA030002BK		BURNER BOWL (VGRT) XBKXXX
	PA030002BT		BURNER BOWL - BT
	PA030002CB		BURNER BOWL - CB
	PA030002EP		BURNER BOWL - EP
	PA030002FG		BURNER BOWL - FG
	PA030002GG		BURNER BOWLS - GG

Ref #	Part Number	Qty.	Description
	PA030002GG		BURNER BOWLS - GG
	PA030002LE		BURNER BOWLS - LE
	PA030002MJ		BURNER BOWL (VGRT) XXMJXX
	PA030002SG		BURNER BOWL - SG
	PA030002VB		BURNER BOWL (VGRT) XXVBXX
	PA030002WH		BURNER BOWL (VGRT) XXWHXX
18	B2001919		SIDE PANEL-RH (VGRT)
19	B2001915		SIDE TRIM-RH (VGRT)
	C9301915BR		SIDE TRIM RH (VGRT) XBRX
20	A2001911		BURNER BOX SIDE RH
21	PK000008		DRIP TRAY GUIDE - RH
22	A2001160		DRIP TRAY GUIDE BRKT (VGRT)
23	PK000010		RUNNER, DRIP TRAY - RH (VGRT)
24	PA080037		TOP BURNER FRONT REPL PA080007
25	PA080036		TOP BURNER REAR REPL PA080008
26	G3004873		DRIP TRAY WELD ASSY (48)
27	J2101749		GREASE PAN
28	PA070001		PRESSURE REGULATOR (NAT.)
29	PK000009		RUNNER, DRIP TRAY - LH (VGRT)
30	B2001920		SIDE PANEL-LH (VGRT)
31	B2001916		SIDE TRIM-LH (VGRT)
	C9301916BR		SIDE TRIM LH (VGRT) XBRX
32	A2001912		BURNER BOX SIDE LH
33	PK000007		DRIP TRAY GUIDE - LH (VGRT)
34	A1009550		WOK FRONT PANEL (VGRT4804K)
35	PA050094		MANIFOLD
36	G50012678		TOP BURNER VALVE KIT (BRASS VALVE REPLACEMENT)
	PA010157		SUB TO 003515-000 - RANGE TOP BURNER VALVE
37	PA010119		SUB TO 003546-000 - RANGE GRILL VALVE-BRASS
38	PA020037		SINGLE MODULE 120V
39	PA020015		SPARK IGNITION SWITCH
	PA020045		IGNITOR SWITCH
40	B9209548		CTRL PAN-(VGRT48-4K) XSLK SCRX
41	PB010208		BEZEL, CHROME PLATE
	PB010209		BEZEL BRASS
42	PB010206		VGSC,VGRC,VGRT TOP BURNER KNOB(BK)
	PB010207		VGSC,VGRC,VGRT TOP BURNER KNOB(WH)
43	PA010122		VGRC/IC/RT GRILL KNOB (BK)
	PA010123		VGRC/IC/RT GRILL KNOB (WH)
44	PE010142		3 LOGO XBKXXCHROME
	PE010143		3 LOGO BK/BR
	PE010144		3 LOGO XWHXCHROME
	PE010145		LOGO - WH / BR
45	G3002580		DRIP TRAY HANDLE ASSY XSSX (VDSC48)
	G9302581PVD		DRIP TRAY HANDLE - BR (BEFORE 3/23/04)
46	G3001584		LANDING LGD 48
NI	PM010043		CARBON STEEL WOK
NI	PM010044		WOK LID FOR PM010043
47	PA020028		SPARK IGNITER