

This Owner's Manual is provided and hosted by [Appliance Factory Parts](#).



STOK SGP4333SB Owner's Manual

[Shop genuine replacement parts for STOK SGP4333SB](#)



[Find Your STOK Grill Parts - Select From 22 Models](#)

----- Manual continues below -----

STÖK
4 Burner LP Gas Grill
Model No. SGP4333SB
Repair Sheet


STÖK
Gril aux gaz de pétrole liquéfiés (GPL) à 4 brûleurs
Numéro de modèle SGP4333SB
Feuille de réparation

STÖK
Parrilla de gas PL de 4 quemadores
Número de modelo SGP4333SB
Lista de piezas de repuesto



SGP4333SB

FIGURE A / FIGURA A





SGP4333SB


FIGURE A

KEY	P/N	DESCRIPTION	QTY	PIÈCE RÉF.	DESCRIPTION	QTÉ	REF. N/P
1	081001083061	Warming Rack	1	1 081001083061	Plateau de réchauffage.....	1	1 0810010830
2	081001026040	Removable Grate Insert.....	2	2 081001026040	Insert de grille amovible.....	2	2 0810010260
3	081001083062	Grate.....	2	3 081001083062	Grille	2	3 0810010830
4	081001083063	Heat Tent	4	4 081001083063	Plaque de distribution de chaleur	4	4 0810010830
5	081001083064	Regulator and Hose Assembly w/Instruction Sheet	1	5 081001083064	Régulateur et le tuyau avec feuille d'instruction	1	5 0810010830
6	081001083065	Gas Bracket.....	3	6 081001083065	Support à essence	3	6 0810010830
7	081001083811	Firebox Assembly	1	7 081001083811	Ensemble de cuve	1	7 0810010838
8	081001083068	Gas Burner Assembly w/Clip and Screw	4	8 081001083068	Ensemble de brûleur à gaz avec clip et vis.....	4	8 0810010830
9	081001083082	Grease Tray.....	1	9 081001083082	Plateau à graisse	1	9 0810010830
10	081001083083	Grease Cup.....	1	10 081001083083	Godet à graisse	1	10 0810010830
11	081001083076	Electronic Ignitor.....	1	11 081001083076	Allumeur électrique.....	1	11 0810010830
12	081001089063	Control Panel	1	12 081001089063	Panneau de control	1	12 0810010890
13	081001083079	Bezel.....	4	13 081001083079	Collet	4	13 0810010830
14	081001083081	Control Knob	4	14 081001083081	Bouton de commande.....	4	14 0810010830
15	081001083075	Gas Manifold Assembly.....	1	15 081001083075	Ensemble de tubulure à essence	1	15 0810010830
16	081001083070	Electrode 1	1	16 081001083070	Électrode 1	1	16 0810010830
17	081001083069	Electrode 2	1	17 081001083069	Électrode 2	1	17 0810010830
18	081001083071	Electrode 3	1	18 081001083071	Électrode 3	1	18 0810010830
19	081001083072	Electrode 4	1	19 081001083072	Électrode 4	1	19 0810010830
20	081001083074	Firebox Front Cover.....	1	20 081001083074	Panneau avant.....	1	20 0810010830
21	089260014701	Insert Removal Tool	1	21 089260014701	Outil de retrait d'inserts	1	21 0892600147
22	081001083067	Rubber Bumper	4	22 081001083067	Amortisseur en caoutchouc	4	22 0810010830
23	081001089023	Veggie Tray	1	23 081001089023	Panier à légumes	1	23 0810010890
24	089260017701	Pizza Stone.....	1	24 089260017701	Pierre à pizza	1	24 0892300177
25	089260016701	Griddle.....	1	25 089260016701	Plaque chauffante	1	25 0892600167
Not Shown:							
081001083901	Hardware Blister Pack (Retail)			081001083901	Sachet buille de quincaillerie (vente au détail)		0810010839
081001083902	Hardware Blister Pack (Factory)			081001083902	Sachet buille de quincaillerie (usine)		0810010839
991000688	Operator's Manual (081001089902)			991000688	Manuel d'utilisation (081001089902)		991000688



SGP4333SB

FIGURE B / FIGURA B





SGP4333SB


FIGURE B / FIGURA B

KEY	P/N	DESCRIPTION	QTY	PIÈCE RÉF.	DESCRIPTION	QTÉ	REF. N/P
1	081001043007	Temperature Gauge Assembly	1	1 081001043007	Ensemble de jauge de température	1	1 081001043007
2	081001083800	Hood Assembly	1	2 081001083800	Ensemble de couvercle	1	2 081001083800
3	081001083804	Side Shelf (Right)	1	3 081001083804	Étagère latérale (droite).....	1	3 081001083804
4	081001083021	Towel Bar	2	4 081001083021	Porte-serviettes	2	4 081001083021
5	081001089802	Side Shelf Assembly (Left).....	1	5 081001089802	Ensemble de étagère latérale (gauche)	1	5 081001089802
6	081001083022	Towel Bar Bezel	4	6 081001083022	Collet de porte-serviettes	4	6 081001083022
7	081001083026	Match Holder w/Chain.....	1	7 081001083026	Porte-allumettes avec la chaîne	1	7 081001083026



SGP4333SB

FIGURE C / FIGURA C





SGP4333SB

FIGURE C / FIGURA C

KEY	P/N	DESCRIPTION	QTY	PIÈCE RÉF.	DESCRIPTION	QTÉ	REF. N/P
1	081001083055	Base	1	1 081001083055	Base.....	1	1 0810010830
2	081001083806	Locking Caster Assembly.....	2	2 081001083806	Ensemble de roulettes verrouillables..	2	2 0810010838
3	081001083805	Caster Assembly (No lock)	2	3 081001083805	Ensemble de roulettes (pas de verrou).....	2	3 0810010838
4	081001089808	Door Assembly (Left).....	1	4 081001089808	Ensemble de porte (gauche).....	1	4 0810010898
5	081001089809	Door Assembly (Right).....	1	5 081001089809	Ensemble de porte (droite)	1	5 0810010898
6	081001083807	Side Panel (Right)	1	6 081001083807	Panneau latéral (droite).....	1	6 0810010838
7	081001083049	Side Panel (Left)	1	7 081001083049	Panneau latéral (gauche)	1	7 0810010830
8	081001083054	Rear Panel	1	8 081001083054	Panneau arrière.....	1	8 0810010830
9	081001083050	Door Header	1	9 081001083050	Linteau de la porte.....	1	9 0810010830
10	081001083057	Insert Bracket	3	10 081001083057	Insérer le support.....	3	10 0810010830
11	941001209	Warning/Data Label.....	1	11 941001209	Avertissement/étiquette de données..	1	11 941001209