

Package Contents



PART	DESCRIPTION	QTY.
Α	Hood Handle	1
В	Temperature Gauge	1
С	Temperature Gauge Bezel	1
D	Grill Body Assembly	1
E	Control Knob	5
F	Grease Pan	1
G	Grease Cup	1
Н	Warming Rack	1
ı	Cooking Grate For Main Burner	2
J	Heat Tent For Main Burner	4
K	Left Side Table	1
L	Cooking Grate For Sear Burner	1
М	Heat Tent For Sear Burner	1
N	Right Side Burner Body	1
0	Left Leg Assembly	1

PART	DESCRIPTION	QTY.
Р	Leg End Cap	2
Q	Side Exclusion Bar	1
R	Tank Brace	1
S	Cart Rear Support	1
T	Cart Front Panel - Upper	1
U	Cylinder Exclusion	1
V	Cart Front Panel - Lower	1
W	Axle	1
X	Wheel	2
Υ	Right Leg Assembly	1
Z	Condiment Tray	1
A1	Control Knob for Sear Burner	1
B1	Side Burner Grate	1
C1	Side Burner	1
D1	Side Burner Control Knob Bezel	1
E1	Tank Retention Fixed Wire	2

Hardware Contents



Preparation

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list on previous page and hardware contents above. If any part is missing or damaged, do not attempt to assemble the product. Contact customer service for replacement parts.


Estimated Assembly Time: 50 minutes with 2 people.

A CAUTION

THIS UNIT IS HEAVY. Two people required for safe assembly.

Two people required for safe assembly. Some parts may contain sharp edges. Wear protective gloves if necessary. Read and follow all safety statements, warnings, assembly instructions and use and care instructions before attempting to assemble and use.







Tools Required for Assembly and Leak Testing (not included): Phillips screwdriver, Spray bottle

Assembly Instructions


1 Assembly – Left Leg




2 Assembly - Right Leg




3 Assembly – Cart Front Panels




4 Assembly – Back Exclusion Bar and Cart Rear Support



5 Assembly – Tank Brace and Side Exclusion Bar




6 Assembly – Handle, Knobs, and Temperature Gauge



Assembly – Grill Body to Base





Assembly – Left Side Table and Condiment Tray Rear shown, same for front 5 Threads D Rear shown, **5X 2X** same for front B Tab Slot




Assembly – Right Side Shelf Rear shown, 1 A B same for front A 5 Threads 100000 DD 2 DD OD (HI 3 5X 2X В E **Engage slots and** tighten screws


10 Assembly – Side Burner









11 Assembly – Heat Tents




12 Assembly – Rack and Cooking Grates



13 Assembly – Side Burner Grate



14 Assembly – Grease Pan and Grease Cup



15 Assembly – Propane Cylinder

