

Parts List for Model CGI08ALP Grill

KEY	DESCRIPTION	PART#	QTY
1	Lid Assembly	P00147063A	1
2	Temperature Gauge	P00601071A	1
3	Lid Handle	P00205086B	1
4	Heat Insulating Spacer	P06801022A	2
5	Protective Pad	P05518011 I	2
6	Cooking Rack/Secondary	P01516004B	1
7	Cooking Grid, 13"	P01604013B	2
8	Cooking Grid, 6.4"	P01604031B	1
9	Burner/Main	P02008032A	3
10	Infrared Burner Assembly	P02005010A	1
11	Thermocouple	P05305019A	1
12	Savor Plate®	P01708033E	3
13	Savor Plate® Bracket, Front	P033280504	3
14	Savor Plate® Bracket, Rear	P033280514	3
15	Burner Bracket	P02210034A	1
16	Back Burner Assembly	P02007068A	1
17	Back Burner Electrode	P02614025A	1
18	Back Burner Wind Shield	P06906046B	1
19	Back Burner Orifice	P06534005A	1
20	Refrigerator Bracket, Left	P03329012D	1
21	Back Burner Thermocouple	P05305022A	1
22	Back Burner Thermocouple Bracket	P03328047C	1
23	Bowl Panel, Front	P0073878KA	1
24	Burner Heat Shield	P06906045A	1
25	Grease Tray Heat Shield	P06904020C	1
26	Grease Tray Heat Shield, Lower	P06903050M	1
27	Electric Wire Set	P02615121A	1
28	Gas Collector Box with Electrode	P02609010B	3
29	Gas Valve/Manifold Assembly	Y0060571	1
30	Grease Draining Plate	P06902006B	2
31	Lighting Stick	P05507008A	1
32	Bowl Support Bracket, Left	P01301006D	1
33	Bowl Support Bracket, Right	P01302006D	1
34	Control Panel Extension	P02909768S	1
35	Control Panel Upper	P02915061S	1
36	Control Panel	P02915051S	1
37	Electric Ignitor, 6-port	P02502265C	1
38	Control Knob Seat	P03415014A	5
39	Control Knob	P03429065V	3
40	Control Knob For Back Burner/Infrared Burner	P03429175V	2
41	Control Knob Spring	P05504021A	5
42	Name Plate	P00407010D	1
43	Electric Ignitor Protector	P05545002A	1
44	Grease Tray	P02717454A	1
45	Grease Tray Handle	P00213012B	1
46	Cart Panel, Top	P07805002A	1