

This Owner's Manual is provided and hosted by [Appliance Factory Parts](#).



Napoleon B36PTR-1 Owner's Manual

[Shop genuine replacement parts for Napoleon
B36PTR-1](#)



ASCENT™ 36

Direct Vent, Millivolt Ignition

Propane

[Find Your Napoleon Fireplace Parts - Select From 171 Models](#)

----- Manual continues below -----


ASCENT™ 36 DIRECT VENT GAS FIREPLACE




Specifications

Model	BTU	Width		Height		Depth		Viewing Area
		Actual	Framing	Actual	Framing	Actual	Framing	
B36	18,000	35	35 1/2	34 5/8	35	15 3/4	16	23 11/16 X 30 11/16


Front Options



Rough Framing




Finish Framing




Spécifications

Modèle	BTU	Largeur		Hauteur		Profondeur		Dimensions de Vision
		Réel	Ossature	Réel	Ossature	Réel	Ossature	
B36	18,000	35	35 1/2	34 5/8	35	15 3/4	16	23 11/16 X 30 11/16


Façades Décoratives



Ossature approximatif



Ossature fini




FOYER À GAZ VENTILÉ DIRECTE ASCENT^{MD} 36




Information du produit fourni n'est pas complet et est sujet de changer sans préavis. Consultez le manuel d'installation pour information d'installation actuel.


Dimensions



Passage d'un section dans un mur



Dégagements Combustible de la Tablette



Location de l'appareil

