


Replacement Parts



Part	Description	QTY	Part #
1	Warming Rack Bracket	2	VN0001
2	Warming Rack	1	VN0002
3	Main Cooking Grate	3	VN0003
4	Main Charcoal Grate	3	VN0004
5	Logo plate	1	VN0005
6	Temperature gauge	1	VN0006
7	Chimney Cap	1	VN0007
8	Chimney	1	VN0008
9	Side Handle	1	VN0009
10	Grease Cup Holder	1	VN0010
11	Grease Cup	1	VN0011
12	Cart Leg Corner LR/RF	2	VN0012
13	Cart Brace Left	1	VN0013
14	Cart Leg Corner LF/RR	2	VN0014
15	Cart Leg Left Rear	1	VN0015
16	Cart Leg Left Front	1	VN0016
17	Grill Lid Handle	1	VN0017
18	Grill Lid	1	VN0018
19	Grill Firebox	1	VN0019
20	Front Shelf	1	VN0020
21	Cart Leg Center	2	VN0021
22	Cart Base Panel	2	VN0022
23	Axle	1	VN0023
24	Cart Leg Right	2	VN0024
25	Wheel	2	VN0025
26	Cart Brace Right	1	VN0026
27	Smoker Box Vent Screen	1	VN0027
28	Smoker Box Vent	1	VN0028
29	Smoker Box Bottom	1	VN0029
30	Smoker Box Vent Holder	2	VN0030
31	Smoker Box Top	1	VN0031
32	Smoker Box Lid	1	VN0032
33	Smoker Box Lid Handle	1	VN0033
34	Smoker Box Lid Stop	1	VN0034
35	Smoker Box Charcoal Grate	2	VN0035
36	Smoker Box Cooking Grate	2	VN0036
37	Smoker Box Ash Shield	1	VN0037
38	Chimney Gasket	1	VN0038

Part	Description	QTY	Part #
Parts not shown			
	Instruction manual	1	VN0039
	Hardware pack	1	VN0040