



Position	Code	description
01	AS00001687	FRONT PANEL
02	AS00001689	LEFT HANDLE
03	AS00001690	RIGHT HANDLE
04.01	AS00001691	COVER
04.02	AS00001692	RECEIVER PCB
04.03	AS00001693	SUPPORT
05	AS00001694	GRID
06	AS00001695	BLOCK
07	AS00001696	BLOCK
08	AS00001697	MOTOR
09	AS00001698	DUCT
10	AS00001699	GRID
11	AS00001700	FAN
12	AS00001701	DUCT
13	AS00001702	EVAPORATOR
14	AS00001703	REMOTE CONTROL
16	AS00001704	GASKET
17	AS00001705	DRAIN TUBE
18	AS00001706	WINDOW BRACKET
19	AS00001707	GRID
20.01	AS00001708	COVER
20.02	AS00001709	DISPLAY PCB
20.03.01	AS00001710	COVER
20.03.02	AS00001711	OVERLAY
21	AS00001712	FILTER
22	AS00001713	COVER
24	AS00001714	STOPPER
26	AS00001715	POWER SUPPLY CORD (US)
27	AS00001716	REAR PANEL
28	AS00001717	TEMPERATURE SENSOR
29	AS00001718	TEMPERATURE SENSOR
30	AS00001719	SENSOR
31.01	AS00001720	BOARD COVER
31.02	AS00001721	COVER
31.03	AS00001722	CONTROL PCB
31.04	AS00001723	CAPACITOR
32	AS00001724	COVER

33	AS00001725	COVER
34	AS00001726	CAPACITOR COVER
35	AS00001727	CAPACITOR COVER
36	AS00001728	CAPACITOR
37	AS00001729	FAN MOTOR
38	AS00001730	WIRE CLAMP
39	AS00001731	SUPPORT
40	AS00001732	DUCT
41	AS00001733	FAN
42	AS00001734	DUCT
43	AS00001735	CONDENSER
44	AS00001736	BRACKET
45	AS00001737	BRACKET
48	AS00001738	DELIVERY TUBE
49	AS00001739	RUNBACK TUBE
50	AS00001740	CAPILLARY
51	AS00001741	CABLE
52	AS00001742	COMPRESSOR
53	AS00001743	SUPPORT
54	AS00001744	REED SENSOR
55	AS00001745	FASTENER
56	AS00001746	MOTOR
57	AS00001747	IMPELLER
58	AS00001748	COVER
59	AS00001749	SUPPORT BASE
60	AS00001750	CASTOR
61	AS00001751	CONNECTOR
62	AS00001752	TUBE
63	AS00001753	CONNECTOR