

This Owner's Manual is provided and hosted by [Appliance Factory Parts](#).



Shop Vac UL2S300 Owner's Manual

[Shop genuine replacement parts for Shop Vac UL2S300](#)



[Find Your Shop Vac Vacuum Cleaner Parts - Select From 498 Models](#)

----- Manual continues below part list -----

Available Replacement Parts for Shop Vac UL2S300

3008000	FILTER RETAINER
8565750	CASTER RETAINER
0704399	FLAT WASHER
4300299	Cap Nut.
6773900	CASTER (SEE ADD'L INFO)
2425010	Wheel.
7413120	INLET DEFLECTOR
1503999	screw
3545000	Cup Float.
1517699	Screw.
7444500	Lid Latch.
7414210	OFF SWITCH COVER ONLY, NOT THE ACTUAL SW
7414200	ON SWITCH COVER ONLY, NOT THE ACTUAL SWI
7446800	Drain cap
7414250	Switch Button Extension .

Model 92L2S300



ITEM	DESCRIPTION	PART NO.
1	Screw ¼" X ½" trilobe ph pan	1517499
2	Handle	1944475
3	Switch button - I	7414200
4	Switch button - O	7414210
5	Outer motor cover assembly	1944137
6	Switch button extension	7414250
7	Inner motor cover	3748921
8	Screw 10 X ¾" sl hex hd	1503999
9	Power unit assembly	1945016
10	Float	3545000
11	Lid latch	7444500
12	Lid cage and latch assembly	1945015
13	Screw 10 x ¾" trilobe	1517699
14	Cartridge filter	90350
15	Filter retainer	3008000
16	High efficiency collection bag	9190710
17	Tank assembly	7368097
18	Inlet deflector	7413120
19	Carriage handle	2088000
20	Screw ¼" - 20 x ¾" slotted thread	0810899
21	Sealing washer	0701299
22	¼" - 20 locknut - heavy hex hd	1304599
23	Rear dolly/basket	7417350
24	Axle	2442100
25	8" rear wheel	2425010
26	Cap nut	4300299
27	Casterfoot A	7431330
28	Casterfoot B	7431350
29	Retainer	8565700
30	Flat washer	0704399
31	Caster	6773900
32	Drain cover	7446800

* Replacement parts may differ from original equipment.

